Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

esonstyle ES-S13

esonstyle ES-S13 Invisible Sleep Earbuds User Manual

Model: ES-S13

1. Introduction

Thank you for choosing the esonstyle ES-S13 Invisible Sleep Earbuds. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it thoroughly before use to ensure optimal performance and longevity of your earbuds.
The esonstyle ES-S13 earbuds are designed for comfort and noise blocking, making them ideal for sleep, relaxation, and light activities. They feature Bluetooth 5.4 connectivity and IPX6 waterproofing.

2. Product Overview

2.1 Package Contents

- esonstyle ES-S13 Invisible Sleep Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual

2.2 Key Features

- **Invisible Design:** Micro-sized for comfortable wear, especially for side sleepers.
- **Noise Blocking:** Provides passive noise cancellation for a peaceful environment.
- **Bluetooth 5.4:** Ensures a fast, stable, and lag-free wireless connection.
- **IPX6 Waterproof:** Resistant to sweat and rain, suitable for various activities.
- **Long Battery Life:** Up to 4 hours of playback, with an additional 24 hours provided by the charging case.
- **Touch Control:** Intuitive touch controls for media playback and calls.

2.3 Product Components and Appearance



Figure 1: esonstyle ES-S13 Invisible Sleep Earbuds in their charging case. The image displays the compact design of the earbuds and the portable charging case, both in a rose gold color scheme.



Figure 2: Illustration of the earbuds' noise-blocking capability. A person is shown sleeping peacefully, indicating the earbuds' function in creating a quiet environment.



Figure 3: Depiction of the earbuds' IPX6 waterproof rating. A person is shown sweating during a workout, highlighting the earbuds' resistance to moisture.



Figure 4: Close-up of a single earbud, emphasizing its tiny, invisible design and the integrated Bluetooth chip for wireless connectivity.



Figure 5: Visual representation of the battery life. It shows 4 hours of playback time for the earbuds and an additional 24 hours provided by the charging case, totaling 28 hours.

3. Setup Instructions

3.1 Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case.
2. **Connect Charger:** Connect the USB-C charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).
3. **Charging Indicators:** The charging case will display an indicator light (refer to product for specific light behavior) to show charging status. The earbuds will also indicate charging when placed in the case.
4. **Charging Time:** A full charge for the case and earbuds typically takes approximately 1.5 hours.

Note: *Ensure the charging contacts on both the earbuds and the case are clean and dry before charging.*

3.2 Bluetooth Pairing

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. You may hear an audio prompt indicating they are ready to pair.
2. **Activate Bluetooth:** On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Select Device:** In the list of available Bluetooth devices, look for "ES-S13" or "esonstyle ES-S13" and select it to connect.
4. **Confirmation:** Once successfully paired, you will hear an audio confirmation, and the earbuds' indicator lights (if present) will change.
5. **Reconnect:** After initial pairing, the earbuds will automatically connect to the last paired device when removed from the case and Bluetooth is active on your device.

Tip: *If pairing fails, place the earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and try again. Ensure no other devices are actively trying to connect to the earbuds.*

4. Operating Instructions

4.1 How to Wear

For optimal comfort and sound quality, ensure the earbuds are correctly positioned in your ears. The ES-S13 earbuds are designed to be discreet and comfortable, especially for side sleepers.



Figure 6: Visual guide for wearing the earbuds. The diagram illustrates the two steps: "Insert" the earbud into the ear canal and then "Tuck" the outer part for a secure and comfortable fit.

1. **Insert:** Gently place the earbud into your ear canal.
2. **Tuck:** Adjust the earbud so that the small wing or outer part tucks securely into the concha of your ear. This provides stability and helps with noise blocking.

Experiment with the fit to find the most comfortable and secure position for your ear shape.

4.2 Touch Controls

The esonstyle ES-S13 earbuds feature intuitive touch controls on each earbud. Specific functions may vary slightly, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.

- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).
- **Volume Control:** (If supported) Long press on left earbud for volume down, long press on right earbud for volume up. Refer to the quick start guide included in your package for exact touch control mapping.

5. Maintenance

5.1 Cleaning

- **Earbuds:** Gently wipe the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. If necessary, use a slightly damp cloth with water, then dry immediately.
- **Charging Case:** Clean the charging case with a soft, dry cloth. Ensure the charging pins inside the case are free of dust and debris.
- **Do Not Use:** Avoid using harsh chemicals, abrasive materials, or solvents for cleaning, as these can damage the product.

5.2 Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures, humidity, and direct sunlight.

6. Troubleshooting

Problem	Possible Cause	Solution
Earbuds not turning on.	Low battery.	Place earbuds in the charging case and charge fully.
Cannot pair with device.	Bluetooth is off; earbuds are not in pairing mode; previously paired with another device.	◦ Ensure Bluetooth is enabled on your device. ◦ Place earbuds back in case, close, then open to re-enter pairing mode. ◦ Forget/delete "ES-S13" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Volume too low; earbuds not properly seated; connection issue.	◦ Increase volume on both your device and the earbuds. ◦ Adjust earbuds for a secure fit. ◦ Reconnect the earbuds to your device.
Earbuds disconnect frequently.	Out of Bluetooth range; interference; low battery.	◦ Keep your device within 10 meters (33 feet) of the earbuds. ◦ Avoid strong electromagnetic interference. ◦ Ensure earbuds and case are sufficiently charged.

If the issue persists, please refer to the support information provided in Section 8.

7. Specifications

Feature	Detail
Model Name	ES-S13
Brand	esonstyle
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	10 Meters
Noise Control	Passive Noise Cancellation
Water Resistance Level	IPX6 Waterproof
Control Method	Touch
Earbud Playback Time	Up to 4 hours
Total Battery Life (with case)	Up to 28 hours (4 hours earbuds + 24 hours case)
Charging Time	Approximately 1.5 hours
Charging Interface	USB-C
Item Weight	2.05 ounces (58 grams)
Material	Acrylonitrile Butadiene Styrene (ABS)
Compatible Devices	Smartphones, Telephones, Cellphones

8. Warranty and Support

The esonstyle ES-S13 Invisible Sleep Earbuds come with a user manual included in the package. For specific warranty details, please refer to the documentation provided with your purchase or contact esonstyle customer support.
For further assistance, troubleshooting, or inquiries, please visit the official esonstyle website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official online presence.

© 2023 esonstyle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074SJ47BM

More documents and user manuals: **https://manuals.plus/**