

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Convenience Concepts](#) /
- › [Convenience Concepts Omega Coffee Table \(Model 203220GY\) - Instruction Manual](#)

Convenience Concepts 203220GY

Convenience Concepts Omega Coffee Table (Model 203220GY)

Brand: Convenience Concepts | Model: 203220GY

1. SAFETY INFORMATION

Please read and understand all instructions before assembling and using this product. Keep this manual for future reference.

- **Maximum Weight Capacity:** The top surface of this coffee table is designed to support up to 100 pounds (45 kg). The lower shelf has a lower weight capacity. Do not exceed these limits.
- **Assembly Surface:** Assemble the unit on a soft, clean surface like a carpet to prevent scratches or damage to the furniture.
- **Secure Connections:** Ensure all screws, bolts, and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Avoid Climbing:** Do not allow children to climb on or play with the coffee table.
- **Proper Placement:** Place the coffee table on a level surface to prevent tipping.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact Convenience Concepts customer support.

| Part | Description | Quantity |
|------|---|----------|
| A | Top Panel | 1 |
| B | Bottom Shelf | 1 |
| C | Side Panels (with octagon cut-outs) | 2 |
| D | Legs | 4 |
| E | Hardware Pack (screws, cam bolts, etc.) | 1 |

3. ASSEMBLY INSTRUCTIONS

Estimated Assembly Time: 30-60 minutes. Tools required: Phillips head screwdriver (not included).

1. **Prepare the Area:** Clear a spacious area and lay out all components on a soft, clean surface like a carpet to prevent damage.
2. **Attach Legs to Side Panels:** Secure the four legs (D) to the bottom of the two side panels (C) using the provided

hardware from pack (E). Ensure they are firmly attached.

3. **Connect Bottom Shelf:** Attach the bottom shelf (B) to the assembled side panels and legs. Make sure the pre-drilled holes align for proper fastening.
4. **Attach Top Panel:** Carefully place the top panel (A) onto the assembled structure. Align the holes and secure it using the remaining hardware from pack (E).
5. **Final Tightening:** Once all parts are in place, gently tighten all screws and bolts. Avoid over-tightening to prevent stripping or damaging the wood.
6. **Positioning:** Carefully lift the assembled coffee table and place it in its desired location.




Figure 1: Product Dimensions. This image illustrates the length (39.5 inches), width (21.75 inches), and height (17.75 inches) of the coffee table, including the 10.5-inch clearance between the top and bottom shelves.



Figure 2: Assembled Coffee Table. This image shows the fully assembled grey coffee table with its two tiers and decorative octagon side cut-outs, positioned in a living room.

4. CARE AND MAINTENANCE

To ensure the longevity and appearance of your Omega Coffee Table, follow these care guidelines:

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Heat and Moisture:** Use coasters under beverages and hot pads under warm items to protect the surface from heat and moisture rings.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Moving:** When moving the table, always lift it rather than dragging it to prevent damage to the legs and frame.

5. TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Difficulty with Assembly:** If parts do not align easily, double-check the orientation of each piece against the diagrams. Ensure all cam bolts are fully inserted before attempting to connect components. Sometimes, a slight adjustment or loosening of previously tightened screws can help.
- **Table Wobbles:** Ensure the table is placed on a level surface. Check that all screws and bolts are tightened evenly.

and securely. If wobbling persists, slightly loosen all fasteners, press down on the table to ensure it's level, then re-tighten.

- **Scratches/Dings:** Minor scratches can sometimes be touched up with a furniture repair marker matching the grey finish. For deeper damage, professional repair may be necessary. Always assemble on a soft surface to minimize this risk.
- **Weight Capacity Concerns:** This table is designed for decorative items and light use. Do not place excessive weight on the table, especially on the top surface (maximum 100 lbs) or lower shelf. Avoid sitting or standing on the table.

6. SPECIFICATIONS

| Feature | Detail |
|--------------------------------|-------------------------------------|
| Model Number | 203220GY |
| Brand | Convenience Concepts |
| Color | Grey |
| Product Dimensions (L x W x H) | 39.5" x 21.75" x 17.75" |
| Item Weight | 37 Pounds (16.78 kg) |
| Maximum Weight Recommendation | 100 Pounds (45 kg) |
| Frame Material | Manufactured Wood / Engineered Wood |
| Number of Shelves | 1 |
| Care Instructions | Wipe with Dry Cloth |

7. WARRANTY AND SUPPORT

For warranty information, please refer to the product packaging or the official Convenience Concepts website. For additional support, missing parts, or further inquiries, please contact Convenience Concepts customer service directly.

Note: Product specifications and appearance are subject to change without notice.