Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- **BONTEC** /
- > BONTEC Portable Mobile Standing Laptop Desk MWS-001BK Instruction Manual

BONTEC MWS-001BK

BONTEC Portable Mobile Standing Laptop Desk MWS-001BK Instruction Manual

Model: MWS-001BK

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your BONTEC Portable Mobile Standing Laptop Desk, Model MWS-001BK. Please read this manual thoroughly before use to ensure proper function and safety.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Do not exceed the maximum weight capacity: Main desktop 44 lbs (20 kg), Secondary shelf 22 lbs (10 kg).
- · Keep children and pets away during assembly.
- Tighten all screws firmly, but do not overtighten.
- Use on a flat, stable surface.
- Lock casters when the desk is in a stationary position.

PACKAGE CONTENTS

Verify that all parts are included in your package:

- · Main Desktop
- · Secondary Shelf
- Vertical Support Columns (2)
- · Base with Casters
- · Assembly Hardware (screws, wrenches, etc.)

If any parts are missing or damaged, please contact customer support.

SETUP AND ASSEMBLY

Follow these steps to assemble your BONTEC Portable Mobile Standing Laptop Desk. It is recommended to have a clear, open space for assembly.

Step 1: Attach Casters to the Base

Secure the four smooth-rolling casters to the base of the desk. Ensure two of the casters are lockable and positioned for easy access.





Image Description: A full view of the assembled BONTEC portable mobile standing laptop desk, highlighting its casters at the base. The main desktop is tilted, holding a laptop, and the secondary shelf holds a cup and pen.

Step 2: Assemble Vertical Support Columns

Connect the vertical support columns to the base. Ensure they are securely fastened using the provided hardware.

Step 3: Attach Secondary Shelf

Mount the secondary shelf to the vertical support columns at your desired height. This shelf provides additional space for accessories.



Image Description: An illustration demonstrating the full dynamic motion of the desk, including the 0-40 degree tilt of the main desktop and the height adjustment mechanism of the entire desk.

Step 4: Install Main Desktop

Attach the main desktop to the top of the vertical support columns. This desktop features a tilt mechanism and an anti-slip stopper.



Image Description: Close-up views of the desk's features: a hand wiping a waterproof surface, non-slip pads on the desktop, and hand screws used for height adjustments.

Step 5: Final Checks

Once assembled, ensure all screws are tight and the desk is stable. Test the height adjustment and tilt mechanisms.

OPERATING INSTRUCTIONS

Height Adjustment

The desk's height can be adjusted from 40.5 to 49 inches (103 to 125 cm). To adjust the height, loosen the hand screws on the vertical support columns, raise or lower the desktop to the desired position, and then firmly tighten the hand screws to secure it.



Image Description: A split image showing a person comfortably using the BONTEC desk while sitting on a stool and then standing, demonstrating the desk's sit-stand functionality.

Desktop Tilt Adjustment

The main desktop can be tilted from 0 to 40 degrees. To adjust the tilt, loosen the knob located on the side of the desktop support, set the desktop to the desired angle, and then tighten the knob to lock it in place. The integrated anti-slip stopper will prevent items from sliding off.

Mobility and Locking Casters

The desk is equipped with four smooth-rolling casters for easy movement. To move the desk, unlock the casters. Once the desk is in the desired position, press down on the locking mechanism on two of the casters to secure the desk in place.



Image Description: A close-up illustration of the desk's casters, showing their 360-degree rotation capability and the locking mechanism for stability.

Using the Secondary Shelf

The secondary shelf provides additional storage for items such as cups, pens, or small documents. Ensure items placed on this shelf do not exceed its weight capacity of 22 lbs (10 kg).

MAINTENANCE

- Cleaning: Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners. The desktop surface is scratch-resistant and waterproof for easy cleaning.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability.
- Casters: Keep casters free of debris to ensure smooth rolling.
- Storage: Store the desk in a dry environment away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is unstable or wobbly.	Loose screws or uneven surface.	Check and tighten all assembly screws. Ensure the desk is on a flat, level surface.
Height adjustment is difficult.	Hand screws are too tight or mechanism is stiff.	Loosen hand screws completely before adjusting. Apply a small amount of silicone lubricant to the vertical columns if necessary.
Casters do not roll smoothly.	Debris in casters or casters are locked.	Check for and remove any debris (hair, dust) from the caster wheels. Ensure the locking mechanism is disengaged.
Desktop does not tilt or stay in position.	Tilt knob is loose or mechanism is obstructed.	Ensure the tilt knob is firmly tightened after adjustment. Check for any obstructions around the tilt mechanism.

SPECIFICATIONS

Model: MWS-001BK
Brand: BONTEC

Product Dimensions: 24.41 x 15.75 x 49.21 inches (62 x 40 x 125 cm)

Item Weight: 32.6 pounds (14.8 kg)

Main Desktop Capacity: 44 lbs (20 kg)

Secondary Shelf Capacity: 22 lbs (10 kg)

Height Adjustment Range: 40.5 to 49 inches (103 to 125 cm)

Desktop Tilt Range: 0 to 40 degrees

Material: Alloy Steel, MDF

Color: Black

Casters: 4 universal mute wheels, 2 lockable



Image Description: A diagram illustrating the key dimensions of the BONTEC desk, including height, width, depth, and the dimensions of both the main desktop and the secondary shelf, along with their respective weight capacities.

WARRANTY INFORMATION

BONTEC products are designed and manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official BONTEC website. Keep your purchase receipt as proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance, or encounter issues with your BONTEC Portable Mobile Standing Laptop Desk, please contact BONTEC customer support:

- Website: Visit the BONTEC Store on Amazon (for general inquiries and product information)
- Refer to your product packaging for direct contact information (email/phone).

Related Documents - MWS-001BK



BONTEC Mobile Workstation Assembly Instructions MWS-001BK

Detailed assembly instructions for the BONTEC MWS-001BK Mobile Workstation, a height-adjustable stand suitable for podium, lectern, and laptop use.



BONTEC FN-411 TV Cart Stand Installation Guide

Detailed installation instructions for the BONTEC FN-411 Mobile TV Cart Stand, including component checklist and step-by-step assembly guidance for 32-85 inch TVs.




BONTEC TC-003WH Mobile TV Cart Instruction Manual

Assembly instructions and parts list for the BONTEC TC-003WH Mobile TV Cart, a height-adjustable stand for flat panel televisions up to 25kg.



BONTEC TC-003B Mobile TV Cart Assembly Instructions & Parts List

Comprehensive assembly instructions and parts list for the BONTEC TC-003B rolling TV stand, suitable for 23-60 inch screens with adjustable height and VESA compatibility.



BONTEC Universal Floor TV Stand Assembly Instructions

Comprehensive guide for assembling the BONTEC Universal Floor TV Stand, suitable for 30-70 inch TVs. Includes component checklist, step-by-step instructions, and safety tips.



BONTEC MTR-S3 Dual Monitor Stand Riser Installation Guide

Official installation guide for the BONTEC MTR-S3 Dual Monitor Stand Riser. Learn how to assemble your ergonomic wooden desktop organizer with smartphone holder.