

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Moen](#) /
- › [Moen Host Series GXB75C Garbage Disposal User Manual](#)

Moen GXB75C

Moen Host Series GXB75C Garbage Disposal User Manual

Model: GXB75C

Brand: Moen

PRODUCT OVERVIEW

The Moen Host Series GXB75C Garbage Disposal is engineered for modern kitchens, offering powerful and quiet food waste management. Its advanced features ensure a clean and efficient kitchen environment.





Image: Front view of the Moen Host Series GXB75C Garbage Disposal, highlighting its sleek black design and 3/4 HP rating.

Key Features:

- **Host Series:** Designed for frequent use, ideal for households that entertain or cook often.
- **Powerful Grinding:** Features a 2,700 RPM, $\frac{3}{4}$ horsepower Vortex motor for efficient grinding and reduced jamming.
- **Controlled, Safer Grinding:** Operates only when the batch feed stopper is engaged, enhancing safety.
- **Noise Reduction:** Equipped with SoundSHIELD sound-deadening insulation for quieter operation.
- **Simple Installation:** Designed for easy replacement, fitting most existing assemblies and includes a pre-installed power cord.
- **Septic Safe:** Compatible with properly sized septic tanks.
- **Eco-Friendly:** Helps reduce landfill waste by efficiently disposing of food scraps.

SETUP AND INSTALLATION

This section provides general guidance for setting up your Moen Host Series GXB75C garbage disposal. For detailed instructions, please refer to the official installation manual.



Image: Diagram showing the included components: 3/4 HP Disposal unit, Batch Feed Stopper, Sink Flange, Drain Elbow and Mounting Assembly, and Pre-Installed Power Cord.

Before You Begin:

- Ensure power to the disposal area is turned off at the circuit breaker.
- Gather necessary tools (e.g., screwdriver, pliers, plumber's putty).
- Verify all included components are present.

Installation Steps (Summary):

1. Remove existing disposal (if applicable) and clean the sink flange area.
2. Install the new sink flange and mounting assembly.
3. Connect the drain elbow to the disposal unit.
4. Attach the disposal unit to the mounting assembly under the sink.
5. Connect the pre-installed power cord to a grounded outlet.
6. Connect the dishwasher drain line (if applicable).
7. Test for leaks and proper operation.

For a comprehensive guide, please download the official [Installation Manual \(PDF\)](#).

OPERATING INSTRUCTIONS

Proper operation ensures the longevity and efficiency of your Moen garbage disposal.



The Host[™] Series

CLEARs FOOD SCRAPS THAT CAUSE ODOR



VORTEX[™] Motor

Grinds scraps into fine particles that easily wash away



Disposal activated with drain stopper

Ensures safer operation—nothing can enter disposal while in use

EASIER INSTALLATION



Simple Swap

Fits most existing assemblies



Pre-installed Power Cord

Saves the hassle—nothing extra to buy (removeable for hardwire applications)

WORRY-FREE OPERATION



Built Smarter, Built Safer

Rugged impeller design uses force and speed to break down food



SoundSHEILD[™]

Sound-deadening insulation

MOEN[®] | GXB75c

Performance you can trust, above and below the sink

Image: Infographic detailing key features like Vortex Motor, SoundSHIELD, and ease of installation.

Daily Use:

1. Turn on a medium stream of cold water.
2. Insert the batch feed stopper into the drain opening and twist to activate the disposal. The disposal will only operate when the stopper is correctly engaged.
3. Slowly feed food waste into the disposal. Avoid overloading.
4. Allow the disposal to run until all food waste is ground and flushed away. You will hear only the sound of the motor and running water.
5. Once grinding is complete, turn off the disposal by twisting the stopper back to its original position or removing it.
6. Let the cold water run for a few seconds to flush the drain line.

What You Can Grind:

- Small fruit pits

- Lemon rinds (helps with odor)
- Banana peels
- Cooked meat scraps
- Most vegetable scraps

What to Avoid:

- Large bones, corn husks, artichokes, and other fibrous materials.
- Grease or fat (pour into a separate container and dispose of in trash).
- Non-food items (e.g., plastic, metal, glass, paper).
- Harsh chemicals or drain cleaners.

MAINTENANCE

Regular maintenance helps keep your disposal running smoothly and extends its lifespan.

Exclusive 360° Clean Rinse eliminates odors



Standard

Lack of waterflow leaves food scraps behind that can lead to unwanted odors



360° Clean Rinse

Additional water clears food scraps that cause odor for a more complete rinse



MOEN® | *The Host*
Series
Performance you can trust, above and below the sink

Image: Illustration of the 360 Clean Rinse feature, showing how additional water flow helps clear food scraps and prevent odors.

Cleaning and Odor Prevention:

- **Regular Flushing:** Always run cold water for 15-20 seconds after grinding to flush out remaining particles.
- **Citrus Cleaning:** Grind citrus peels (lemon, orange, lime) occasionally to freshen the disposal and help clean the grinding chamber.
- **Ice Cubes:** Grind a tray of ice cubes to help dislodge food particles and clean the grinding components.
- **Baking Soda & Vinegar:** Pour 1/2 cup of baking soda into the drain, followed by 1 cup of white vinegar. Let it sit for 10-15 minutes, then flush with hot water.

Preventing Jams:

- Avoid putting large quantities of food waste at once. Feed gradually.
- Always use cold water when operating the disposal.
- Do not pour grease or oil down the drain.

TROUBLESHOOTING

Common issues and their solutions for your Moen Host Series GXB75C garbage disposal.

Disposal Not Starting:

- **Check Power:** Ensure the disposal is plugged in and the circuit breaker has not tripped.
- **Reset Button:** Press the red reset button located on the bottom of the disposal unit.
- **Batch Feed Stopper:** Verify the batch feed stopper is fully engaged and twisted into the "on" position.

Disposal Hums but Doesn't Grind:

- This usually indicates a jam. Turn off the power immediately.
- **Clear Jam:** Use the provided hex wrench (or an Allen wrench) to insert into the center hole on the bottom of the disposal and turn it back and forth to free the impellers.
- **Remove Obstruction:** Once the impellers move freely, use tongs or pliers (NEVER your hand) to remove any foreign objects from the grinding chamber.
- Press the reset button and try again.

Leaking Disposal:


- **Check Connections:** Inspect all plumbing connections (sink flange, drain elbow, dishwasher connection) for looseness or damage. Tighten or replace as needed.
- **Cracks:** If the disposal unit itself is cracked, it will need to be replaced.

Unpleasant Odors:

- Refer to the "Maintenance" section for cleaning and odor prevention tips.

SPECIFICATIONS

Included



Power Cord

7.5"



15.625"

Connection Size - 1.5"

Dishwasher Connection Size - 0.875"

Image: Technical drawing showing the dimensions of the Moen Host Series GXB75C, including height (15.625") and width (7.5").

Attribute	Value
Brand	Moen
Model Number	GXB75C
Horsepower	3/4 HP
Motor Speed	2,700 RPM (Vortex Motor)
Sound Reduction	SoundSHIELD Insulation
Activation Type	Batch Feed with Stopper Control
Power Cord	Pre-installed
Voltage	115 Volts

Attribute	Value
Material	Stainless Steel
Item Weight	11 pounds
Product Dimensions	7.5 x 7.5 x 15.63 inches
Country of Origin	China
Septic System Safe	Yes (with properly sized tanks)

WARRANTY AND SUPPORT

Moen stands behind the quality of its products.

Warranty Information:

The Moen Host Series GXB75C Garbage Disposal comes with a **10-year limited warranty with in-home service**. This warranty covers defects in material and manufacturing under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, troubleshooting, or warranty claims, please contact Moen Customer Service. Refer to the official Moen website or your product packaging for the most current contact information.



MOEN

10x
YEARS IN A ROW

★★★★★
Lifestory Research

AMERICA'S
MOST TRUSTED

Faucet Brand

2016-2025

Moen received the highest numerical score in the proprietary Lifestory Research 2025 America's Most Trusted® Faucet study. Study results are based on the experiences and perceptions of people surveyed. Your experiences may vary. Visit www.lifestoryresearch.com.

Image: Moen's recognition as America's Most Trusted Faucet Brand, reflecting their commitment to quality and customer satisfaction.