Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42420

Schleich Farm World Rabbit Hutch and Bunny Playpen Toy Set - Instruction Manual

1. Introduction

Welcome to the Schleich Farm World! This instruction manual provides guidance for the assembly, use, and care of your Rabbit Hutch and Bunny Playpen Toy Set. Designed for imaginative play, this set allows children to explore farm life with realistic animal figures.

This set is part of the Schleich Farm World collection, encouraging creative storytelling and interaction with farm animals.

2. Safety Information

Warning! Swallowable small parts. Choking hazard. Not suitable for children under 3 years (36 months) due to small parts.

Always supervise young children during play to ensure safe interaction with all components of the toy set.

3. What's in the Box

Your Schleich Farm World Rabbit Hutch and Bunny Playpen Toy Set includes the following components:

- 1 x Rabbit Hutch
- 1 x Rabbit Run (Playpen)
- 1 x Adult Rabbit Figure
- 2 x Baby Rabbit Figures
- 1 x Water Bottle Accessory
- 1 x Food Bowl Accessory
- 1 x Carrot Accessory
- 1 x Wooden Hide Accessory



Image: All 9 pieces included in the set, laid out against a green background. This includes the rabbit hutch, playpen, adult rabbit, two baby rabbits, water bottle, food bowl, carrot, and wooden hide.

4. Setup Instructions

The Schleich Farm World Rabbit Hutch and Bunny Playpen Toy Set is designed for easy setup with no complex assembly required. Follow these steps to prepare your play environment:

1. Unpack all components from the packaging.
2. Place the rabbit hutch on a flat, stable surface. The hutch features opening doors for access.
3. Position the rabbit run (playpen) adjacent to the hutch or as a separate enclosure. The playpen sections can be arranged to form a desired shape.
4. Distribute the accessories: the water bottle can be placed near the hutch or playpen, the food bowl and carrot can be positioned for feeding scenarios, and the wooden hide provides a shelter for the rabbits.
5. Place the adult rabbit and baby rabbit figures within the hutch or playpen to begin play.



Image: The fully assembled rabbit hutch and playpen, with an adult rabbit inside the hutch, two baby rabbits, a wooden hide, food bowl, and carrot arranged in front.



Image: A close-up view of the green playpen with two baby rabbits and a water bottle attached to the fence, demonstrating how the playpen can be used.

5. Operating Instructions (Imaginative Play)

This toy set is designed to foster imaginative play and storytelling. Here are some ways to interact with your Schleich Rabbit Hutch and Bunny Playpen:

- **Rabbit Care:** Use the water bottle, food bowl, and carrot to simulate feeding and providing water for the rabbits.
- **Exploration:** Place the adult rabbit and baby rabbits in different areas of the hutch and playpen. The wooden hide offers a cozy spot for them to rest.
- **Interaction:** Open and close the hutch doors to move the rabbits in and out of their living space.
- **Storytelling:** Create various scenarios and stories involving the rabbits and their farm environment. Integrate other Schleich Farm World figures for expanded play.



Image: A young child sitting on a bed, engaged in imaginative play with the Schleich Rabbit Hutch and Bunny Playpen set, demonstrating typical use.

6. Maintenance and Care

Proper care will ensure the longevity of your Schleich toy set:

- **Cleaning:** Clean all figures and playset components with a soft, damp cloth. Mild soap can be used if necessary, followed by rinsing with clean water.
- **Drying:** Allow all parts to air dry completely before storing to prevent moisture damage.
- **Storage:** Store the toy set in a dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the paint and material of the figures.

7. Troubleshooting

The Schleich Farm World Rabbit Hutch and Bunny Playpen Toy Set is designed for durability and simple operation. Should you encounter any issues:

- **Missing or Damaged Parts:** If any parts are missing or damaged upon opening the package, please refer to the Warranty and Support section for contact information.

- **General Play Issues:** Ensure all components are correctly placed as per the setup instructions. Most play-related issues can be resolved by re-arranging the pieces.

8. Specifications

Feature	Detail
Product Dimensions	3.23 x 9.65 x 7.48 inches
Item Weight	8.8 ounces
Model Number	42420
Manufacturer Recommended Age	36 months - 8 years
Manufacturer	Schleich



Image: The rabbit hutch with a graphic overlay indicating its height is 6 inches, providing a visual reference for its dimensions.

9. Warranty and Support

Schleich products are known for their high quality and durability. While specific warranty details are not provided in this manual, Schleich stands by its products.

For product inquiries, support, or to report any issues, please visit the official Schleich website or contact their customer service department. Please retain your purchase receipt as proof of purchase for any potential warranty claims or support requests.

Official Schleich Website: www.schleich-s.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074VD4WZ9

More documents and user manuals: **https://manuals.plus/**