

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Batavia](#) /
- › [BATAVIA 7062518 18V 4.0 AH 36W Lithium-Ion Battery User Manual](#)

Batavia 7062518

BATAVIA 7062518 18V 4.0 AH 36W Lithium-Ion Battery User Manual

Model: 7062518 | Brand: Batavia

INTRODUCTION

This manual provides essential information for the safe and efficient use of your BATAVIA 7062518 18V 4.0 AH 36W Lithium-Ion Battery. Please read these instructions carefully before first use and keep them for future reference.

The Batavia Maxx Pack Collection offers a flexible 18V lithium-ion battery platform designed for various tools used in home, yard, and garden applications. This battery allows you to power multiple compatible devices with a single battery and charger, enhancing convenience and efficiency.



Image: The Batavia Maxx Pack 18V 4.0 Ah Lithium-Ion Battery, featuring a black body with orange accents and the 'BATAVIA MAXXPACK 18 V 4Ah' branding clearly visible.

SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent injury or damage:

- Do not expose the battery to water or excessive moisture.
- Do not store the battery in direct sunlight or near heat sources.
- Do not short-circuit the battery terminals.
- Only use the battery with compatible Batavia Maxx Pack chargers and tools.
- Do not attempt to open, disassemble, or modify the battery.
- Keep out of reach of children.
- Dispose of used batteries responsibly according to local regulations.

SETUP

Initial Charge

Before first use, fully charge the battery using a compatible Batavia Maxx Pack charger. Refer to your charger's manual for specific charging instructions.



Image: The Batavia 18V 4.0 Ah battery connected to its dedicated charger. The charger has indicator lights, one red and one green, suggesting charging status. The battery is securely seated on the charger base.

Inserting the Battery

Align the battery with the battery slot on your compatible Batavia Maxx Pack tool. Slide the battery firmly into place until it clicks, indicating it is securely locked.



Image: The Batavia 18V 4.0 Ah battery resting on a wooden surface, with a blurred power drill and other tools in the background. This illustrates the battery's compact size and its intended use with various power tools.

OPERATING

Battery Indicator

The battery features an indicator to show the remaining charge. Press the button on the battery to illuminate the indicator lights. The number of lit LEDs indicates the charge level:

- **3 LEDs:** Full charge
- **2 LEDs:** Medium charge
- **1 LED:** Low charge, recharge soon

- **No LEDs:** Battery empty, recharge immediately



Image: A close-up of the Batavia 18V 4.0 Ah battery, showing its side with a red battery indicator light illuminated. This indicates the battery's charge status, likely low or in use.

Removing the Battery

To remove the battery, press the release button(s) on the tool and slide the battery out of the slot.

MAINTENANCE

- Keep the battery terminals clean and free from dirt or debris. Use a dry cloth to wipe them if necessary.
- Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to store the battery with a partial charge (around 50%). Avoid storing it fully charged or completely discharged.
- Do not store the battery connected to a tool or charger for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Battery not charging	Charger not plugged in; Battery not properly seated; Faulty charger or battery.	Check power connection; Re-seat battery; Test with another charger/battery if available.
Tool not operating with battery	Battery discharged; Battery not properly inserted; Tool malfunction.	Charge battery; Re-insert battery; Test battery with another tool or tool with another battery.
Battery gets hot during use/charging	Normal operation (slight warmth); Overload; Faulty battery.	Allow to cool; Reduce load on tool; Discontinue use and contact support if excessive heat.

SPECIFICATIONS

Model: 7062518
Brand: Batavia
Battery Type: Lithium-Ion
Voltage: 18 V
Capacity: 4.0 Ah
Wattage: 36 W
Dimensions (L x W x H): 12 x 8 x 8 cm (approximately)
Weight: 600 g (approximately)
Color: Orange/Black

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Batavia website or contact your local retailer. Keep your purchase receipt as proof of purchase.
For further assistance, visit the [Batavia official website](#).

© 2024 Batavia. All rights reserved.

Related Documents - 7062518



[Batavia Maxxpack 18V Batteries and Chargers - User Manual](#)

Comprehensive user manual for Batavia Maxxpack 18V batteries and chargers, covering operation, safety, technical specifications, and disposal. Includes model numbers BT-CLB001, BT-CLB002, BT-CLB004.



[Batavia MAXXPack 18V Chargers: Operating Instructions and Safety Guide](#)

Comprehensive operating instructions and safety guidelines for Batavia MAXXPack 18V battery chargers (Models BT-CLC003, BT-CLC004, BT-CLC006, BT-CLC007). Learn about safe usage, charging procedures, and technical specifications.



[Batavia MAXXPack 18V Cordless Caulking Gun - Model BT-CCG002 User Manual](#)

Comprehensive operating instructions, safety guidelines, technical specifications, and maintenance information for the Batavia MAXXPack 18V Cordless Caulking Gun (Model BT-CCG002). Learn about its features, intended use, and proper handling.



[Batavia MAXXPack 18V Twinbrush Operating Instructions Manual](#)

Comprehensive operating instructions for the Batavia MAXXPack 18V Twinbrush, covering assembly, usage, maintenance, safety, and technical data for domestic cleaning tasks.



[Batavia NEXSAW 12V Compact Cordless Chain Saw Operating Instructions and Safety Manual](#)

Comprehensive operating instructions and safety guidelines for the Batavia NEXSAW 12V Compact Cordless Chain Saw (Model BT-NXS003, Item No. 7064197). Learn about safe usage, maintenance, technical specifications, and troubleshooting.



[Batavia MAXXPACK 18V Cordless Drain Auger User Manual](#)

Operating instructions and safety guide for the Batavia MAXXPACK 18V Cordless Drain Auger (Model BT-CDA001). Learn how to safely and effectively use this tool for drain cleaning.