

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Baxton Studio](#) /

› [Baxton Studio 2-Drawer Desk \(Model 424-7713-AMZ\) Instruction Manual](#)

## Baxton Studio 424-7713-AMZ

# Baxton Studio 2-Drawer Desk (Model 424-7713-AMZ) Instruction Manual

Model: 424-7713-AMZ | Brand: Baxton Studio

## INTRODUCTION

This manual provides detailed instructions for the assembly, care, and maintenance of your Baxton Studio 2-Drawer Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Baxton Studio 2-Drawer Desk features a contemporary design with a two-tone oak and grey PU veneer finish. It includes two drawers for storage, complemented by angled legs for stability and style. This desk is designed for indoor use only.

## SAFETY INFORMATION

- Always assemble the product on a flat, carpeted surface to prevent damage and scratches.
- Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.
- Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.
- Keep all components and packing materials out of reach of children or animals to avoid risk of choking or suffocation.
- Two people are recommended for assembly.

## PACKAGE CONTENTS

Before starting assembly, ensure all parts and components are present. Do not discard any packing materials until assembly is complete.

### Hardware

**Screw (M7x50MM):** 12 Pieces

**White Leg Pin:** 4 Pieces

**Allen Key:** 1 Piece

*Note: Specific parts are detailed in the assembly video.*

## SETUP AND ASSEMBLY

Approximate assembly time: 60 minutes. Two people recommended for assembly.

### Assembly Video Guide

Your browser does not support the video tag.

Official assembly video for the Baxton Studio 2-Drawer Desk (Model 424-7713-AMZ). This video provides a visual step-by-step guide for assembling the desk, including identifying hardware and attaching components.

### Step-by-Step Assembly Instructions

#### Step 1: Prepare the Desk Body

Remove all drawers from the desk body. Rotate the desk body to access the underside for leg attachment.



Image showing the desk with its two drawers partially open, illustrating the drawer removal step.

#### Step 2: Attach the Legs

Attach the four angled legs to the underside of the desk body. Secure each leg using the provided screws (M7x50MM). Ensure screws are tightened firmly but do not over-tighten.



Image displaying the underside of the desk with all four angled legs securely attached, ready for the next step.

### Step 3: Insert Leg Pins

Insert the white leg pins into the bottom of each leg. These pins provide stability and protect your flooring.





Close-up image of a desk leg with a white leg pin inserted at the bottom, demonstrating proper installation.

#### Step 4: Reinsert Drawers

Once the legs are securely attached and pins are in place, carefully turn the desk upright. Reinsert the two drawers into their respective compartments.



Image showing the desk fully assembled with the drawers reinserted, ready for use.

## OPERATING INSTRUCTIONS

Your Baxton Studio 2-Drawer Desk is designed for general home office use. The two drawers provide convenient storage for stationery, documents, and other small items.

- Ensure the desk is placed on a level surface to prevent wobbling.
- Avoid placing excessively heavy items on the desk surface or inside the drawers to prevent damage.
- The inset drawer handles are designed for smooth operation. Pull gently to open and push to close.

## CARE AND MAINTENANCE

- **Cleaning:** Wipe with a damp cloth using a mild cleaner.
- **Avoid:** Never use harsh chemicals, abrasive cleaners, or furniture polish containing silicone, as these could damage the finish of the item.
- **Protection:** Protect the surface from direct sunlight and extreme temperature changes. Use coasters under beverages to prevent water marks.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary, but do not over-tighten.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk is wobbly.	Uneven floor or loose leg attachments.	Ensure the desk is on a level surface. Check and tighten all leg screws. Adjust leg pins if necessary.
Drawers do not slide smoothly.	Misalignment or obstruction in the drawer glides.	Remove drawers and inspect glides for any obstructions. Ensure drawers are inserted correctly and aligned with the tracks.
Scratches or minor damage to the surface.	Impact or abrasive contact.	For minor scratches, a wood repair kit matching the oak finish may be used. Prevent future damage by using protective mats.

## SPECIFICATIONS

Feature	Detail
<b>Brand:</b>	Baxton Studio
<b>Model Number:</b>	424-7713-AMZ
<b>UPC:</b>	842507131197
<b>Product Dimensions:</b>	17.87"D x 47.4"W x 29.72"H
<b>Item Weight:</b>	59 Pounds
<b>Color:</b>	Light Brown (Oak and Grey two-tone finish)
<b>Material:</b>	Engineered Wood, Wood
<b>Number of Drawers:</b>	2
<b>Assembly Required:</b>	Yes
<b>Recommended Assembly Persons:</b>	2
<b>Room Type:</b>	Office
<b>Care Instructions:</b>	Wipe with Damp Cloth

## WARRANTY AND SUPPORT

### Warranty Information

This product comes with a **30-day limited warranty** from the manufacturer, Wholesale Interiors. Please retain your proof of purchase for any warranty claims.

### Customer Support

For assistance with assembly, missing parts, or any other inquiries, please contact Baxton Studio customer support. Refer to your purchase documentation for specific contact details or visit the [Baxton Studio Store on Amazon](#).

© 2024 Baxton Studio. All rights reserved.