

## Solight WO46

# Solight LED Desk Lamp WO46 User Manual

## 1. INTRODUCTION

Thank you for choosing the Solight LED Desk Lamp WO46. This versatile lamp combines modern design with practical features, including a dimmable LED light, an integrated display showing time, date, alarm, and temperature. This manual provides essential information for the safe and efficient use of your new desk lamp.

## 2. SAFETY INSTRUCTIONS

- Read all instructions carefully before use and retain for future reference.
- Ensure the power supply voltage matches the requirements specified on the product.
- Do not expose the lamp to water or excessive moisture.
- Avoid disassembling or modifying the lamp. Refer all servicing to qualified personnel.
- Keep the lamp away from heat sources and direct sunlight.
- Clean the lamp only with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- This product is designed for indoor use only.

## 3. PACKAGE CONTENTS

Please check the package for the following items:

- Solight LED Desk Lamp WO46
- Power Cable
- User Manual (this document)

## 4. PRODUCT OVERVIEW

The Solight LED Desk Lamp WO46 features a flexible arm, an integrated LED light panel, and a multi-functional display on its base. The base also houses the touch-sensitive controls.





Figure 1: Solight LED Desk Lamp WO46 in folded position, displaying time, date, and temperature on its integrated screen.





Figure 2: Solight LED Desk Lamp WO46 with its arm extended, highlighting the LED light panel and the functional display.



Figure 3: Angled view of the Solight LED Desk Lamp WO46, extended, emphasizing its sleek design and the display panel.



Figure 4: Side profile of the Solight LED Desk Lamp WO46, extended, illustrating the flexibility of its arm and the slim design of the light panel.







Figure 5: Rear view of the Solight LED Desk Lamp WO46, extended, indicating the power input port located at the back of the lamp's base.

## 5. SETUP

---

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the lamp on a stable, flat surface. The non-slip base ensures stability.
3. **Connect Power:** Insert the power cable into the DC input port at the back of the lamp's base, then plug the adapter into a standard electrical outlet.
4. **Adjust Position:** Gently adjust the flexible arm to your desired lighting angle.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Light Control

- **Power On/Off:** Press the touch-sensitive power button on the base to turn the lamp on or off.
- **Brightness Adjustment:** With the lamp on, press and hold the power button to cycle through the three available brightness levels. Release the button at your desired brightness.

### 6.2 Display Functions

The integrated display shows time, date, day of the week, temperature, and alarm status. Specific buttons on the base (e.g., 'Mode', 'Set', 'Up', 'Down' - refer to physical markings on your lamp if available) are used to navigate and set these functions.

- **Setting Time and Date:**
  - a. Press the 'Mode' button until the time display flashes.
  - b. Use the 'Up' and 'Down' buttons to adjust the hour, then press 'Set' to confirm and move to minutes.
  - c. Repeat for minutes, year, month, and day.
  - d. Press 'Mode' to exit setting mode.
- **Setting the Alarm:**
  - a. Press the 'Mode' button repeatedly until the alarm icon appears and the alarm time flashes.
  - b. Use 'Up' and 'Down' to set the alarm hour, then 'Set' to confirm and move to minutes.
  - c. Press 'Mode' to activate/deactivate the alarm. An alarm icon will indicate if it's active.
- **Temperature Display:** The lamp automatically displays the ambient temperature. No user adjustment is typically required for this function.

## 7. MAINTENANCE

---

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. Wipe the lamp's surface with a soft, dry, lint-free cloth. Do not use liquid cleaners or sprays.
- **Storage:** If storing the lamp for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------



Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cable is securely connected to the lamp and the electrical outlet. Ensure the outlet is functional.
Display is blank or incorrect.	Power interruption or incorrect settings.	Ensure continuous power. Reset time and date settings as per Section 6.2.
Light flickers.	Unstable power supply.	Try plugging the lamp into a different electrical outlet.
Alarm does not sound.	Alarm not activated or set incorrectly.	Verify that the alarm is set and activated (alarm icon visible) as per Section 6.2.






## 9. SPECIFICATIONS

Feature	Detail
Model Number	WO46-H
Dimensions (L x W x H)	5.5 x 9 x 50 cm
Weight	599 g (1.32 lbs)
Material	PS (Polystyrene)
Finish Type	Leather look
Light Source Type	LED
Number of Bulbs	3
Luminous Flux	300 lm
Power	1.5 Watts
Voltage	230 Volts
Average Lifespan	30,000 Hours
IP Rating	IP20
Switch Style	Push Button
Energy Label	A+

## 10. WARRANTY AND SUPPORT

Solight products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or spare parts availability, please refer to the documentation provided with your purchase or visit the official Solight website. Please retain your proof of purchase for any warranty claims.

Related Documents - WO46

	<p><a href="#">Solight CA04 Projection Alarm Clock User Manual and Features</a></p> <p>Comprehensive guide to the Solight CA04 Projection Alarm Clock, covering features, setup, clock settings, alarm configuration, FM radio operation, display brightness, and projector usage.</p>
	<p><a href="#">Solight CA04 Projection Alarm Clock User Manual</a></p> <p>User guide for the Solight CA04 Projection Alarm Clock. This manual covers features, description, commissioning, clock settings, alarm setup, FM radio operation, display brightness, and projector usage.</p>
	<p><a href="#">Solight TE45 Weather Station User Manual and Instructions</a></p> <p>Comprehensive user manual for the Solight TE45 weather station. Learn how to set up, operate, and use features like temperature and humidity monitoring, time setting, and unit conversion. Includes technical specifications and compliance information.</p>
	<p><a href="#">Solight WN32 Lamp Instruction Manual - User Guide</a></p> <p>User manual for the Solight WN32 rechargeable LED lamp. Features include Li-Ion battery, multiple light modes, microUSB charging, and IP44 rating. Provides instructions for safe operation and disposal.</p>
	<p><a href="#">SOLIGHT WO8009/WO8010 LED Lighting with Remote Control - User Manual &amp; Specifications</a></p> <p>Comprehensive guide for SOLIGHT WO8009 and WO8010 LED ceiling lights. Includes technical specifications, installation instructions, remote control operation, and safety information.</p>

[Solight TE92WiFi Smart WiFi Weather Station: Operating Instructions and Features](#)

Comprehensive guide to the Solight TE92WIFI smart WiFi weather station. Learn about setup, Wi-Fi connection, app integration, and detailed weather measurements including temperature, humidity, air pressure, wind, precipitation, UV, and air quality.