Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video B074ZVMJYS

Dunkirk (Blu-ray) (BD) User Manual

Model: B074ZVMJYS

1. Introduction

This manual provides comprehensive instructions for the proper use and care of your Dunkirk (Blu-ray) (BD) disc. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.



Image 1: Front cover of the Dunkirk Blu-ray disc. This image displays the primary artwork for the film, featuring a soldier on a beach with a dramatic backdrop, indicating the movie's war theme.

2. Setup

1. **Prepare Your Blu-ray Player:** Ensure your Blu-ray player is connected to your television or display device and powered on. Refer to

your player's instruction manual for specific connection details.

2. **Inspect the Disc:** Carefully remove the Dunkirk Blu-ray disc from its case. Check the disc surface for any visible smudges, dust, or scratches. If necessary, clean the disc as described in the Maintenance section.
3. **Insert the Disc:** Open the disc tray of your Blu-ray player and gently place the disc with the label side facing up. Close the disc tray.
4. **Automatic Playback:** The player should automatically detect the disc and begin loading the main menu or movie. If it does not, select the "Play Disc" or "Disc" option from your player's on-screen menu.

3. Operating Instructions

- **Main Menu Navigation:** Use your remote control's arrow keys to navigate through the main menu options (e.g., Play Movie, Scene Selection, Special Features, Setup). Press the "Enter" or "OK" button to make a selection.
- **Playing the Movie:** Select "Play Movie" to begin playback of the main feature.
- **Language and Subtitle Selection:** Access the "Setup" or "Audio/Subtitle" menu from the main menu or during playback (using your remote's dedicated buttons) to choose your preferred audio track (English, Spanish, etc.) and subtitle options (English, French, Portuguese, Spanish).
- **Accessing Bonus Content:** Select "Special Features" from the main menu to explore additional content such as documentaries, behind-the-scenes footage, and interviews.



Image 2: Back cover of the Dunkirk Blu-ray disc. This image provides details on the film's bonus content, cast, and technical specifications, including audio and subtitle options.

4. Maintenance

- **Cleaning the Disc:** To clean the disc, hold it by the edges and wipe gently from the center outwards using a soft, lint-free cloth. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store the Blu-ray disc in its original case, away from direct sunlight, extreme temperatures, and high humidity. This prevents warping and surface damage.

- **Handling:** Always handle the disc by its edges to avoid fingerprints and scratches on the playing surface.

5. Troubleshooting

Problem	Solution
Disc does not play or load.	Ensure the disc is inserted correctly (label side up). Clean the disc for smudges or dust. Check if your Blu-ray player is functioning correctly with other discs.
Poor picture or sound quality.	Clean the disc. Check all cable connections between your player and TV/audio system. Ensure your player's firmware is up to date.
Cannot access special features or menus.	Ensure you are navigating the disc's menu correctly. Some players may require specific remote buttons to access certain features.

6. Specifications

- **Title:** Dunkirk
- **Format:** Blu-ray, NTSC, Subtitled
- **Model Number (ASIN):** B074ZVMJYS
- **Director:** Christopher Nolan
- **Actors:** Aneurin Barnard, Fionn Whitehead, Harry Styles, Jack Lowden, Tom Glynn-Carney
- **Run Time:** 1 hour and 49 minutes
- **Release Date:** December 19, 2017
- **MPAA Rating:** PG-13 (Parents Strongly Cautioned)
- **Number of Discs:** 3
- **Languages:** English (DTS-HD Master Audio 5.1), English (Dolby Digital 5.1 EX), Spanish (Dolby Digital 5.1)
- **Subtitles:** English, French, Portuguese, Spanish
- **Studio:** Warner Home Video
- **Product Dimensions:** 0.7 x 7.5 x 5.4 inches; 0.01 ounces

7. Warranty Information

For physical media such as Blu-ray discs, specific warranties typically cover manufacturing defects. Please refer to the packaging or contact Warner Home Video directly for details regarding any applicable warranty for this product. General wear and tear or damage due to improper handling are usually not covered.

8. Support

For technical issues related to your Blu-ray player, please consult the instruction manual provided with your player or contact the player's manufacturer for support. For inquiries regarding the content of the Dunkirk Blu-ray disc, you may visit the official Warner Home Video website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074ZVMJYS

More documents and user manuals: **https://manuals.plus/**