

## SPICE SPP007-CK

# SPICE K-Beater Mixer Attachment Instruction Manual

Model: SPP007-CK

## INTRODUCTION

---

This manual provides instructions for the proper use and maintenance of your SPICE K-Beater Mixer Attachment. This accessory is designed to enhance the functionality of compatible stand mixers, offering efficient mixing for various recipes.

The SPICE K-Beater features a durable ceramic non-stick coating, making it ideal for general mixing tasks, such as creaming butter and sugar, mixing batters, and preparing doughs of medium consistency. Its design ensures easy cleaning and long-lasting performance.

### Key Features:

- **Ceramic Non-Stick Coating:** Prevents ingredients from sticking and simplifies cleaning.
- **Dishwasher Safe:** For convenient and hygienic cleaning.
- **Durable Construction:** Built for reliable performance.

### Compatibility:

This K-Beater attachment is compatible with the following stand mixer models:

- **SPICE Emilia SPP007 R/S**
- **G3FERRARI Pastaio G2P018**
- **MELCHIONI Suprema**

## ACCESSORIO UNCINO

## ACCESSORIO K



## MODELLI COMPATIBILI

SPICE - Emilia SPP007 R/S

G3FERRARI - Pastaio G2P018

MELCHIONI - SUPREMA



This image displays the SPICE K-Beater attachment, highlighting its ceramic non-stick coating. Below it, three compatible stand mixer models are shown: SPICE Emilia SPP007 R/S, G3FERRARI Pastaio G2P018, and MELCHIONI Suprema. The K-beater is designed for general mixing tasks.

## SETUP AND INSTALLATION

1. **Safety First:** Ensure your stand mixer is turned off and unplugged from the power outlet before attaching or removing any accessories.
2. **Identify Attachment Hub:** Locate the attachment hub on your stand mixer. Refer to your mixer's instruction manual if you are unsure.
3. **Align and Insert:** Hold the SPICE K-Beater attachment and align its shaft with the attachment hub. Insert the shaft into the hub.
4. **Secure the Attachment:** Rotate the attachment slightly until it locks into place. Some mixers may require a gentle push upwards before rotating. Ensure the attachment is firmly secured and does not wobble.
5. **Verify Clearance:** Before operating, ensure there is adequate clearance between the K-Beater and the mixing bowl. Adjust the bowl height if your mixer model allows.

## OPERATION

The K-Beater is versatile for various mixing tasks. Always refer to your stand mixer's specific instruction manual for recommended speed settings and capacities.

1. **Add Ingredients:** Place your ingredients into the mixing bowl.
2. **Lower Head (if applicable):** If your mixer has a tilt-head design, lower the head and lock it into position.
3. **Select Speed:** Start with a low speed to incorporate ingredients, then gradually increase to the desired speed for mixing. Avoid starting at high speeds, especially with dry ingredients, to prevent splashing.
4. **Monitor Mixing:** Observe the mixing process. Use a spatula to scrape down the sides of the bowl if necessary to ensure all ingredients are thoroughly combined.
5. **Completion:** Once mixing is complete, turn off the mixer and unplug it before removing the attachment or bowl.

**Note:** The K-Beater is generally suitable for medium to heavy mixtures. For very light, airy mixtures (like whipping cream or egg whites) or very heavy doughs (like bread dough), use the appropriate whisk or dough hook attachment, respectively.

## MAINTENANCE AND CLEANING

---

Proper care will extend the life of your SPICE K-Beater attachment.

### Cleaning:

- **Dishwasher Safe:** The ceramic non-stick coating allows for safe and convenient cleaning in a dishwasher. Place it on the top rack for best results.
- **Hand Washing:** If hand washing, use warm, soapy water and a soft sponge or cloth. Rinse thoroughly and dry immediately to prevent water spots.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or metal utensils on the K-Beater, as this can damage the ceramic non-stick coating.

### Storage:

Store the K-Beater in a dry place, away from direct heat or moisture, to maintain its condition.

## TROUBLESHOOTING

---

- **Attachment Does Not Fit:**  
Ensure your stand mixer model is explicitly listed as compatible (SPICE Emilia SPP007 R/S, G3FERRARI Pastaio G2P018, MELCHIONI Suprema). Double-check the attachment method described in the 'Setup and Installation' section and your mixer's manual.
- **Coating Appears Damaged or Peeling:**  
While the ceramic coating is durable, it can be susceptible to damage from harsh impacts or abrasive cleaning. Always use soft utensils and avoid dropping the attachment. If damage occurs, discontinue use to prevent coating particles from mixing with food.
- **Ineffective Mixing:**  
Ensure the K-Beater is properly installed and reaches the bottom and sides of the bowl. If your mixer has a bowl-lift mechanism, adjust the bowl height if necessary. Ensure you are using the correct speed settings for your ingredients.

## SPECIFICATIONS

---

<b>Brand</b>	SPICE
<b>Model</b>	SPP007-CK
<b>Dimensions (L x W x H)</b>	19.4 x 14 x 3.4 cm
<b>Weight</b>	220 grams
<b>Coating</b>	Ceramic Non-Stick
<b>Dishwasher Safe</b>	Yes

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation provided with your original purchase or visit the official SPICE website. Specific warranty terms may vary by region and retailer.

If you encounter issues not covered in this manual, please contact the retailer where you purchased the product or SPICE customer service for assistance.