

## Insten 4-in-1 Joy-Con Charging Dock (B0753FLMVG)

# Insten 4-in-1 Joy-Con Charging Dock for Nintendo Switch and OLED Model

User Manual

## 1. INTRODUCTION

---

This manual provides instructions for the Insten 4-in-1 Joy-Con Charging Dock. This device is designed to charge up to four Nintendo Switch Joy-Con controllers simultaneously, ensuring they are ready for use. It is compatible with both the original Nintendo Switch and the OLED Model.

## 2. SAFETY INFORMATION

---

- Do not expose the charging dock to water or excessive moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or modify the charging dock.
- Use only the provided USB cable or a certified equivalent for power.
- Keep out of reach of children.
- Ensure proper ventilation around the charging dock during use.

## 3. PACKAGE CONTENTS

---

- 1 x Insten 4-in-1 Joy-Con Charging Dock
- 1 x USB Charging Cable

## 4. SETUP

---

1. Place the charging dock on a stable, flat surface.
2. Connect the small end of the included USB charging cable to the Micro USB port on the back of the charging dock.
3. Connect the standard USB end of the cable to a powered USB port (e.g., a Nintendo Switch dock,

computer, or USB wall adapter).

The charging dock is now ready for use.



Figure 1: Connecting the USB cable to the charging dock. The image also shows the dock's dimensions (4.8" height, 3.3" diameter) and the 2.25 ft USB cable length.

Video 1: Demonstrates connecting the USB cable to the charging dock and inserting Joy-Cons for charging. The video also shows the LED indicators changing color.

## 5. OPERATING INSTRUCTIONS

### 5.1 Charging Joy-Cons

1. Ensure the charging dock is powered on and connected to a USB power source.
2. Slide your Joy-Con controllers into the available slots on the charging dock. Ensure they click into place securely. The dock supports up to four Joy-Cons simultaneously.
3. The LED indicators on the top of the dock will illuminate to show the charging status.

## Simultaneous Charging

Easily slide in and quickly charge 4 Joy-Cons at the same time



Figure 2: Four Joy-Con controllers (two red, two blue) inserted into the charging dock, illustrating simultaneous charging capability. The image highlights that Joy-Cons can be easily slid in for quick charging.

### 5.2 LED Charging Indicators

The Insten 4-in-1 Joy-Con Charging Dock features individual LED indicators for each charging slot. These indicators provide visual feedback on the charging status of your Joy-Cons:

- **Blue Light:** Indicates that the Joy-Con controller is currently charging.
- **Green Light:** Indicates that the Joy-Con controller is fully charged.

## LED Charging Indicators

○ Blue: Charging

○ Green: Fully Charged



Figure 3: Close-up of the Insten Joy-Con Charging Dock's top, showing the LED charging indicators. The image clarifies that a blue light signifies charging, and a green light signifies a full charge.



Figure 4: The Insten Joy-Con Charging Dock actively charging four Joy-Con controllers (red and blue) on a wooden surface, positioned next to a Nintendo Switch console on a separate stand. The LED indicators on the dock are illuminated green, indicating fully charged controllers.

## 6. MAINTENANCE

---

- To clean the charging dock, disconnect it from the power source and wipe it with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Store the charging dock in a cool, dry place when not in use.

[ Wide Stable Base ]



Figure 5: The underside of the Insten Joy-Con Charging Dock, highlighting its wide stable base (3.3" diameter) and non-slip grip for secure placement during use and maintenance.

## 7. TROUBLESHOOTING

- **Joy-Cons not charging:** Ensure the USB cable is securely connected to both the charging dock and the power source. Try a different USB port or power adapter. Verify Joy-Cons are correctly inserted into the slots.
- **LED indicators not lighting up:** Check the power connection. If the Joy-Cons are already fully charged, the LEDs will be green or off depending on the specific charge cycle.
- **Slow charging:** Ensure the power source provides sufficient output (e.g., a wall adapter rather than a low-power USB port on a computer).

## 8. SPECIFICATIONS

Feature	Specification
Product Dimensions	4.92 x 3.39 x 3.39 inches
Item Weight	2.56 ounces
Connector Type	USB
Compatible Devices	Nintendo Switch Joy-Cons
Included Components	1 x Joy-Con Charging Dock
Special Feature	Multiple Output Ports, LED Charge Indicator
Input Voltage	240 Volts (AC, via USB adapter)
Output Voltage	5 Volts (DC)
Total USB Ports	1 (for input power)
Number of Items	1

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Insten customer service through their official website or the retailer where the product was purchased. Please have your product model number (B0753FLMVG) and purchase date available.