Baldr B0127T2

BALDR Wireless Indoor/Outdoor Thermometer Model B0127T2 User Manual

Introduction

The BALDR Wireless Indoor/Outdoor Thermometer provides accurate temperature readings for both indoor and outdoor environments. Designed for ease of use and clear readability, this device features a compact display unit and a remote wireless sensor. It allows you to monitor temperature trends and record maximum and minimum temperatures over a 24-hour period.

Product Features

- Indoor and outdoor temperature display.
- Indoor temperature range: 0°C to 50°C (32°F to 122°F).
- Outdoor temperature range: -30°C to 60°C (-22°F to 140°F).
- Switchable temperature units: Celsius (°C) or Fahrenheit (°F).
- Outdoor temperature trend indicator.
- Max/Min record of indoor and outdoor temperature data.
- Low power indicator for both the main unit and external sensor.
- Large, bold numbers for easy readability.

Package Contents

Verify that all items are present upon unpacking:

- 1 x BALDR B0127T2 Digital Indoor/Outdoor Thermometer (Main Unit)
- 1 x Wireless Remote Sensor
- 1 x Instruction Manual

Note: 2 x AAA batteries for the main unit and 2 x AAA batteries for the sensor are **not included** and must be purchased separately.



Image: The BALDR B0127T2 main unit and its wireless sensor, shown alongside the product packaging.

Setup

1. Battery Installation

For the Main Unit:

1. Open the battery compartment cover on the back of the main unit.
2. Insert 2 x AAA batteries, ensuring correct polarity (+ and -).
3. Close the battery compartment cover.

For the Wireless Remote Sensor:

1. Open the battery compartment cover on the back of the sensor.
2. Insert 2 x AAA batteries, ensuring correct polarity (+ and -).
3. Close the battery compartment cover.



Image: Rear view of the main unit showing the battery compartment and the wireless sensor, also with its battery compartment.

2. Sensor Placement

Place the wireless sensor in the desired outdoor location. Ensure it is protected from direct sunlight and precipitation for accurate readings and extended lifespan. The sensor can be mounted on a wall using the integrated hanging keyhole or placed on a flat surface.

3. Initial Synchronization

After installing batteries in both units, the main unit will automatically search for the wireless sensor. The outdoor temperature reading should appear on the main unit's display within a few minutes. If the outdoor temperature does not display, press the 'RESET' button on the back of the main unit and the 'RESET' button on the sensor to re-initiate the connection process.

Operating Instructions

1. Temperature Display

The main unit displays both indoor and outdoor temperatures simultaneously. The upper section shows the outdoor temperature, and the lower section shows the indoor temperature.




Image: Front display of the BALDR thermometer showing outdoor temperature (top) and indoor temperature (bottom), along with dimensions.

2. Celsius/Fahrenheit Selection

To switch between Celsius (°C) and Fahrenheit (°F), press the 'C/F' button located on the back of the main unit.



Image: Rear view of the main unit, highlighting the 'C/F' button for temperature unit selection and the 'RESET' button.

3. Max/Min Temperature Records

The thermometer automatically records the maximum and minimum indoor and outdoor temperatures over a 24-hour period. These records reset automatically every 24 hours. To view the recorded maximum and minimum temperatures, press the 'MAX/MIN' button (if available, otherwise this feature is automatic and continuously updated).

4. Temperature Trend Indicator

An arrow icon next to the outdoor temperature indicates the temperature trend:

- **Up arrow (↑):** Temperature is rising.
- **Down arrow (↓):** Temperature is falling.
- **Horizontal arrow (→):** Temperature is stable.

Maintenance

1. Cleaning

Clean the thermometer's display and casing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the device.

2. Battery Replacement

When the low power indicator appears on the display for either the main unit or the sensor, replace the batteries promptly to ensure continuous and accurate operation. Refer to the 'Battery Installation' section for instructions.

Troubleshooting

- **No outdoor temperature reading:**
  - Ensure batteries are correctly installed in both the main unit and the sensor.
  - Press the 'RESET' button on both units to re-establish connection.
  - Check the distance between the main unit and the sensor; reduce obstacles if possible.
  - Replace batteries in the sensor if the low power indicator is on.
- **Incorrect temperature readings:**
  - Ensure the sensor is not in direct sunlight or exposed to extreme heat sources.
  - Verify that the sensor is protected from rain or moisture.
  - Allow time for the sensor to stabilize after placement.
- **Display is dim or blank:**
  - Replace batteries in the main unit.
  - Check battery polarity.

Specifications

Model:	B0127T2
Indoor Temperature Range:	0°C to 50°C (32°F to 122°F)
Outdoor Temperature Range:	-30°C to 60°C (-22°F to 140°F)
Temperature Accuracy:	±1°C (±1.8°F)
Power Supply (Main Unit):	2 x AAA Batteries (not included)
Power Supply (Sensor):	2 x AAA Batteries (not included)
Item Size (Main Unit):	94mm L x 38mm W x 94mm H (3.70"L x 1.49"W x 3.70"H)
Net Weight:	160g




Image: The BALDR thermometer held in a hand, demonstrating its compact and portable size.

Warranty Information

BALDR provides a **1-year limited warranty** on this product against manufacturing defects in materials and workmanship from the date of purchase. This warranty does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

Support

For further assistance, technical support, or warranty claims, please contact BALDR customer service. Refer to the product packaging or the official BALDR website for current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question