

Powerbank 3615101860322

Power Bank Slim 8000 mAh External Battery User Manual

Model: **3615101860322** | Brand: **Powerbank**

INTRODUCTION

Thank you for choosing the Power Bank Slim 8000 mAh External Battery. This portable power bank is designed to provide reliable and convenient charging for your mobile devices, including smartphones, tablets, and other USB-powered electronics. With its ultra-slim design and 8000 mAh capacity, it is an ideal companion for travel and extended use away from power outlets. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your device.

SETUP

Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your Power Bank. This ensures optimal battery performance and longevity.

1. Connect the provided charging cable to the input port of the Power Bank.
2. Plug the other end of the cable into a USB power adapter (not included) or a computer's USB port.
3. The indicator lights on the Power Bank will illuminate, typically blinking, to show that it is charging. Once all lights are solid, the Power Bank is fully charged.

Connecting Your Device

To charge your electronic device:

1. Use your device's original USB charging cable.

2. Connect one end of the cable to the USB output port on the Power Bank.
3. Connect the other end of the cable to your device's charging port.
4. The Power Bank should automatically begin charging your device. If not, press the power button on the Power Bank (if available) to initiate charging.




Image: The Power Bank Slim 8000 mAh External Battery in its silver finish. This image illustrates the compact design and typical port layout of the device, showing its sleek profile.

OPERATING INSTRUCTIONS

Charging the Power Bank

To recharge the Power Bank, connect it to a power source using its input port. The LED indicators will show the charging status. A full charge typically takes several hours, depending on the power source's output.

Charging Your Devices

Once your device is connected to the Power Bank's USB output port, charging should commence automatically. Monitor your device's screen for the charging icon. The Power Bank's indicator lights will show its remaining battery level, typically decreasing as power is transferred.

Indicator Lights

The Power Bank features LED indicator lights to display its battery status. The number of illuminated lights corresponds to the remaining charge:

- **4 Lights:** 75-100% charge
- **3 Lights:** 50-75% charge
- **2 Lights:** 25-50% charge
- **1 Light:** 0-25% charge (recharge soon)

MAINTENANCE

Cleaning

To clean your Power Bank, use a soft, dry cloth. Avoid using harsh chemicals, abrasive cleaners, or water, as these can damage the device.

Storage

Store the Power Bank in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If storing for an extended period, it is recommended to charge the Power Bank to about 50-75% every three months to maintain battery health.

Battery Care

- Do not expose the Power Bank to fire or water.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or modify the Power Bank.
- Use only certified charging cables and adapters.

TROUBLESHOOTING

Power Bank Not Charging

- Ensure the charging cable is securely connected to both the Power Bank's input port and the power source.
- Try a different USB cable or power adapter.
- Verify that the power source is active.

Device Not Charging from Power Bank

- Check if the Power Bank has sufficient charge (refer to indicator lights).
- Ensure your device's charging cable is properly connected to the Power Bank's output port and your device.
- Try pressing the Power Bank's power button to activate charging.
- Test with a different charging cable or device to rule out cable or device issues.

Slow Charging

- Ensure you are using a high-quality USB cable.
- Some devices may charge slower if they are being used heavily while charging.
- Check the output specifications of the Power Bank and the input requirements of your device.

SPECIFICATIONS

Brand	Powerbank
Model Number	3615101860322
Capacity	8000 mAh
Color	Silver
Special Feature	Slim Design
Product Dimensions (L x W x H)	5 x 5 x 10 cm
Item Weight	300 grams
Power Source	Electric Cable
Compatible Devices	Qilive 10.1, and other USB-chargeable devices
International Article Code (UPC/EAN)	03615101860322
Number of Items	1

WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the documentation provided at the time of purchase or contact the retailer. If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact the manufacturer's customer support.