#### **Delock 83687**

# **Delock USB 2.0 A-B Cable User Manual**

Model: 83687

#### PRODUCT OVERVIEW

This manual provides instructions for the Delock USB 2.0 A-B Cable, model 83687. This cable is designed for connecting devices with a USB Type-A port to devices with a USB Type-B port, facilitating data transfer.




Image: The Delock USB 2.0 A-B Cable, featuring a white cable and gold-plated connectors. The USB Type-A connector is visible on the right, and the USB Type-B connector is on the left.

#### SETUP

The Delock USB 2.0 A-B Cable is designed for simple plug-and-play operation. Follow these steps to connect your devices:

- 1. **Identify Ports:** Locate the USB Type-A port on your host device (e.g., computer, laptop) and the USB Type-B port on your peripheral device (e.g., printer, scanner, external hard drive).
- 2. **Connect USB Type-A:** Insert the USB Type-A connector of the cable into the corresponding USB Type-A port on your host device. Ensure it is fully seated.
- 3. Connect USB Type-B: Insert the USB Type-B connector of the cable into the corresponding USB Type-B port on

your peripheral device. Ensure it is fully seated.

4. Verify Connection: Once both ends are connected, your operating system should automatically detect the peripheral device. If necessary, install any required drivers for your peripheral device as per its manufacturer's instructions.

This cable is compatible with devices such as laptops and personal computers.

#### **OPERATING INSTRUCTIONS**

Once the cable is properly connected, it facilitates data transfer between the connected devices. The cable supports USB 2.0 specifications, allowing for data transfer rates of up to 480 Mbit/s.

- Ensure both connected devices are powered on for proper communication.
- Initiate data transfer operations (e.g., printing, scanning, file transfer) through the software or operating system interface of your host device.
- For optimal performance, avoid disconnecting the cable during active data transfer.

#### MAINTENANCE

To ensure the longevity and optimal performance of your Delock USB 2.0 A-B Cable, follow these maintenance guidelines:

- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable, especially near the connectors, to prevent internal damage.
- Cleaning: If the cable or connectors become dirty, gently wipe them with a soft, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials.
- Handling: Always grasp the connector housing when plugging or unplugging the cable, rather than pulling on the cable itself. This prevents strain on the cable's internal wires and connections.
- **Protection:** Keep the cable away from sharp objects, heavy furniture, or areas where it might be stepped on or pinched, as this can damage the insulation and internal conductors.

#### **TROUBLESHOOTING**

If you encounter issues with your Delock USB 2.0 A-B Cable, consider the following troubleshooting steps:

Problem	Possible Cause / Solution	
Device not recognized	<ul> <li>Ensure both ends of the cable are fully inserted into their respective ports.</li> <li>Try connecting the cable to a different USB port on your host device.</li> <li>Test the cable with another compatible device to rule out cable malfunction.</li> <li>Verify that the peripheral device is powered on and functioning correctly.</li> <li>Install or update drivers for your peripheral device if required.</li> </ul>	
Slow data transfer	<ul> <li>Ensure both devices support USB 2.0 for optimal speed.</li> <li>Disconnect other high-bandwidth USB devices from your host computer.</li> <li>Check for background processes on your computer that might be consuming resources.</li> </ul>	

Problem	Possible Cause / Solution
Intermittent connection	<ul> <li>Check for physical damage to the cable or connectors.</li> <li>Ensure the cable is not excessively bent or strained.</li> <li>Try a different USB port or a different cable to isolate the issue.</li> </ul>

### **SPECIFICATIONS**

Feature	Detail
Brand	Delock
Model Number	83687
Cable Type	USB 2.0 A-B Cable
Cable Length	2 meters (6.56 feet)
Connector 1	USB Type-A Male
Connector 2	USB Type-B Male
USB Version	2.0
Data Transfer Rate (Max)	480 Mbit/s
Contacts	Gold-plated
Color	White
Compatible Devices	Laptop, Personal Computer, and other devices with USB A and B ports
Special Feature	Data Transfer

## WARRANTY AND SUPPORT

For information regarding warranty coverage and technical support for your Delock USB 2.0 A-B Cable, please refer to the official Delock website or contact their customer service directly. Specific warranty terms may vary by region and retailer.

Manufacturer: DeLOCK

Date First Available: August 29, 2017

Documents - Delock - 83687



#### [pdf]

Herunterladen Computing Software PC Kabel Adapter USB USB2 0 Easy A B 2m weiss Stecker beidseitig einsteckbar NewStore GmbH Multimedia Support index dispatch attachments getfile attachment id 6386 shop newstore ch |||

Artikel-Nr. **83687** Delock Kabel EASY-USB 2.0 Typ-A Stecker USB 2.0 Typ-B Stecker 2 m wei Kurzbeschreibung Dieses Kabel von Delock, mit EASY-USB Stecker, kann in beide Richtungen in die USB-A Buchse gesteckt werden. Somit kann der Stecker beidseitig verwendet werden und erleichtert das Einstecken. ...

lang:de score:17 filesize: 218 K page\_count: 2 document date: 2017-08-19