

[Manuals.plus](#) /

› [Anker](#) /

› Anker Soundbuds Slim+ Bluetooth Headphones User Manual - Model AK-A3412011

Anker AK-A3412011

Anker Soundbuds Slim+ Bluetooth Headphones User Manual

Model: AK-A3412011

Brand: Anker

INTRODUCTION

This manual provides comprehensive instructions for the Anker Soundbuds Slim+ Bluetooth Headphones. Designed for comfort and durability, these lightweight stereo earbuds offer extended playtime and IPX7 waterproofing, making them suitable for various activities including workouts and sports. Please read this manual thoroughly to ensure proper use and maintenance of your device.



Image: The Anker Soundbuds Slim+ Bluetooth Headphones, featuring a lightweight design and in-ear earbuds connected by a neckband.

WHAT'S IN THE BOX

Your Anker Soundbuds Slim+ package includes the following items:

- Soundbuds Slim+ Earphones
- Multiple Ear Tips (various sizes)
- Multiple Ear Wings (various sizes)
- Cord Management Clip
- Cord Shirt Clip
- USB 2.0 Charging Cable
- Carrying Case with Metal Carabineer
- User Manual




Image: A flat lay showing the Anker Soundbuds Slim+ headphones, various sizes of ear tips and ear wings, a USB charging cable, and a zippered carrying case with a carabiner.

PRODUCT OVERVIEW

The Anker Soundbuds Slim+ are designed for ease of use and comfort. Key components include:

- **Earbuds:** Ergonomically designed for a secure and comfortable fit.
- **Neckband:** A flexible band connecting the earbuds, designed to rest comfortably around your neck.
- **In-line Remote Control:** Features a 3-button layout for convenient control of music and calls.
- **Microphone:** Integrated into the remote for clear hands-free communication.
- **USB Charging Port:** Located on the remote control for easy charging.



In Control

3-Button Mic to answer calls and change songs.


Image: Close-up of the in-line 3-button remote control on the Anker Soundbuds Slim+ headphones, showing volume up, volume down, and a multi-function button.

SETUP

1. Fitting Your Earbuds

Achieving a secure and comfortable fit is crucial for optimal sound quality and to prevent the earbuds from falling out during activity.

1. Select the ear tips and ear wings that best fit your ears. Experiment with different sizes provided in the package.
2. Gently insert the earbuds into your ear canal.
3. Adjust the ear wings to sit snugly within your ear's concha for added stability.



The Perfect Fit

Customize your accessories.

Image: A close-up of the Anker Soundbuds Slim+ earbuds, highlighting the customizable ear tips and ear wings designed for a perfect fit.

2. Bluetooth Pairing

To pair your Soundbuds Slim+ with your device:

1. Ensure your Soundbuds Slim+ are charged.

2. Press and hold the multi-function button on the in-line remote until the LED indicator flashes blue and red, indicating pairing mode.
3. On your smartphone or audio device, enable Bluetooth and search for available devices.
4. Select "Anker Soundbuds Slim+" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the multi-function button for 3 seconds.
- **To Power Off:** Press and hold the multi-function button for 5 seconds.

Music Control

- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button for 2 seconds.
- **Previous Track:** Press and hold the '-' button for 2 seconds.

Call Handling

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.

CHARGING

To charge your Anker Soundbuds Slim+:

1. Connect the provided USB 2.0 charging cable to the charging port on the in-line remote control.
2. Connect the other end of the USB cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show red during charging and turn blue when fully charged.
4. A full charge takes approximately 1.5 hours and provides up to 10 hours of playtime.

MAINTENANCE

Waterproofing (IPX7)

The Soundbuds Slim+ feature IPX7 waterproofing, offering protection against sweat and rain. This means they can withstand submersion in up to 1 meter of water for 30 minutes.

- After exercising or exposure to water, ensure the USB charging port cover is securely closed.
- If the earbuds become wet, gently wipe them dry with a clean cloth before charging.
- Do not charge the earbuds if the USB port is wet.




Image: A man wearing the Anker Soundbuds Slim+ headphones while water is being splashed on his head, demonstrating their water-resistant capabilities.

Cleaning and Storage

- Regularly clean the ear tips and earbuds with a soft, dry cloth.
- Store the headphones in the provided carrying case when not in use to protect them from dust and damage.

- Avoid extreme temperatures and direct sunlight.

TROUBLESHOOTING

- **Cannot Pair:**
 - Ensure the earbuds are in pairing mode (flashing blue and red LED).
 - Check if Bluetooth is enabled on your device.
 - Move the earbuds closer to your device.
 - Clear previous Bluetooth connections from your device and try pairing again.
- **No Sound/Low Volume:**
 - Increase the volume on both the earbuds and your connected device.
 - Ensure the earbuds are properly connected to your device.
 - Check if the earbuds are charged.
- **Intermittent Connection:**
 - Ensure there are no obstacles between the earbuds and your device.
 - Avoid strong electromagnetic interference.
 - Keep your device within the recommended Bluetooth range (typically 10 meters/33 feet).

SPECIFICATIONS

Model Name	A3412011
Connectivity Technology	Wireless (Bluetooth 5)
Playtime	Up to 10 hours
Charging Time	Approx. 1.5 hours
Water Resistance Level	IPX7
Control Type	Button Control
Item Weight	0.48 ounces
Material	Metal
UPC	848061057447

WARRANTY AND SUPPORT

Anker Soundbuds Slim+ comes with an 18-month warranty and friendly customer service. For support, please refer to the contact information provided in your product packaging or visit the official Anker website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0756T7R5T>

More documents and user manuals: <https://manuals.plus/>