

- Manuals.plus /
- › Skullcandy /
- › Skullcandy Hesh 3 Wireless Over-Ear Headphone User Manual

Skullcandy S6HTW-K033

Skullcandy Hesh 3 Wireless Over-Ear Headphone User Manual

MODEL: S6HTW-K033 | BRAND: SKULLCANDY

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Skullcandy Hesh 3 Wireless Over-Ear Headphones. Designed for all-day listening with up to 22 hours of battery life and rapid charge technology, these headphones offer high-end audio drivers and a foldable design for convenience.

Product Overview

The Skullcandy Hesh 3 Wireless Over-Ear Headphones combine comfort, portability, and powerful sound. Featuring Bluetooth wireless technology, they provide freedom of movement and a long-lasting battery. The noise-isolating fit ensures an immersive audio experience, while integrated controls allow for easy management of music and calls.



Figure 1: Front view of the Skullcandy Hesh 3 Wireless Over-Ear Headphones.

Key features include:

- Bluetooth wireless technology for seamless connectivity.
- Up to 22 hours of total battery life for extended listening sessions.
- Rapid Charge feature: 10 minutes of charging provides 4 hours of playback.
- Noise isolating fit for an immersive audio experience.
- Integrated microphone, call, track, and volume controls on the earcup.
- Collapsible design for easy portability and storage.

What's in the Box

Upon unboxing your Skullcandy Hesh 3 headphones, you should find the following components:

- Skullcandy Hesh 3 Headphones
- USB Charging Cable
- Backup Aux Cable
- User Manual (this document)

Setup

1. Initial Charging

Before first use, it is recommended to fully charge your Hesh 3 headphones. Connect the supplied USB charging cable to the headphone's USB port and the other end to a USB power source (e.g., wall adapter, computer USB port). The LED indicator will show charging status and turn off when fully charged. The Rapid Charge feature allows for quick power-ups.



Figure 2: Side view highlighting the charging port and control buttons.

2. Bluetooth Pairing

1. Ensure your headphones are powered off.
2. Press and hold the main power button on the earcup for 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Hesh 3" from the list of available devices.
5. Once connected, the LED indicator will flash blue periodically.

If you encounter issues, ensure the headphones are not connected to another device and try restarting the pairing

process.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the main power button for 1-2 seconds.
- **Power Off:** Press and hold the main power button for 3-5 seconds.

Music Controls

- **Play/Pause:** Press the main power button once.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Next Track:** Press and hold the "+" button for 2 seconds.
- **Previous Track:** Press and hold the "-" button for 2 seconds.

Call Controls

- **Answer/End Call:** Press the main power button once.
- **Reject Call:** Press and hold the main power button for 2 seconds.



Figure 3: Overview of Hesh 3 features and controls.

Wired Listening

The Hesh 3 headphones can also be used in wired mode. Simply connect the included Backup Aux Cable to the headphone's audio jack and your device's audio output. This is useful when the battery is depleted or for devices without Bluetooth.

Maintenance

Cleaning

To maintain the appearance and hygiene of your headphones, gently wipe the earcups and headband with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure no moisture enters the charging port or audio jack.

Storage

When not in use, store your headphones in a cool, dry place away from direct sunlight and extreme temperatures. The

collapsible design allows for compact storage, protecting them from damage during travel.



Figure 4: Hesh 3 headphones in their folded, packable state.

Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use. Store with some charge if storing for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Headphones won't power on.	Low battery.	Charge the headphones using the supplied USB cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; previously paired to another device; device Bluetooth off.	Ensure headphones are in pairing mode (flashing red/blue). Turn off Bluetooth on other nearby devices. Restart your device's Bluetooth.

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on headphones or device; incorrect audio source selected; loose cable connection (wired mode).	Increase volume on both headphones and device. Ensure correct audio output is selected on your device. Check aux cable connection if using wired mode.
Intermittent audio.	Too far from device; interference.	Move closer to your Bluetooth device. Avoid strong Wi-Fi signals or other Bluetooth devices that may cause interference.

Specifications

Feature	Detail
Model Name	Hesh 3
Connectivity Technology	Wireless (Bluetooth)
Battery Life	Up to 22 Hours
Rapid Charge	10 Minutes = 4 Hours Playback
Noise Control	Sound Isolation
Earpiece Shape	Over-Ear
Material	Memory Foam (earcups), Plastic/Synthetic (carrying case)
Item Weight	8 Ounces
Product Dimensions	1.69 x 7.32 x 7.79 inches
Impedance	32 Ohm
Frequency Range	20 Hz - 20,000 Hz
Control Type	Volume Control, Remote
Water Resistance Level	Not Water Resistant

Warranty and Support

For detailed warranty information and customer support, please refer to the official Skullcandy website or the provided warranty document.

Warranty Document: [Download Warranty \(PDF\)](#)

For further assistance, visit the [Skullcandy Store on Amazon](#) or contact Skullcandy customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B075749KHR>

More documents and user manuals: **<https://manuals.plus/>**