

Mabe LMA71214VBAB0

Mabe LMA71214VBAB0 Automatic Washing Machine User Manual

Model: LMA71214VBAB0

1. INTRODUCTION

Thank you for choosing the Mabe LMA71214VBAB0 Automatic Washing Machine. This appliance is designed to provide efficient and convenient laundry care. Featuring Aqua Saver Green technology for water conservation and an Express Wash option for quick cycles, this washing machine ensures maximum cleaning and garment care with its innovative agitator design. Please read this manual thoroughly before operating your new washing machine to ensure safe and optimal performance.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- Electrical Safety:** Ensure the washing machine is connected to a properly grounded electrical outlet. Do not use extension cords. Disconnect power before servicing.
- Water Safety:** Ensure water hoses are securely connected to prevent leaks. Do not operate the machine if water is leaking.
- Child Safety:** Keep children away from the washing machine during operation. Do not allow children to play on or in the appliance.
- Flammable Materials:** Do not wash items that have been soiled with flammable liquids (e.g., gasoline, cleaning solvents).
- Proper Use:** Use the appliance only for its intended purpose as described in this manual.

3. SETUP AND INSTALLATION

Proper installation is crucial for the performance and longevity of your washing machine.

3.1 Unpacking

Carefully remove all packaging materials, including the base packaging and any internal packing. Inspect the machine for any damage incurred during transit. Keep packaging materials away from children.

3.2 Location Requirements

- Place the washing machine on a firm, level floor.
- Ensure there is adequate space for water inlet and drain hoses, as well as electrical connections.
- Avoid direct sunlight or extreme temperatures.

3.3 Connecting Water Hoses

Connect the hot and cold water inlet hoses to the corresponding valves on the back of the washing machine and to your household water supply. Ensure connections are tight to prevent leaks.

3.4 Connecting Drain Hose

Securely attach the drain hose to the drain outlet on the machine and route it into a standpipe or laundry tub. Ensure the drain hose is not kinked and is positioned to allow proper drainage.

3.5 Electrical Connection

Plug the power cord into a grounded 120 Volt, 60 Hz electrical outlet. Do not use adapters or extension cords.

3.6 Leveling the Machine

Use a level to ensure the washing machine is perfectly level. Adjust the leveling feet at the bottom of the machine as needed. A level machine reduces vibration and noise during operation.



Figure 1: Front-top view of the Mabe LMA71214VBAB0 Automatic Washing Machine.

4. OPERATING INSTRUCTIONS

Follow these steps for effective and efficient use of your washing machine.

4.1 Loading Laundry

Open the lid and load clothes loosely into the wash tub. Do not overload the machine. For best results, mix large and small items.

4.2 Adding Detergent and Softener

Add the recommended amount of detergent to the dispenser. If using fabric softener, add it to the designated softener dispenser.

4.3 Selecting a Wash Cycle

Turn the cycle selector knob to choose the desired wash program. Options may include Normal, Heavy Duty, Delicates, and the **Express Wash** cycle, which completes laundry in approximately 20 minutes.

4.4 Starting a Cycle

Close the lid and press the Start/Pause button to begin the wash cycle. The machine will automatically fill with water and proceed through the selected cycle.

4.5 End of Cycle

Once the cycle is complete, the machine will signal. Remove laundry promptly to prevent wrinkles.

5. MAINTENANCE

Regular maintenance helps ensure your washing machine operates efficiently and extends its lifespan.

5.1 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

5.2 Cleaning the Dispenser

Periodically remove and clean the detergent and softener dispensers to prevent residue buildup.

5.3 Cleaning the Wash Tub

Run a tub clean cycle (if available) or a hot wash cycle with an empty tub and a washing machine cleaner to remove detergent residue and odors.

5.4 Water Inlet Filter Cleaning

Occasionally check and clean the filters located at the water inlet connections on the back of the machine to prevent blockages.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed; Circuit breaker tripped.	Check power connection; Ensure lid is fully closed; Reset circuit breaker.
Machine not filling with water	Water supply turned off; Inlet hoses kinked; Water inlet filters clogged.	Turn on water supply; Straighten hoses; Clean inlet filters.
Machine not draining	Drain hose kinked or clogged; Drain pump issue.	Check and clear drain hose; Contact service if problem persists.
Excessive vibration/noise	Machine not level; Overloaded or unbalanced load.	Level the machine; Redistribute laundry; Reduce load size.
Poor cleaning results	Overloading; Incorrect detergent amount; Wrong cycle selection.	Do not overload; Use correct detergent amount; Select appropriate cycle.

7. SPECIFICATIONS

Detailed technical specifications for the Mabe LMA71214VBAB0 Automatic Washing Machine.

- **Brand:** Mabe
- **Model Number:** LMA71214VBAB0
- **Color:** White
- **Product Dimensions (W x D x H):** 67.8 cm x 68 cm x 111.63 cm
- **Capacity:** 21 Kilograms
- **Voltage:** 120 Volts
- **Material (Tub/Finish):** Stainless Steel / White
- **Noise Level:** 56 Decibels
- **Special Features:** Water saving (Aqua Saver Green), Better cleaning (New Agitator Design), Quick wash (Express Wash)
- **Product Weight:** 50 Kilograms
- **Access Location:** Top Load
- **Cycle Options:** Express Wash, and others.



Figure 2: Mabe LMA71214VBAB0 Automatic Washing Machine with key dimensions.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase. For technical assistance, installation, repair, or maintenance services, please contact Mabe Service:

- **Phone:** 461 471 7000
- **WhatsApp:** 55 41635939

Please have your model number (LMA71214VBAB0) and purchase details ready when contacting support.

© 2026 Mabe. All rights reserved.