

Jaybird 985-000688

Jaybird RUN True Wireless Headphones User Manual

Model: 985-000688 | Brand: Jaybird

INTRODUCTION

The Jaybird RUN True Wireless Sport Headphones are designed to provide a completely wireless audio experience for active users. These earbuds offer a secure and comfortable fit, are sweat-proof and water-resistant, and deliver customizable sound. With up to 12 hours of portable battery life when combined with the included charging case, they are ideal for running and other sports activities.

SETUP AND FIRST USE

Charging Your Headphones

Before first use, fully charge your Jaybird RUN headphones and the charging case. The earbuds provide up to 4 hours of playtime on a full charge, and the charging case provides an additional 8 hours, totaling 12 hours of portable battery life. A quick 5-minute charge can provide 1 hour of playtime. The carrying case itself takes approximately 1.11 hours to fully charge.



Image: Jaybird RUN headphones inside their charging case, illustrating the on-the-go charging capabilities and fast charging feature.

Achieving a Secure and Comfortable Fit

The Jaybird RUN headphones come with interchangeable silicone tips and secure-comfort fins to ensure a snug fit for various ear shapes. Experiment with different sizes of tips and fins to find the combination that provides the best seal and comfort for your ears. A proper fit is crucial for optimal sound quality and to keep the earbuds secure during physical activity.



Image: A person running while wearing Jaybird RUN headphones, demonstrating the secure and comfortable fit during exercise.

Bluetooth Pairing

To pair your Jaybird RUN headphones with your device (iOS or Android), ensure Bluetooth is enabled on your phone. The headphones utilize Bluetooth 4.0 and have a range of up to 10 meters. Follow these general steps:

1. Remove both earbuds from the charging case. They should automatically enter pairing mode (indicated by a flashing LED light).
2. On your device, go to Bluetooth settings.
3. Select "Jaybird RUN" from the list of available devices.
4. Once connected, a voice prompt will confirm successful pairing.

OPERATING YOUR JAYBIRD RUN HEADPHONES

Button Controls

Each earbud features a single control button. These buttons allow you to manage music playback, calls, and activate voice assistants without interrupting your activity. The specific functions of single-click, double-click, and long-press can often be customized via the Jaybird app.

Custom Sound with the Jaybird App

Enhance your listening experience by downloading the Jaybird app. The app allows you to fully customize your sound profile by adjusting the lows, mids, and highs to your preference. It also includes a "Find My Buds" feature, which can help locate your earbuds if they go missing by showing their last connected location.



Image: The Jaybird app interface on a smartphone, demonstrating the custom sound equalization feature.

CARE AND MAINTENANCE

The Jaybird RUN headphones are designed to be sweat-proof and water-resistant, making them suitable for intense workouts and outdoor use. While they can withstand sweat and splashes, they are not intended

for submersion in water.



ON-THE-GO CHARGING

4 H ON THE BUDS + 8 H CHARGING CASE
SO YOU NEVER MISS A BEAT



FAST CHARGING

5 MIN = 1 H PLAY TIME

Image: A user demonstrating the sweat-proof and water-resistant capabilities of the Jaybird RUN headphones.

To maintain optimal performance and hygiene, regularly clean your earbuds. Gently wipe the earbuds and charging contacts with a dry, soft cloth. Ensure the charging case is also kept clean and dry. Store the headphones in their charging case when not in use to protect them and keep them charged.

TROUBLESHOOTING

If you encounter issues with your Jaybird RUN headphones, try the following common troubleshooting steps:

- **No Sound/Intermittent Sound:** Ensure both earbuds are charged. Check the Bluetooth connection on your device; try disconnecting and re-pairing. Sometimes, the left earbud may temporarily lose connection with the right (master) earbud; placing them back in the case and taking them out can

reset this.

- **Pairing Issues:** Make sure the earbuds are in pairing mode (flashing LED). Forget the device from your phone's Bluetooth settings and attempt to pair again. Ensure no other devices are actively connected to the headphones.
- **Battery Drain:** Confirm the earbuds are properly seated in the charging case. Ensure the charging case itself is charged. High volume usage can also lead to faster battery depletion.
- **Controls Not Responding:** Check if the earbuds are connected. If customized controls are set via the app, ensure the app is updated and settings are correctly applied.

For more detailed troubleshooting or persistent issues, refer to the official user manual or contact Jaybird customer support.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Jaybird RUN True Wireless Headphones
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	4.0
Bluetooth Range	10 Meters
Battery Life (Earbuds)	4+ Hours Playtime
Battery Life (with Case)	Up to 12 Hours
Charging Time (Earbuds)	5 minutes for 1 hour playtime
Water Resistance Level	Water Resistant (Sweat-Proof)
Noise Control	Sound Isolation
Frequency Range	20Hz - 20kHz
Impedance	16 Ohm
Item Weight	0.03 Pounds (earbuds)
Product Dimensions	0.56 x 0.75 x 0.77 inches

WHAT'S INCLUDED

The Jaybird RUN True Wireless Headphones package typically includes the following items:

- Jaybird RUN True Wireless Earbuds
- Charging Case (provides +8 hours battery life)
- Silicone Ear Tips (various sizes)
- Oval Ear Tips (various sizes)
- Secure Comfort-Fit Fins (various sizes)
- USB Charging Cable
- Low Profile Carry Pouch

INCLUDED IN THE BOX



LOW PROFILE CARRY POUCH



+ 8 HOUR CHARGING CASE



TRUE WIRELESS EARBUDS



SECURE COMFORT-FIT FINs



SILICONE EAR TIPS

OVAL EAR TIPS



USB CHARGING CABLE

Image: All components included in the Jaybird RUN product package.

WARRANTY AND SUPPORT

Jaybird products are covered by a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official Jaybird website.

For further assistance, technical support, or to download the complete user manual in PDF format, please visit the official Jaybird support page or refer to the provided [User Manual \(PDF\)](#).

© 2023 Jaybird. All rights reserved.



[\[pdf\]](#) Specifications Dimension Guide

RunSellSheet 1 985 000689 specs content abt documents 81271 |||

RUN TRUE WIRELESS SPORT HEADPHONES JET DRIFT POWER YOUR
PASSION Sport is finally wire-free Jaybi ... PRIMARY PACK WEIGHT 0.315KG
MASTER SHIPPER WEIGHT 1.51KG COLOR JET DRIFT MODEL JB RUN JB RUN
P/N **985-000688** 985-000689 UPC 097855133526 097855133533 PRODUCT
DESCRIPTION 100-word description Built...

lang:en **score:23** filesize: 5 M page_count: 2 document date: 2017-08-01