Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UpStart Components ALB-WB25X10019-DL355

UpStart Components Replacement Halogen Light Bulb User Manual

Model: ALB-WB25X10019-DL355

Introduction

Thank you for choosing the UpStart Components Replacement Halogen Light Bulb. This manual provides essential information for the safe and effective installation, operation, and maintenance of your new light bulb. This bulb is designed as a compatible replacement for General Electric PNM1971SR1SS microwave light bulbs, specifically replacing the WB25X10019 model.

Product Overview

The UpStart Components replacement light bulb is a G8 base, 120V, 20W halogen bulb. It features superior-crafted filaments for long-lasting brightness and is manufactured with quality glass and packaging to ensure it arrives in optimal condition. This bulb is specifically designed to match the performance and specifications of the original General Electric WB25X10019 light bulb.



Image 1: UpStart Components G8 Halogen Light Bulb, showing its compact size and two-pin G8 base.

Safety Information

Please read and understand all safety instructions before attempting to install or replace the light bulb. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Disconnect Power:** Always disconnect power to the microwave oven at the circuit breaker or by unplugging the appliance before attempting any service or bulb replacement.
- **Allow Cooling:** If the old bulb was recently in use, allow it to cool completely before handling to prevent burns.
- **Handle with Care:** Halogen bulbs can be sensitive to oils from skin. Handle the new bulb by its base or with a clean cloth to avoid reducing its lifespan.
- **Correct Voltage and Wattage:** Ensure the replacement bulb matches the specified voltage (120V) and wattage (20W) for your appliance. Using an incorrect bulb can cause damage or fire.
- **Disposal:** Dispose of old bulbs according to local regulations.

Installation Instructions

Follow these steps to safely replace the light bulb in your General Electric microwave oven (models compatible with WB25X10019):

1. **Power Disconnection:** Unplug the microwave oven from the electrical outlet or turn off the power at the circuit breaker.

2. **Locate Bulb Cover:** Depending on your microwave model, the bulb may be located behind a cover on the bottom, side, or inside the oven cavity. Refer to your microwave's specific user manual for the exact location and access method.
3. **Remove Cover (if applicable):** If there is a cover, carefully remove it. This may involve unscrewing a screw or prying open a plastic tab.
4. **Remove Old Bulb:** Gently pull the old G8 base bulb straight out from its socket. If the bulb is hot, use gloves or allow it to cool.
5. **Insert New Bulb:** Holding the new UpStart Components bulb by its ceramic base (or with a clean cloth), align the two pins with the holes in the socket. Gently push the bulb straight into the socket until it is firmly seated. Do not force it.
6. **Replace Cover:** Reattach any covers or protective shields that were removed.
7. **Restore Power:** Plug the microwave oven back into the electrical outlet or restore power at the circuit breaker.
8. **Test:** Turn on the microwave light to ensure the new bulb is functioning correctly.


G8

Image 2: A close-up view of the G8 halogen bulb, highlighting its two-pin base for proper alignment during installation.

Operation

Once installed, the light bulb operates in conjunction with your microwave oven's internal lighting system. It will illuminate when the microwave door is opened or when the internal light function is activated, providing clear visibility inside the appliance.

Maintenance

- **Cleaning:** If the bulb or its cover becomes dirty, ensure the microwave is unplugged and the bulb is cool. Wipe gently with a soft, dry cloth. Do not use abrasive cleaners or liquids directly on the bulb.
- **Replacement:** The lifespan of a halogen bulb can vary. Replace the bulb when it burns out or its brightness significantly diminishes. Always use a compatible replacement bulb with the correct specifications (G8 base, 120V, 20W).

Troubleshooting

Problem	Possible Cause	Solution
Bulb does not light up after installation.	No power to the microwave. Bulb not seated correctly in socket. Defective bulb. Microwave light switch issue.	Check if the microwave is plugged in and the circuit breaker is on. Disconnect power, then re-seat the bulb firmly. Try a different, known-good bulb if available. Consult your microwave's service manual or a qualified technician for switch issues.
Bulb burns out quickly.	Frequent handling of the glass with bare hands (oils). Voltage fluctuations. Over-tightening or improper installation.	Always handle new bulbs by the base or with a clean cloth. Ensure your home's electrical system is stable. Install gently, ensuring a snug fit without excessive force.

Specifications

Brand: UpStart Components

Model Number: ALB-WB25X10019-DL355

Bulb Type: Halogen

Base Type: G8

Voltage: 120V

Wattage: 20W

Material: Glass

Special Feature: Long Lasting

Compatibility: Replaces General Electric WB25X10019 light bulb, compatible with GE PNM1971SR1SS microwave.



Image 3: Side view of the G8 halogen bulb, showing the internal filament structure.

Warranty Information

This UpStart Components brand replacement part is not an OEM product and is not covered under any warranties offered by the original manufacturers. Any warranties for this product are offered solely by UpStart Components. For specific warranty details, please refer to the product packaging or contact UpStart Components directly.

Customer Support

If you have any questions regarding the installation, operation, or compatibility of your UpStart Components replacement light bulb, please contact UpStart Components customer support. For further assistance with your microwave oven, please refer to your appliance's original manufacturer manual or contact their support services.
For more information about UpStart Components products, visit their official website or contact their customer service department.

© 2025 UpStart Components. All rights reserved.
All brand names and logos are registered trademarks of their respective owners.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0759WL7ZV

More documents and user manuals: **https://manuals.plus/**