

[Manuals.plus](#) /

› [Surebonder](#) /

› Surebonder Cordless Mini Hot Glue Gun USB-195 Instruction Manual

Surebonder USB-195

Surebonder Cordless Mini Hot Glue Gun USB-195 Instruction Manual

Model: USB-195 | Brand: Surebonder

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Surebonder Cordless Mini Hot Glue Gun, Model USB-195. Please read this manual thoroughly before operating the device and retain it for future reference. This glue gun is designed for various crafting, repair, and DIY projects requiring high-temperature adhesive application.



Image 1.1: The Surebonder Cordless Mini Hot Glue Gun, Model USB-195.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in fire, electric shock, burns, or other injury.

- The glue gun operates at high temperatures. Avoid direct contact with the nozzle and molten glue to prevent burns.
- Do not use the glue gun while it is charging. This can damage the battery and the device.
- Keep the device out of reach of children. Adult supervision is required when children are near the operating area.
- Ensure the work area is well-ventilated.
- Do not immerse the glue gun in water or other liquids.
- Use only mini high-temperature glue sticks (5/16" diameter) with this device.
- Turn off the glue gun and allow it to cool completely before cleaning or storing.
- Do not attempt to disassemble or modify the glue gun. Refer all servicing to qualified personnel.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Surebonder Cordless Mini Hot Glue Gun (USB-195)
- Micro-USB Charging Cable (Note: Quick-Charge 3.0 USB charger not included)
- Instruction Manual



Image 3.1: Front and back view of the Surebonder Cordless Mini Hot Glue Gun packaging.

4. PRODUCT FEATURES

The Surebonder USB-195 Cordless Mini Hot Glue Gun offers several features for convenient and safe operation:

- **Cordless Operation:** Powered by a lithium-ion battery, providing up to 75 minutes of run time for unrestricted use.
- **Micro-USB Charging:** Conveniently recharges via a standard Micro-USB cable. Quick-Charge 3.0 USB chargers are recommended for faster charging.
- **LED Status Indicator:** A multi-colored LED light on the back of the gun indicates its current status:

- No Light: Power Off
 - Blue Light: Power On
 - Red Light: Charging
 - Green Light: Fully Charged
- **Safety Features:** Includes an On/Off switch, insulated nozzle, anti-backflow side fins for safe lay-down, a safety fuse, and a flip-up kickstand.
 - **Compatibility:** Designed for use with high-temperature mini glue sticks (5/16" diameter).

FEATURES



Image 4.1: Diagram illustrating key features of the glue gun, including the insulated nozzle, side fins, power indicator, trigger, ON/OFF switch, USB port, and flip-up stand.

5. SETUP

5.1 Initial Charging

1. Before first use, fully charge the glue gun.
2. Connect the Micro-USB charging cable to the USB port on the back of the glue gun.

3. Plug the other end of the cable into a USB power source (e.g., Quick-Charge 3.0 USB charger, standard USB wall adapter, computer, or mobile charging brick).
4. The LED indicator light will turn **RED** to indicate charging.
5. Once fully charged, the LED indicator light will turn **GREEN**.
6. Disconnect the charging cable once charging is complete. **Do not use the glue gun while it is charging.**



Image 5.1: Illustration of the LED indicator lights for OFF, ON, CHARGING (red), and CHARGED (green) states, along with USB charging options.

5.2 Inserting a Glue Stick

1. Ensure the glue gun is turned off and cool.
2. Insert a mini high-temperature glue stick (5/16" diameter) into the opening at the back of the glue gun.
3. Push the glue stick firmly until it stops. Do not force it.

6. OPERATING INSTRUCTIONS

6.1 Powering On and Heating

1. Press the ON/OFF switch located near the USB port to the "ON" position.
2. The LED indicator light will turn **BLUE**, indicating the glue gun is powered on and beginning to heat.
3. Allow approximately 3-5 minutes for the glue gun to reach its operating temperature. The blue light will remain on during operation.

6.2 Applying Glue

1. Once heated, gently squeeze the trigger to dispense molten glue from the nozzle.
2. Apply glue to the desired surface. Hot glue sets quickly, so work efficiently.
3. To continue applying glue, insert a new glue stick into the back of the gun as the previous one shortens.



Image 6.1: Examples of the glue gun in use for various crafting and repair tasks.

6.3 Using the Flip-Up Kickstand

The integrated flip-up kickstand allows you to safely rest the hot glue gun on a flat surface during use, preventing the hot nozzle from touching your work surface. Ensure the kickstand is deployed when setting the gun down.

6.4 Powering Off

When finished, press the ON/OFF switch to the "OFF" position. The blue LED light will turn off. Allow the glue gun to cool completely before storing.

7. MAINTENANCE

- **Cleaning the Nozzle:** After the glue gun has cooled completely, any excess dried glue on the nozzle can be carefully peeled or scraped off. Do not use abrasive cleaners or sharp objects that could damage the nozzle.
- **Storage:** Store the glue gun in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure it is completely cool before storing.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Recharge the glue gun when the performance starts to diminish.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Glue gun does not heat up.	Not powered on; battery discharged; faulty unit.	Ensure ON/OFF switch is in "ON" position. Charge the battery until the LED turns green. If problem persists, contact customer support.
Glue does not dispense.	Not heated sufficiently; no glue stick inserted; incorrect glue stick size; jammed mechanism.	Allow full heating time (3-5 minutes). Insert a new mini high-temp glue stick. Ensure correct 5/16" diameter glue sticks are used. Do not force the trigger; allow glue to melt.
Glue gun not charging.	Charging cable not connected properly; faulty cable/charger; battery issue.	Ensure Micro-USB cable is securely connected to both the gun and the power source. Try a different USB cable or power adapter. If the red LED does not illuminate, contact customer support.
Short battery run time.	Battery not fully charged; aging battery.	Ensure the glue gun is fully charged until the LED turns green. Battery performance may decrease over time.

9. SPECIFICATIONS

Feature	Detail
Model Number	USB-195
Brand	Surebonder
Power Source	Battery Powered (Lithium-ion)
Voltage	5 Volts
Compatible Glue Sticks	Mini High-Temperature (5/16" diameter)

Feature	Detail
Run Time	Up to 75+ minutes (on full charge)
Charging Port	Micro-USB
Item Weight	0.45 Pounds (approx. 7.2 ounces)
Product Dimensions	8 x 6 x 2 inches
UPC	018239359288
Manufacturer	Surebonder

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Surebonder website. Keep your proof of purchase for any warranty claims.

Manufacturer: Surebonder

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question