

[Manuals.plus](#) /

› [UpStart Components](#) /

› UpStart Components Replacement Light Bulb for Whirlpool ET6WSMXKQ00 / 8009 Instruction Manual

UpStart Components ALB-8009-2PK-DL11965

UpStart Components Replacement Light Bulb for Whirlpool ET6WSMXKQ00 / 8009

Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the UpStart Components replacement light bulb, designed for compatibility with Whirlpool ET6WSMXKQ00 and 8009 models. Please read these instructions carefully before installation and use to ensure safe and proper operation.

Important Note: This is an UpStart Components brand replacement part. It is not an OEM (Original Equipment Manufacturer) product and is not affiliated with any OEM brands. All mentions of brand names or model descriptions are made strictly to illustrate compatibility.

SETUP AND INSTALLATION

Follow these steps to safely install your new replacement light bulb:

1. **Safety First:** Before attempting to replace the light bulb, ensure the appliance's power supply is completely disconnected. This can be done by unplugging the appliance or turning off the corresponding circuit breaker.
2. **Locate the Old Bulb:** Identify the light bulb that needs replacement within your appliance.
3. **Remove the Old Bulb:** Carefully unscrew the old light bulb counter-clockwise until it is free from the socket. If the bulb is broken, use appropriate safety measures (gloves, eye protection) and tools to remove it.
4. **Inspect the Socket:** Check the light bulb socket for any debris, corrosion, or damage. Clean if necessary.
5. **Install the New Bulb:** Gently screw the new UpStart Components replacement light bulb clockwise into the socket until it is snug. Do not overtighten.



Figure 1: Side view of the replacement light bulb, illustrating its clear glass and standard screw-in base.



Figure 2: Bottom view of the replacement light bulb, highlighting the E26 screw base for proper installation.

6. **Restore Power:** Once the new bulb is securely installed, restore power to the appliance.
7. **Test:** Turn on the appliance's light switch to confirm the new bulb is functioning correctly.

OPERATING INSTRUCTIONS

This replacement light bulb operates like any standard incandescent bulb. Once installed, simply use the appliance's designated light switch to turn the light on or off.

- Ensure the appliance is connected to a power source.
- Activate the light switch on your appliance to illuminate the bulb.
- Deactivate the light switch to turn off the bulb.

MAINTENANCE

To ensure optimal performance and longevity of your light bulb:

- **Cleaning:** Periodically, with the power off and the bulb cool, gently wipe the bulb with a dry, soft cloth to remove dust or grime. Do not use liquid cleaners directly on the bulb.
- **Replacement:** Replace the bulb when it burns out. The lifespan of an incandescent bulb varies based on usage.
- **Handling:** Avoid touching the glass portion of the bulb with bare hands during installation or removal, as oils from your skin can reduce bulb life.

TROUBLESHOOTING

If the light bulb does not illuminate after installation, consider the following:

- **No Power:** Ensure the appliance is plugged in and the circuit breaker is on.
- **Loose Connection:** Turn off the power, then carefully re-tighten the bulb in its socket.
- **Faulty Bulb:** Although rare, a new bulb can sometimes be defective. If possible, test the bulb in another working socket or try a different known-good bulb in the original socket to isolate the issue.
- **Appliance Issue:** If other bulbs work in the socket, or if the new bulb works elsewhere, there might be an issue with the appliance's wiring or light fixture. Consult an appliance technician if this is suspected.

SPECIFICATIONS

Feature	Detail
Brand	UpStart Components
Model Number	ALB-8009-2PK-DL11965
Compatibility	Whirlpool ET6WSMXKQ00, Whirlpool 8009
Bulb Type	Incandescent
Wattage	40 Watts
Voltage	120 Volts
Bulb Base	E26
Bulb Shape Size	A15
Dimensions (Product)	1.9 x 3.8 x 3.22 inches (Length x Width x Height)
Material	Glass
Special Feature	Long Lasting filaments

WARRANTY INFORMATION

Any warranties for this UpStart Components product are offered solely by UpStart Components. This product is not covered under any warranties offered by the original manufacturers of the compatible appliances. For specific warranty details or claims, please refer to the purchase documentation or contact UpStart Components directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or encounter issues not covered in this manual, please contact the seller or UpStart Components customer support. Please have your product model number (ALB-8009-2PK-DL11965) and purchase information ready when contacting support.

For the most up-to-date contact information, please refer to the retailer's website where the product was purchased.

© 2023 UpStart Components. All rights reserved. All brand names and logos are registered trademarks of their respective owners.
Model: ALB-8009-2PK-DL11965

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0759ZZRKY>

More documents and user manuals: <https://manuals.plus/>