

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Serta](#) /
- › [Serta Essential Armless Task Chair Instruction Manual](#)

Serta 48740

Serta Essential Armless Task Chair

MODEL: 48740

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Serta Essential Armless Task Chair (Model 48740). Please read all instructions carefully before assembly and use to ensure proper function and safety. Keep this manual for future reference.

Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assembly should ideally be performed by two people for ease and safety.
- Do not stand on the chair.
- Do not use the chair for purposes other than its intended use as an office or task chair.
- Maximum weight recommendation: 275 pounds.

Parts List

Please verify that all components are included in your package:

- Seat Cushion (Faux Leather)
- Backrest (Mesh and Faux Leather)
- Gas Lift Cylinder
- Star Base (Chrome)
- Casters (5 pieces)
- Assembly Hardware (Screws, washers, Allen key)

Assembly Instructions

Follow these steps for quick and easy assembly. Two people are recommended for optimal setup.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the chrome star base. Push firmly until they click into place.



Image: The chrome star base with five casters, highlighting the 360-degree motion capability.

2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base. Ensure it is seated securely.



Image: The sturdy chrome base and gas lift, indicating superior quality and a 275 lb weight capacity.

3. **Attach Seat to Backrest:** Align the seat cushion with the backrest and secure them using the provided hardware. Refer to the included assembly diagram for screw placement.
4. **Place Assembled Top onto Gas Lift:** Carefully place the assembled seat and backrest onto the top of the gas lift cylinder. Press down firmly to secure the connection.

Your Serta Essential Armless Task Chair is now assembled and ready for use.



Image: The Serta Essential Armless Task Chair, fully assembled and ready for use in an office setting.

Operating Instructions

The Serta Essential Armless Task Chair offers simple adjustments for personalized comfort:

- **Height Adjustment:** Locate the accessible lever on the side of the chair, beneath the seat. Lift the lever up to adjust the seat height. While seated, lift the lever to lower the chair. To raise the chair, stand up and lift the lever. Release the lever to lock the height in place.



Image: A visual guide demonstrating the height adjustment lever and its function.

- **360° Swivel and Casters:** The chair features a 360° swivel mechanism and dual-wheel casters, allowing for effortless movement and rotation across various surfaces.



360° Motion

The versatile, dual-wheel casters allow you to easily glide across most carpeted surfaces.

Image: The dual-wheel casters designed for smooth 360-degree movement.

- **Armless Design:** The armless design allows for unrestricted movement and easy fitting under most desks or tables.
- **Breathable Mesh Back:** The mesh back promotes air circulation, keeping you cool and comfortable during extended use.



Image: Detail of the breathable mesh back, designed for air circulation and comfort.

Maintenance

To maintain the appearance and longevity of your Serta Essential Armless Task Chair:

- **Cleaning:** Spot clean the faux leather and mesh surfaces as needed. Use a mild soap and water solution with a soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Caster Care:** Keep casters free of debris (hair, dust, etc.) to ensure smooth rolling.

Troubleshooting

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair not adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged. Check if the gas lift cylinder is properly installed and not damaged.
- **Chair wobbles:** Verify that all assembly screws are securely tightened. Ensure the casters are fully inserted into the base.
- **Casters not rolling smoothly:** Check for any debris (hair, lint) caught in the casters and remove it. Ensure the chair is used on an appropriate surface.

If problems persist, please contact customer support.

Specifications

Feature	Detail
Brand	Serta
Model Name	Essential Armless TaskChair
Model Number	48740
Color	Black
Product Dimensions	25"D x 22"W x 36.5"H
Seat Depth	16.5 inches
Seat Height (Adjustable)	Min: 17 inches, Max: 21 inches
Back Height	17 inches
Material	Faux Leather, Mesh
Base Movement	Swivel
Special Feature	Adjustable Height
Maximum Weight Recommendation	275 Pounds
Item Weight	17.64 pounds
UPC	887909059816



Product Dimensions



Image: Detailed product dimensions including width, depth, back height, and seat height ranges.

Official Product Video

Your browser does not support the video tag.

Video: "Serta - We Make Better Chairs" - An official Serta video showcasing the brand's commitment to quality and comfort in their chairs.

Warranty and Support

For warranty information, additional support, or to contact our dedicated U.S.-based team for assistance with your Serta chair, please visit our support page:

[Serta Customer Support](#)



Customer Support

www.trueinnovations.com/support

Our dedicated U.S. based team is ready to assist you with your Serta® chair and any help needed with its assembly!

Image: Serta Customer Support details, including a QR code and website for assistance.