

GPX HTB017B

GPX HTB017B 18" Bluetooth Soundbar User Manual

Model: HTB017B

INTRODUCTION

Thank you for purchasing the GPX HTB017B 18" Bluetooth Soundbar. This soundbar is designed to enhance your audio experience with its compact size and versatile connectivity options, including Bluetooth for wireless streaming and built-in cables for external audio sources. This manual provides essential information for setting up, operating, and maintaining your soundbar to ensure optimal performance and longevity.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

- Read these instructions thoroughly before operating the unit.
- Keep these instructions for future reference.
- Heed all warnings on the product and in the operating instructions.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

KEY FEATURES

- 18-inch compact design
- Bluetooth wireless technology for streaming audio
- Built-in 3.5mm audio input cable for MP3 players and other devices
- Built-in USB cable for power (connects to computer or USB power adapter, not included)
- Integrated microphone for hands-free calling
- Touch controls for easy operation
- Stereo audio output



Figure 1: Front view of the GPX HTB017B Bluetooth Soundbar.

SETUP GUIDE

What's in the Box

- GPX HTB017B 18" Bluetooth Soundbar
- User Manual

Connecting the Soundbar

1. **Power Connection:** Connect the integrated USB cable from the soundbar to a USB power adapter (not included) or a powered USB port on a computer. The soundbar requires 5V DC power.
2. **Audio Connection (Optional - Wired):** For devices without Bluetooth, connect the built-in 3.5mm audio input cable to the headphone jack or audio output port of your MP3 player, smartphone, tablet, or other audio source.
3. **Placement:** Place the soundbar on a stable, flat surface near your audio source or display. Ensure there is adequate ventilation around the unit.



Figure 2: Rear view of the soundbar, illustrating the integrated cables and control buttons.

OPERATING INSTRUCTIONS

Power On/Off

The soundbar powers on automatically when connected to a power source via its USB cable. To turn off, disconnect the USB power cable.

Volume Control

Adjust the volume using the volume control buttons located on the soundbar (refer to Figure 2 for location) or directly from your connected audio device.

Bluetooth Pairing

1. Ensure the soundbar is powered on.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for Bluetooth devices. The soundbar will appear as "GPX HTB017B" or similar.
4. Select the soundbar from the list to pair. Once paired, you will hear a confirmation tone, and audio will stream wirelessly to the soundbar.
5. If prompted for a password, enter "0000".

Using Auxiliary Input (3.5mm)

When the 3.5mm audio input cable is connected to an audio source, the soundbar will automatically switch to auxiliary mode. Ensure your Bluetooth device is disconnected or Bluetooth is turned off on your device for optimal performance in auxiliary mode.

Using the Built-in Microphone

When connected via Bluetooth to a smartphone, the built-in microphone allows for hands-free calling. Answer or end calls using your smartphone's controls. Audio will be routed through the soundbar.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the soundbar. Do not use liquid cleaners or aerosol sprays.
- **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or pinching the integrated cables excessively to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	Soundbar not powered on. Volume too low. Incorrect audio source selected (for wired connection). Bluetooth not paired or disconnected. Damaged audio cable.	Ensure USB power cable is securely connected to a powered USB port. Increase volume on both the soundbar and the connected device. If using 3.5mm cable, ensure Bluetooth is off on your device. Re-pair Bluetooth device. Check audio cable for damage; try another cable if possible.
Bluetooth device cannot find soundbar	Soundbar not in pairing mode or powered off. Device too far from soundbar. Interference.	Ensure soundbar is powered on. Move Bluetooth device closer to the soundbar (within 10 meters). Move away from other wireless devices that may cause interference.
Sound distortion or static	Volume too high. Weak Bluetooth signal. Poor audio source quality.	Lower the volume on both the soundbar and the connected device. Move Bluetooth device closer. Try a different audio source or file.

SPECIFICATIONS

Model Name	HTB017B
Speaker Type	Soundbar
Speaker Size	18 Inches

Connectivity Technology	Bluetooth, USB, 3.5mm Audio Input
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (33 feet)
Power Source	Corded Electric (USB 5V DC)
Audio Output Mode	Stereo
Product Dimensions	18.8 x 3.9 x 4 inches
Item Weight	1.9 Pounds
Manufacturer	DPI Inc

WARRANTY AND SUPPORT

This GPX HTB017B Soundbar comes with a**Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or contact GPX customer support directly.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please visit the official GPX support website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

© 2025 GPX. All rights reserved. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question