

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [EBL](#) /

> [EBL C Size Battery Adapters Instruction Manual](#)

EBL C Size Spacer 4Pcs

EBL C Size Battery Adapters Instruction Manual

Model: C Size Spacer 4Pcs

1. PRODUCT OVERVIEW

The EBL C Size Battery Adapters are designed to allow the use of standard AA batteries in devices that require C size batteries. This 4-pack provides a practical and economical solution, enabling you to utilize readily available AA cells, including rechargeable ones, for various electronic devices.

- **High Quality:** Constructed from durable ABS plastic for extended product life.
- **Economical:** Reduces the need to purchase C size batteries by converting AA cells.
- **Easy to Use:** Simple insertion of an AA battery transforms it into a C size equivalent.
- **Versatile:** Compatible with a wide range of devices such as cameras, MP3 players, radios, flashlights, toys, and remote controls.




Image 1.1: Visual representation of an AA battery converting to C size using the adapter.

2. SETUP INSTRUCTIONS

To prepare the EBL C Size Battery Adapter for use, follow these steps:

1. Obtain a compatible AA battery (NiMH, Alkaline, or Lithium).


2. Insert the AA battery into the C Size Adapter, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the adapter.
3. Gently push the AA battery until it is fully seated within the adapter. The adapter is designed to hold the AA battery securely.



Portable & Easy to Use

Even children can use it conveniently

Image 2.1: Correct insertion of an AA battery into the adapter.



Fine Detail and Craftsmanship

Accurate design ensures that battery will not sway in spacer

Image 2.2: Internal design of the adapter for secure battery fit.

3. OPERATING INSTRUCTIONS

Once the AA battery is correctly inserted into the C Size Adapter, the adapter functions as a C size battery. Follow these steps to use it in your device:

1. Open the battery compartment of your device that requires C size batteries.
2. Insert the EBL C Size Battery Adapter (with the AA battery inside) into the device's battery compartment, observing the correct polarity (+/-) as indicated by the device.
3. Close the battery compartment securely.
4. Turn on your device. The adapter is suitable for various devices such as cameras, MP3 players, radios, flashlights, toys, and remote control cars.

Important Note: While these adapters allow the use of AA batteries, the overall capacity (mAh) of an AA battery is typically lower than a standard C battery. This may result in shorter operating times for your device compared to using dedicated C batteries.

Portable and Convenient

Just bring these spacers and your AA batteries



Image 3.1: Adapters in use with a battery-powered device.

4. MAINTENANCE

To ensure the longevity and optimal performance of your EBL C Size Battery Adapters:

- Keep the adapters clean and dry. Wipe with a soft, dry cloth if necessary.
- Avoid exposing the adapters to extreme temperatures or direct sunlight.
- Store adapters in a cool, dry place when not in use.
- If the AA battery becomes difficult to remove or insert, check for any debris inside the adapter.

5. TROUBLESHOOTING

If you encounter issues while using the EBL C Size Battery Adapters, consider the following:

Device Not Powering On:

- Ensure the AA battery is fully charged and correctly inserted into the adapter with the correct polarity.
- Verify that the adapter, with the AA battery, is correctly inserted into the device's battery compartment, matching the device's polarity markings.
- Check if the device's battery contacts are clean and free from corrosion.
- Some devices may have contacts that do not properly connect with the smaller diameter of an AA cell within the adapter. If the AA cell pushes through the sleeve or does not make contact, try wrapping a small amount of electrical tape around the AA cell to increase friction and ensure proper seating and contact.

Shorter Operating Time:

- AA batteries generally have a lower milliamp-hour (mAh) capacity than C batteries. This will naturally lead to shorter operating times for your device. This is normal and not a defect of the adapter.
- Consider using high-capacity rechargeable AA batteries for better performance.

Battery Slipping Out of Adapter:

- If the AA battery slips out of position within the adapter, ensure it is pushed firmly into place. A small piece of tape around the AA battery can help secure it if needed.

6. SPECIFICATIONS

Feature	Detail
Model Number	C Size Spacer 4Pcs
Brand	EBL
Material	High-quality ABS Plastic
Compatibility	AA batteries (NiMH, Alkaline, Lithium) for C size devices
Package Contents	4 C-size battery adapters (batteries not included)
UPC	709445073005
ASIN	B075CFZ1D8

7. WARRANTY AND SUPPORT

EBL provides a 12-month worry-free service for this product. For any questions, concerns, or support needs, please contact EBL customer service through their official channels or the retailer where the product was purchased.

For more information and to explore other EBL products, visit the official EBL store [EBL Official Store](#)

