



Manuals.plus /

› Samsonite /

› Samsonite Luggage Strap with Combination Lock (Model 91152-1041) Instruction Manual

## Samsonite 91152-1041

# Samsonite Luggage Strap with Combination Lock (Model 91152-1041) Instruction Manual

Your guide to securing your luggage with confidence.

## 1. OVERVIEW

### Product Description

The Samsonite Luggage Strap with Combination Lock is designed to provide an extra layer of security and easy identification for your baggage. Featuring a rugged ABS buckle and a triple-dial mechanism, it offers hundreds of possible combinations for enhanced protection. The ultra-rugged polypropylene strap is adjustable to fit bags up to 72 inches, and its distinct design helps in quickly identifying your luggage on the carousel. This strap is accepted and recognized by the TSA.

### Key Features

- Rugged ABS buckle built to withstand baggage handling.
- Triple-dial mechanism for setting and re-setting combinations.
- Hundreds of possible combinations for added security.
- Ultra-rugged polypropylene strap, adjustable up to 72 inches.
- Distinct design and color for easy luggage identification.
- TSA accepted and recognized.

## 2. SETUP INSTRUCTIONS

### Setting Your Combination Lock

Your Samsonite Luggage Strap comes with a resettable 3-dial combination lock. The factory preset combination is 0-0-0. Follow these steps to set your personal combination:



*An image showing the Samsonite Luggage Strap, highlighting the three-dial combination lock and the Samsonite branded buckle. The strap is black with a subtle pattern.*

1. Ensure the lock is set to the factory default combination (0-0-0) or your previously set combination.
2. Locate the small reset button or lever on the side or bottom of the lock mechanism.
3. Using a pen or a pointed object, press and hold the reset button, or slide the lever to the reset position.
4. While holding the reset button/lever, rotate the three dials to your desired personal 3-digit combination. Choose a memorable number.
5. Release the reset button/lever. Your new combination is now set.
6. Scramble the dials to lock the strap. Test your new combination to ensure it opens correctly before securing your luggage.

### **3. OPERATING INSTRUCTIONS**

#### **Attaching and Adjusting the Luggage Strap**

This video demonstrates the process of attaching and adjusting the Samsonite Luggage Strap to a suitcase, ensuring a secure fit. It highlights the ease of use and the added security layer for your baggage.

Your browser does not support the video tag.

*Video: Samsonite Luggage Strap | A Perfect Backup For Stuffed Bags? - Demonstrates attaching and adjusting the strap.*

1. Place your luggage on a flat, stable surface.
2. Unbuckle the strap and extend it to its full length.
3. Wrap the strap around your luggage, either horizontally or vertically, depending on your preference and luggage size. For maximum security, consider wrapping it both ways if using two straps.
4. Thread the loose end of the strap through the buckle mechanism.
5. Pull the strap firmly to remove any slack, ensuring a snug fit around your luggage. The strap should be tight enough to prevent movement but not so tight that it damages your bag.
6. Once adjusted, secure the buckle.

## Securing and Opening the Lock

- **To Lock:** After attaching the strap and setting your combination, scramble the dials to a random set of numbers. The strap is now locked.
- **To Open:** Align the dials to your personal 3-digit combination. The buckle will then release, allowing you to remove the strap.

## 4. MAINTENANCE

---

Proper care will extend the life of your luggage strap.

- **Cleaning:** Wipe the strap and buckle with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the strap in a dry place away from direct sunlight when not in use.
- **Inspection:** Periodically check the strap and buckle for any signs of wear or damage. Replace if significant wear is observed.

## 5. TROUBLESHOOTING

---

- **Cannot set new combination:** Ensure the lock is set to the current combination (0-0-0 initially or your last set code) before attempting to press the reset button/lever. Make sure the reset button/lever is fully engaged while setting the new code.
- **Forgot combination:** Unfortunately, if you forget your combination and did not record it, there is no master key or universal reset. You may need to try all 1000 possible combinations (000-999) or contact Samsonite customer support for further assistance.
- **Strap is too loose or too tight:** Adjust the length of the polypropylene strap through the buckle mechanism until it fits snugly around your luggage. The strap is designed to be highly adjustable.
- **Buckle not closing/opening:** Check for any debris or obstruction in the buckle mechanism. Ensure the combination dials are correctly aligned when attempting to open.

## 6. SPECIFICATIONS

---

Feature	Detail
Model Number	91152-1041
Material	Polypropylene strap, ABS buckle, Stainless Steel hardware
Color	Black
Adjustable Length	Up to 72 inches
Lock Type	Triple-dial combination lock (TSA accepted)
Item Weight	6.4 ounces
Manufacturer	Samsonite Corporation

## 7. WARRANTY AND SUPPORT

---

Samsonite products are rigorously tested to ensure they meet stringent standards. This luggage strap is backed by Samsonite's commitment to quality. For specific warranty details, including coverage and duration, please refer to the warranty information provided with your purchase or visit the official Samsonite website.

For product support, troubleshooting assistance, or to inquire about warranty claims, please contact Samsonite customer service through their official website or the contact information provided in your product packaging.

**Online Support:** Visit the official Samsonite website for FAQs and support resources.

**Contact Information:** Refer to your product's packaging or the Samsonite website for the most current customer service contact details.