

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SereneLife](#) /

› [SereneLife Portable Outdoor Sink with Faucet, Water Tank, Soap Dispenser, and Towel Holder, 19 Liters \(Model SLCASN18\) Instruction Manual](#)

SereneLife SLCASN18

SereneLife Portable Outdoor Sink (Model SLCASN18) Instruction Manual

Your guide to setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the SereneLife Portable Outdoor Sink. This manual provides essential information for the safe and efficient use of your new portable sink. Designed for outdoor convenience, this unit offers a hands-free water source for personal hygiene and cleaning tasks in various settings.

Please read this manual thoroughly before assembly and operation, and retain it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Ensure the unit is placed on a stable, level surface to prevent tipping.
- Do not use the sink with water temperatures exceeding 50°C (122°F).
- Regularly inspect all components for damage before each use. Do not use if any part is broken or compromised.
- Keep out of reach of small children when not in use or unsupervised.
- Dispose of wastewater responsibly according to local regulations.
- The unit is made of food-safe HDPE plastic. However, avoid storing potable water for extended periods without proper sanitation.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged:

- Portable Sink Basin
- Support Column
- Base Water Tank (19 Liters / 5 Gallons)
- Faucet

- Liquid Soap Dispenser
- Stainless Steel Towel Holder
- Flexible Drain Hose
- Foot Pump Mechanism
- (Optional: Storage Bag, Ground Stakes - check your specific model for inclusion)



Image 3.1: Exploded view showing the faucet, dispenser, basin, drain hose, base tank, and support column.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your portable sink:

- 1. Prepare the Base:** Place the base water tank on a flat, stable surface. Ensure the foot pump mechanism is securely attached to the tank.
- 2. Attach the Support Column:** Insert the support column firmly into the designated opening on the base water tank. Twist gently until it locks into place.
- 3. Mount the Sink Basin:** Carefully place the sink basin onto the top of the support column. Ensure it is seated correctly and stable.
- 4. Install the Faucet:** Insert the faucet into the opening on the sink basin. Tighten any securing nuts from

underneath the basin if applicable.

5. **Connect the Water Line:** Connect the water line from the foot pump to the underside of the faucet. Ensure a tight connection to prevent leaks.
6. **Install Soap Dispenser and Towel Holder:** Insert the liquid soap dispenser into its designated hole on the basin. Attach the stainless steel towel holder to the side of the basin.
7. **Attach the Drain Hose:** Connect the flexible drain hose to the drain opening on the underside of the sink basin. Direct the other end of the hose into a suitable wastewater collection container or drainage area.
8. **Fill the Water Tank:** Open the cap on the base water tank and fill it with clean water. The tank has a capacity of 19 liters (approximately 5 gallons). Close the cap securely.

SOLUZIONE IGIENICA TUTTO-IN-UNO



Image 4.1: A person demonstrating the assembly of the portable sink, showing the basin being attached to the base.

5. OPERATING INSTRUCTIONS

The SereneLife Portable Outdoor Sink is designed for simple, hands-free operation.

1. **Prime the Pump:** Before first use, or if the unit has been dry, press the foot pump several times until water begins to flow from the faucet.

2. **Dispense Water:** Place your hands or items under the faucet. Press the foot pump repeatedly with your foot to dispense water. Each press delivers a stream of water.
3. **Use Soap:** Press the top of the liquid soap dispenser to release soap into your hands or onto items being washed.
4. **Drainage:** Ensure the flexible drain hose is directed into a suitable container or drainage area to collect wastewater.

SUPPORTA OLTRE 100 LAVAGGI DELLE MANI OVUNQUE E IN QUALSIASI MOMENTO



Image 5.1: A woman demonstrating washing hands with the portable sink in an outdoor setting.

OPERAZIONE SENZA MANI



Image 5.2: Close-up of a foot pressing the pump for hands-free water operation.

6. MAINTENANCE

6.1. Cleaning

- After each use, especially if used for food preparation, rinse the sink basin and drain hose thoroughly with clean water.
- Clean the exterior surfaces with a mild soap and water solution. Avoid abrasive cleaners or harsh chemicals that could damage the plastic.
- Periodically clean the inside of the water tank. For thorough cleaning, you can add a small amount of bleach solution (1 teaspoon per gallon of water) to the tank, pump it through the system, let it sit for 15 minutes, then rinse thoroughly with fresh water until no bleach smell remains.
- Empty the soap dispenser and clean it regularly to prevent clogs.

6.2. Storage

- Before storing, ensure the water tank is completely empty and dry to prevent mold or mildew growth.
- Disconnect the components and store them in a cool, dry place, away from direct sunlight.

- If your model includes a storage bag, use it to protect the components during transport and storage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flows from faucet.	Water tank is empty. Water line is kinked or disconnected. Pump is not primed.	Refill water tank. Check and straighten water line connections. Press foot pump several times to prime.
Water leaks from connections.	Connections are loose. O-rings or seals are damaged.	Tighten all connections. Inspect and replace damaged O-rings or seals.
Sink is unstable.	Not on a level surface. Components not fully locked.	Move to a flat, stable surface. Ensure support column and basin are securely attached.
Soap dispenser is clogged.	Dried soap residue.	Remove dispenser and clean with warm water.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	SLCASN18
Brand	SereneLife
Water Tank Capacity	19 Liters (approx. 5 Gallons)
Material	High-Density Polyethylene (HDPE)
Color	White
Product Dimensions (L x W x H)	33.02 x 50.04 x 101.85 cm (13 x 19.7 x 40.1 inches)
Item Weight	3.49 kg (7.7 lbs)
Operation	Hands-free foot pump
Included Accessories	Integrated liquid soap dispenser, stainless steel towel holder, flexible drain hose



Image 8.1: Visual representation of the portable sink's dimensions and capacity.

9. WARRANTY AND SUPPORT

9.1. Warranty Information

SereneLife products are manufactured with quality and durability in mind. This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. Please refer to the product packaging or the official SereneLife website for specific warranty terms and conditions, as these may vary.

9.2. Customer Support

For technical assistance, troubleshooting, or to inquire about replacement parts, please contact SereneLife customer support. Contact information can typically be found on the SereneLife official website or on the product packaging. When contacting support, please have your model number (SLCASN18) and purchase date available.

