

VR SHINECON SC-G04

VR SHINECON SC-G04 Smartphone Virtual Reality Device User Manual

Your guide to an immersive virtual reality experience.

INTRODUCTION

Thank you for choosing the VR SHINECON SC-G04 Smartphone Virtual Reality Device. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new VR headset. Please read it carefully before use to ensure optimal performance and safety.

The SC-G04 is designed to transform your smartphone into an immersive virtual reality viewer, compatible with both Android and iOS devices. It features integrated headphones for a complete audio-visual experience and adjustable lenses for personalized viewing comfort.

PACKAGE CONTENTS

- VR SHINECON SC-G04 VR Headset
- User Manual
- Cleaning Cloth

SETUP

Follow these steps for initial setup of your VR SHINECON SC-G04 headset:

1. **Prepare Your Smartphone:** Ensure your smartphone is charged and has VR-compatible applications installed. For the best experience, disable screen rotation lock and adjust screen brightness to a comfortable level.
2. **Open the Front Cover:** Gently press the release button on the side or top of the headset to open the front cover where the smartphone is inserted.
- 3.



Image: The VR SHINECON SC-G04 headset with its front cover open, revealing the internal tray designed to securely hold a smartphone. This view demonstrates how the phone is placed inside the device.

Insert Your Smartphone: Carefully place your smartphone into the adjustable tray inside the front compartment. Ensure the phone is centered and securely held by the clamps. Connect the audio jack of the headset to your smartphone's headphone port for integrated sound.

4. **Close the Front Cover:** Close the front cover firmly until it clicks into place.
5. **Adjust Head Straps:** Put on the headset. Adjust the elastic head straps to ensure a snug yet comfortable fit. The straps should distribute the weight evenly across your head.
- 6.



Image: A side view of the VR SHINECON SC-G04 VR headset, highlighting its sleek black design and the adjustable head strap that ensures a secure and comfortable fit for various head sizes.

Adjust Focus and Pupil Distance: Use the adjustment knobs on the top of the headset to fine-tune the focus for each eye and the interpupillary distance (IPD) to match your eyes. Rotate the knobs until the image appears clear and comfortable.

OPERATING INSTRUCTIONS

Once your smartphone is securely in place and the headset is adjusted, you are ready to begin your VR experience:

- **Launch VR Content:** Open your preferred VR application or content on your smartphone before inserting it into the headset.
- **Immersive Viewing:** The headset provides a 110-degree field of view, offering an expansive and immersive experience.
- **Audio Experience:** The integrated headphones deliver high-quality audio directly to your ears, enhancing the realism of your VR content. Adjust volume using your smartphone's controls.
- **Comfortable Wear:** The lightweight design (380g) and adjustable straps ensure comfort during extended use. Take breaks as needed to prevent eye strain or discomfort.



Image: A composite image displaying various angles and features of the VR SHINECON SC-G04 headset, including its adjustable lenses, integrated headphones, and overall ergonomic design.

MAINTENANCE

Proper maintenance will prolong the life of your VR SHINECON SC-G04 headset:

- **Cleaning Lenses:** Use the provided cleaning cloth or a soft, dry microfiber cloth to gently wipe the lenses. Do not use liquid cleaners or abrasive materials, as they can damage the lens coating.
- **Cleaning Body:** Wipe the exterior of the headset with a slightly damp, soft cloth. Avoid getting moisture into any openings.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Keep it free from dust and scratches.

TROUBLESHOOTING

If you encounter issues with your VR SHINECON SC-G04, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Image is blurry or out of focus.	Incorrect focus or IPD adjustment.	Adjust the focus and interpupillary distance (IPD) knobs on the top of the headset until the image is clear.
Smartphone does not fit or is not secure.	Incorrect phone placement or phone size incompatibility.	Ensure your smartphone is within the compatible size range and is properly centered and clamped in the tray.
No sound from integrated headphones.	Audio cable not connected or phone volume too low.	Verify the audio jack is fully inserted into your smartphone's headphone port. Check your smartphone's volume settings.
Discomfort during use.	Head straps too tight or loose, or prolonged use.	Adjust the head straps for a comfortable fit. Take regular breaks during extended VR sessions.

SPECIFICATIONS

Key specifications for the VR SHINECON SC-G04 VR Device:

Feature	Detail
Brand	VR SHINECON
Model	SC-G04
Compatible Devices	Smartphones (Android, iOS)
Field of View (FOV)	110 Degrees
Integrated Headphones	Yes
Adjustable Lenses	Yes (Focus and IPD)
Product Weight	380 Grams
Color	Black
Connection Method	Wireless (for VR content streaming from phone)

WARRANTY AND SUPPORT

Specific warranty details for the VR SHINECON SC-G04 are not provided in this manual. For information regarding warranty coverage, technical support, or service, please refer to the official VR SHINECON website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For the latest software updates and compatible VR applications, please visit your smartphone's app store or the VR SHINECON official resources.

