

**RCA RT1970**

# RCA RT1970 19-Inch 720p 60Hz LED TV User Manual

Model: RT1970

## 1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before operating the TV. Keep these instructions for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons.

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## 2. PRODUCT OVERVIEW

The RCA RT1970 is a 19-inch 720p LED TV designed for clear high-definition viewing. It features a true 16:9 aspect ratio and a built-in digital tuner. Multiple HDMI ports allow for connection of various multimedia devices.



Figure 2.1: Front view of the RCA RT1970 19-Inch 720p LED TV. This image shows the television screen with a scenic landscape displayed, and the RCA logo centered on the bottom bezel. The TV is supported by two black stand feet.

## What's in the Box

- RCA RT1970 19-Inch 720p 60Hz LED TV
- Remote Control
- Power Cord
- Stand Feet and Screws
- User Manual (this document)

## 3. SETUP

### 3.1 Attaching the Stand

Carefully place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand feet with the mounting holes on the bottom of the TV. Secure the feet using the provided screws.

### 3.2 Connecting Power

Plug the power cord into the AC IN port on the back of the TV, then plug the other end into a standard electrical outlet (AC 120V, 60Hz).

### 3.3 Connecting External Devices

The TV features HDMI ports for connecting high-definition devices such as Blu-ray players, game consoles, or cable/satellite boxes. Use an HDMI cable to connect your device to any available HDMI port on the TV.

- **HDMI:** For digital audio/video connection.
- **Antenna/Cable In:** For connecting an antenna or cable TV signal.
- **USB:** For media playback from USB storage devices.
- **Audio Out:** For connecting external audio systems or headphones.

## 4. OPERATING THE TV

### 4.1 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. This includes selecting your preferred language (English, Spanish, French), scanning for channels (if using an antenna), and setting the time zone.

### 4.2 Basic Functions

- **Power On/Off:** Press the Power button on the remote or on the TV.
- **Volume Control:** Use the VOL +/- buttons on the remote.
- **Channel Change:** Use the CH +/- buttons on the remote.
- **Input Selection:** Press the INPUT or SOURCE button on the remote to cycle through available input sources (HDMI 1, HDMI 2, TV, USB, etc.).
- **Menu Navigation:** Use the directional arrows and OK/ENTER button on the remote to navigate the on-screen menu.

### 4.3 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various settings of the TV, including Picture, Sound, Channel, Time, Setup, and Lock options.

- **Picture Settings:** Adjust brightness, contrast, color, tint, sharpness, and picture mode (Standard, Dynamic, Movie, User).
- **Sound Settings:** Adjust bass, treble, balance, sound mode (Standard, Music, Movie, User), and enable/disable surround sound.
- **Channel Settings:** Perform auto scan, manual scan, and edit channel lists.

## 5. MAINTENANCE

### 5.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of water or a specialized screen cleaner. Do not spray liquid directly onto the screen.

### 5.2 Cleaning the Cabinet

Wipe the TV cabinet with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.

## 5.3 Energy Efficiency

The RCA RT1970 is designed with energy efficiency in mind. For detailed energy consumption information, refer to the Energy Guide label.



Figure 5.1: Energy Guide label for the RCA RT1970 television. This label indicates an estimated yearly energy cost of \$4, based on 12 cents per kWh and 5 hours per day usage. The estimated yearly electricity use is 33 kWh.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Power cord not securely connected; Power outlet not working.	Check power cord connection; Test outlet with another device.
No Picture, But Sound is Present	Incorrect input source selected; External device not powered on or connected properly.	Press INPUT/SOURCE button to select correct input; Check connections and power of external devices.
No Sound, But Picture is Present	Volume is muted or too low; Audio cables not connected properly.	Unmute volume or increase level; Check audio cable connections.
Remote Control Not Working	Batteries are dead or inserted incorrectly; Obstruction between remote and TV sensor.	Replace batteries; Ensure clear line of sight to TV's IR sensor.
Poor Picture Quality	Antenna signal weak; Picture settings incorrect.	Adjust antenna position or check signal strength; Reset picture settings to default or adjust manually.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	RT1970
Screen Size (Diagonal)	19 inches (49 cm)
Display Technology	LED
Resolution	720p (HD)
Refresh Rate	60Hz
Aspect Ratio	16:9 (1.77:1)
Viewable Angle (H/V)	170 degrees / 160 degrees
OSD Language	English, Spanish, French
Connectivity	HDMI, Antenna/Cable In, USB, Audio Out
Power Supply	AC 120V, 60Hz
Product Dimensions (W x D x H)	17.5 x 7.5 x 11 inches
Item Weight	0.01 ounces

## 8. WARRANTY AND SUPPORT


For warranty information and technical support, please refer to the warranty card included with your product or visit the official RCA support website. Keep your purchase receipt as proof of purchase for warranty claims.

### RCA Customer Support:

- **Website:** [www.rca.com/support](http://www.rca.com/support)
- **Phone:** Refer to product packaging or website for contact numbers.

© 2024 RCA. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.



**RCA**  
**INSTRUCTION MANUAL**  
Before using the TV, please read this manual thoroughly, and retain it for future reference.

Model: RT1970




RT1970 User Manual Instructions

RT1970 RCA EN FR UG V6 300110001523001 User Manual only legacy curtisint html CustService Manuals |||

**Model: RT1970 4009947 CONFORMS TO/CONFORME UL STD. 60065 CERTIFIED TO/CERTIFI AU CSA STD. C22.2 No.60065 EP 5000977 Digital audio out**

Connection Sound Menu This product meets ENERGY STAR guidelines for energy efficiency. ENERGY STAR and the ENERGY STAR mark are registered U.S. marks. ENERGY ...

lang:en score:34 filesize: 7.11 M page\_count: 25 document date: 2020-02-14



**RCA**  
**INSTRUCTION MANUAL**  
Before using the TV, please read this manual thoroughly, and retain it for future reference.

Model: RT1970



RT1970 User Manual Instructions

RT1970 RCA EN FR UG V6 300110001523001 Download 19" LED TV Televisions Canada and Smartphones French Manual User ENFR legacy curtisint html CustService Manuals |||

**Model: RT1970 4009947 CONFORMS TO/CONFORME UL STD. 60065 CERTIFIED TO/CERTIFI AU CSA STD. C22.2 No.60065 EP 5000977 Digital audio out**

Connection Sound Menu This product meets ENERGY STAR guidelines for energy efficiency. ENERGY STAR and the ENERGY STAR mark are registered U.S. marks. ENERGY ...

lang:en score:33 filesize: 13.83 M page\_count: 50 document date: 2018-11-23



**Abt**  
Celebrating 82 Years

**CUSTOMER APPRECIATION  
SALE**

2 DAYS ONLY  
Saturday, February 10th – 9am to 8pm & Sunday, February 11th – 10am to 7pm

**FREE DELIVERY, RECYCLING & HAUL-AWAY**  
24 Months Special Financing on Purchases Over \$799\*  
12 Months Special Financing on any Purchase\*  
with your Abt Credit Card through 02/11/18

**8 RT1970 Samsung 24 LED Smart HDTV / Clear Motion Rate 120**

lang:en score:19 filesize: 3.36 M page\_count: 8 document date: 2018-01-29



### [\[pdf\] Specifications Guide](#)

RCA RLED1945A E ENERGY STAR Certified Televisions v8 0 certification information for Product ID 2333956 Specification Version 8 2021 12 19 energystar.gov productfinder product certified televisions details export |||

ENERGY STAR CERTIFIED Televisions RCA - RLED1945A-E : RLED1945A-E Specifications ENERGY STAR Uniq ... ram Guide No 33.0 N/A 16.9 0.5 2019-02-26 United States, Canada Yes Additional Model Information ,**RT1970**, UPC Codes Captured On: 12/19/2021 ...

lang:es **score:17** filesize: 19.24 K page\_count: 1 document date: 2021-12-19



### [\[pdf\] Specifications Guide](#)

RCA RLED1945A E ENERGY STAR Certified Televisions v8 0 certification information for Product ID 2333956 Specification Version 8 2021 12 19 energystar.gov productfinder product certified televisions details export |||

ENERGY STAR CERTIFIED Televisions RCA - RLED1945A-E : RLED1945A-E Specifications ENERGY STAR Uniq ... ram Guide No 33.0 N/A 16.9 0.5 2019-02-26 United States, Canada Yes Additional Model Information ,**RT1970**, UPC Codes Captured On: 12/19/2021 ...

lang:es **score:17** filesize: 19.24 K page\_count: 1 document date: 2021-12-19



### [\[pdf\] User Manual Flyer](#)

N07p20 indd Hubert Yu We Remember HOT DiamondClean Smart Toothbrush Complete system for a healthier mouth than manual toothbrush can provide Available in 4 colours flyer f wishabi net flyers 18516064 4ce534996b75c99d

Save Thursday, November 7 Wednesday, November 13, 2019 We Remember. November 11 Ofers and rewards ... hites and brilliant colours VGA input allows connection to your computer for use as a PC monitor. #**RT1970** 9999 SAVE 20 Of our everyday low price RCA Home Theatre Projector Project a home theatre i...

lang:en **score:16** filesize: 22.14 M page\_count: 21 document date: 2019-11-05



### [\[pdf\] User Manual Flyer](#)

M15p20 indd SAVINGS week versus a manual toothbrush HX6877 21 HX6870 41 or HX6876 Honest Baby Products and Diapers Playtex Nurser with Drop Ins Liners flyer f wishabi net flyers 13992199 caf1f641cb411b53

Proudly Canadian Since 1945 Save Friday, March 15 Wednesday, March 20, 2019 699 30 SAVE Of our ... RCA 19 LED Backlit LCD TV The perfect accessory to complement any bedroom, oice, kitchen or den. #**RT1970** 44999 LG 360W Dolby Atmos Soundbar Connect and stream music from Bluetooth devices directly...

lang:en **score:15** filesize: 30.94 M page\_count: 22 document date: 2019-03-12



### [pdf] User Manual Flyer

O12p24 indd We take care of that versus a manual toothbrush Advanced sonic technology Improves gum health and removes 7 times more plaque HX6877 21 HX6870 41 or flyer f wishabi net flyers 11241031 1ebdceb9cfe5df04

Save Friday, October 12 - Wednesday, October 17, 2018 Fall NEW FAVES We take care of that We are mo ... RCA 19 LED Backlit LCD TV The perfect accessory to complement any bedroom, oice, kitchen or den. #RT1970 Pg 14 Prices efective Friday, October 12 - Wednesday, October 17, 2018 / Coupon value deduc... lang:en score:15 filesize: 34.18 M page\_count: 26 document date: 2018-10-11



### [pdf] User Manual Flyer Accessories

S06p28 indd Get it together than a manual toothbrush Feel the difference of gentle clean with our Pressure Sensor while removing up to 7x more plaque flyer f wishabi net flyers 17081019 dc910b594c5fe9ec

Save Friday, September 6 Wednesday, September 11, 2019 Ofers and rewards await Sign up in store o ... RCA 19 LED Backlit LCD TV The perfect accessory to complement any bedroom, oice, kitchen or den. #RT1970 Pg 22 Prices efective Friday, September 6 - Wednesday, September 11, 2019 / Coupon value de... lang:en score:15 filesize: 32.76 M page\_count: 29 document date: 2019-08-30



### [pdf]

ps1 2018 web content abt documents 84539 |||

Celebrating 82 Years Customer APPRECIATION sale 2 Days Only Saturday, February 10th 9am to 8pm S ...

.....Special..... 78 RT1970 Samsung 24 LED Smart HDTV / Clear Motion Rate 120.....

lang:i-klingon score:11 filesize: 3.01 M page\_count: 8 document date: 2018-01-26



### [pdf] Flyer Accessories

A26p08 RTG indd TECH SAVINGS EVENT flyer f wishabi net flyers 14820992 515f513889037275

TECH SAVINGS EVENT Save Friday, April 26 Wednesday, May 1, 2019 No receiver required. Just add vin ... RCA 19 LED Backlit LCD TV The perfect accessory to complement any bedroom, oice, kitchen or den. #RT1970 Rainchecks may not be available on some lyer merchandise. All prices are shown before applic... lang:en score:11 filesize: 10.15 M page\_count: 9 document date: 2019-04-24