Nokia TA-1036-R

Nokia 3310 3G User Manual

Model: TA-1036-R

Introduction

The Nokia 3310 3G is a modern reimagining of a classic, designed for simplicity and reliability. This manual will guide you through setting up and using your device, ensuring you can make the most of its features, from essential communication to entertainment.

What's in the Box

- Nokia 3310 3G Device
- Nokia MicroUSB Charger
- Charging/Data Cable
- Quick Start Guide

Setup

1. **Insert SIM Card:** Locate the SIM card slot, typically under the battery cover. Insert your compatible 3G SIM card into the designated slot.
2. **Insert Battery:** Place the included Lithium Polymer battery into its compartment, ensuring the contacts align correctly.

3. **Charge the Device:** Connect the MicroUSB charger to the phone's charging port and plug it into a power outlet. Allow the phone to charge fully before first use. A full charge provides up to 24 hours of talk time.
4. **Power On:** Press and hold the power key until the Nokia logo appears.

Operating Your Nokia 3310 3G

Your Nokia 3310 3G features an intuitive keypad and a simple user interface for ease of use.

Basic Navigation

Use the directional keys and the center select button to navigate through menus and select options. The left and right soft keys provide context-sensitive actions displayed on the screen.

Making Calls

Enter the phone number using the keypad and press the green call button to initiate a call. To end a call, press the red end call button.

Sending Messages

Access the Messaging application from the main menu. Select 'New message' and enter your recipient's number and message text. The T9 predictive text feature can assist with faster typing.

Camera Functionality

The phone is equipped with a 2MP rear camera and LED flash. To take a photo or record a video, navigate to the Camera application. Ensure adequate lighting for best results.



This image displays the Nokia 3310 3G mobile phone in its Warm Red color. The phone features a classic numeric keypad and a color display showing the time and date. The screen indicates 'Unlock' at the bottom.

Classic Snake Game

Enjoy the iconic Snake game with a modern look and feel. Access it from the Games menu. The game offers various levels and challenges.

Your browser does not support the video tag.

An official promotional video showcasing the key features of the Nokia 3310 3G, including its design, messaging capabilities, call functions, and the classic Snake game.

Connectivity

The Nokia 3310 3G supports Bluetooth 2.1 for connecting to compatible accessories like headsets or car kits. It also features a Micro USB port for charging and data transfer, and a 3.5 mm audio jack for headphones.

Music Player

The phone includes an MP3 player. You can store music files on a MicroSD card (up to 32 GB supported) and play them through the phone's speaker or connected headphones.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The phone has a durable design that withstands drops and spills, but it is not fully waterproof. Avoid submerging the device in water.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. Charge the battery regularly, but avoid overcharging.
- **Storage:** Store the phone in a cool, dry place when not in use.

Troubleshooting

- **Phone Not Turning On:** Ensure the battery is properly inserted and charged. If the issue persists, try removing and reinserting the battery.
- **No Network Signal:** Check if your SIM card is correctly inserted. Move to an area with better network coverage.
- **Battery Draining Quickly:** Reduce screen brightness, close unused applications, and limit background data usage.
- **Keypad Unresponsive:** Restart the device. If the problem continues, ensure no debris is lodged around the keys.

Specifications

Feature	Detail
Model Number	TA-1036-R
Dimensions	4.61 x 2.06 x 0.53 inches
Item Weight	1.6 ounces
Display	2.4 Inches, 320 x 240 pixels LCD
Camera	2MP Rear with LED Flash
Internal Storage	128 MB (expandable up to 32 GB with MicroSD)
RAM	0.5 GB
Battery	1220 mAh Lithium Polymer (24 hours talk time)

Connectivity	3G Cellular, Bluetooth 2.1, Micro USB, 3.5 mm Audio Jack
Operating System	Android (basic feature phone OS)

Warranty and Support

Your Nokia 3310 3G comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For further assistance, technical support, or to view the full user manual in PDF format, please visit the official Nokia support website or contact their customer service. A PDF version of the user manual is available for download:User Manual (PDF)

© 2024 Nokia. All rights reserved. Nokia is a registered trademark of Nokia Corporation.