

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ninco](#) /

> [Ninco 50660 Super Gt Bullshot Slot Car Instruction Manual](#)

## Ninco 50660

# Ninco 50660 Super Gt Bullshot Slot Car Instruction Manual

Model: 50660

## 1. SAFETY INFORMATION

---

**WARNING:** This product is not suitable for children under 8 years of age due to small parts and potential choking hazards. Adult supervision is recommended during use.

- Always operate the slot car on a clean, dry surface.
- Keep fingers and loose clothing away from moving parts.
- Do not modify the slot car or its components, as this may affect performance and safety.
- Store the slot car in a cool, dry place away from direct sunlight and extreme temperatures.

## 2. PRODUCT OVERVIEW

---

The Ninco 50660 Super Gt Bullshot is a fantasy GT slot car designed for use on compatible slot car tracks. It features a durable thermoformed shell and a universal chassis, ensuring compatibility and robust performance. This model is manufactured by Ninco, a brand known for quality and durability in toy vehicles.



Figure 2.1: Front-side view of the Ninco 50660 Super Gt Bullshot slot car, showcasing its red and black livery with racing decals.



Figure 2.2: Rear-side view of the Ninco 50660 Super Gt Bullshot slot car, highlighting the rear spoiler and wheel design.



Figure 2.3: Side view of the Ninco 50660 Super Gt Bullshot slot car, showing the full profile and racing number '21'.

### 3. SETUP

---

The Ninco 50660 Super Gt Bullshot slot car comes pre-assembled and does not require complex setup. Follow these steps to prepare for operation:

1. **Unpack:** Carefully remove the slot car from its packaging.
2. **Inspect:** Check for any visible damage or loose parts. Ensure the guide flag and braids are properly seated.
3. **Prepare Track:** Ensure your slot car track is clean, properly assembled, and powered according to its own instruction manual.

### 4. OPERATING INSTRUCTIONS

---

To operate your Ninco 50660 Super Gt Bullshot slot car, follow these steps:

1. **Place on Track:** Carefully place the slot car onto the track, ensuring the guide flag is correctly inserted into the track slot and the braids are making contact with the track rails.
2. **Connect Controller:** Connect your slot car controller to the track power base (controller not included with this slot car).
3. **Start Racing:** Gently press the controller trigger to apply power and make the car move. Adjust speed as needed to navigate corners and straights.
4. **Remove from Track:** To stop, release the controller trigger. Carefully lift the car from the track when finished.

**Note:** Optimal performance depends on the condition of the track and controller. Refer to your slot car track system's manual for specific power and control instructions.

### 5. MAINTENANCE

---

Regular maintenance ensures the longevity and performance of your Ninco 50660 Super Gt Bullshot slot car.

- **Cleaning:** Use a soft, dry cloth to wipe down the car body. For the chassis and wheels, a small brush can help remove dust and debris. Avoid using harsh chemicals or abrasive cleaners.
- **Braid Maintenance:** Periodically check the braids (electrical contacts) under the guide flag. If they become frayed or dirty, gently clean them or replace them if necessary to ensure good electrical contact with the track.

- **Axle and Gear Inspection:** Ensure axles spin freely and gears are clean and free of obstructions. A small amount of specialized slot car lubricant can be applied to axles if needed (consult a hobby specialist).
- **Storage:** Store the slot car in its original packaging or a protective case to prevent dust accumulation and damage.

## 6. TROUBLESHOOTING

---

If your Ninco 50660 Super Gt Bullshot slot car is not performing as expected, consider the following common issues:

- **Car Not Moving:**
  - Ensure the track is powered and the controller is connected correctly.
  - Check if the guide flag is properly seated in the track slot.
  - Verify that the braids are making good contact with the track rails and are not dirty or worn.
  - Inspect the motor and wiring for any visible disconnections (if accessible).
- **Poor Performance / Stuttering:**
  - Clean the track rails and the car's braids.
  - Ensure the wheels and axles are free of hair or debris.
  - Check for any binding in the drivetrain.
- **Car Derails Frequently:**
  - Reduce speed, especially on corners.
  - Ensure the track sections are securely connected and flat.
  - Check the guide flag for damage or excessive wear.

For persistent issues, consult a hobby specialist or contact Ninco customer support.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Ninco
<b>Model Number</b>	50660
<b>Product Dimensions (L x W x H)</b>	14 x 6 x 4 cm
<b>Item Weight</b>	1 kilogram
<b>Recommended Age (Manufacturer)</b>	8 years and up
<b>Assembly Required</b>	No
<b>Batteries Required</b>	No
<b>Composition</b>	Plastic
<b>Remote Control Included</b>	No
<b>Color</b>	Multicolor (Red and Black)
<b>Car Shape</b>	Car (GT Fantasy)
<b>Model Year</b>	2018

Country of Origin	Spain
-------------------	-------

## 8. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, spare parts availability, or technical support for your Ninco 50660 Super Gt Bullshot slot car, please refer to the official Ninco website or contact their customer service department. Keep your proof of purchase for any warranty claims.

**Note:** Information on spare parts availability is not provided in the product details. Please contact the manufacturer directly for inquiries.

