Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Pure /
- > Pure Siesta S6 Bluetooth Alarm Clock Radio User Manual

Pure S6 (P149584)

Pure Siesta S6 Bluetooth Alarm Clock Radio User Manual

Model: S6 (P149584)

Introduction

The Pure Siesta S6 is a sophisticated DAB/DAB+ and FM alarm clock radio designed to enhance your bedside experience. It features a large, ultra-clear CrystalVue display, impressive audio quality via Bluetooth, and a convenient USB port for charging your devices. This manual provides comprehensive instructions for setting up, operating, and maintaining your Siesta S6.

Key Features

- Wireless Audio Streaming: Use Siesta S6 as a wireless speaker to stream audio content from your smartphone, laptop, or tablet via Bluetooth.
- CrystalVue+ Display: Large, ultra-clear display for optimal readability, with adaptive brightness.
- Siesta Timer: Program a short nap with a single button press.
- Integrated USB Power Port: Keep your phone, tablet, or other devices fully charged by connecting them to the built-in USB port.
- DAB/DAB+ and FM Radio: Access a wide range of digital and analog radio stations.
- **Multiple Alarms:** Set up to three independent alarms with customizable days, sources (tone, last station, preset), and volume.

Setup Guide

Follow these steps to set up your Pure Siesta S6 for the first time.

- 1. Unpack the Device: Carefully remove the Siesta S6 from its packaging.
- 2. **Connect Power:** Insert the supplied mains adapter into the DC IN port on the back of the unit. Plug the adapter into a wall outlet.



Image: Rear view of the Siesta S6, highlighting the USB charging port and the power input.

- 3. **Position the Antenna:** Uncoil the wire antenna fully for optimal DAB/DAB+ and FM reception. Position it away from other electronic devices.
- 4. **Initial Scan:** Upon first power-up, the Siesta S6 will automatically scan for available DAB/DAB+ radio stations and set the clock. This process may take a few minutes.



Image: Angled front view of the Pure Siesta S6, displaying the time and alarm indicators.

5. **Adjust Display Brightness (Optional):** The display brightness adjusts automatically. If desired, you can manually adjust this setting via the "Menu" section.

Operating Instructions

This section details the various functions and controls of your Siesta S6.

Controls Overview



Image: Close-up of the top panel buttons, including Menu, Siesta, Alarm 1-4, Preset, Volume, Power, Sleep, Source, and Navigation buttons.

Power Button (•): Press to turn the unit on or off.

Menu Button: Access system settings and options.

Siesta Button: Activates the Siesta timer for short naps.

Alarm Buttons (1, 2, 3, 4): Press to activate/deactivate or configure individual alarms.

Preset Button: Save and recall your favorite radio stations.

Volume (+/-) Buttons: Adjust the audio volume.

Sleep Button: Set a sleep timer for the radio to turn off automatically.

Source Button: Switch between DAB, FM, and Bluetooth modes.

Navigation Buttons (< Select >): Navigate menus and select options.

Snooze Bar: Press to temporarily silence an active alarm.

Radio Operation (DAB/DAB+ and FM)

- 1. **Select Mode:** Press the **Source** button to cycle between DAB and FM radio modes.
- 2. Tune Stations:
 - DAB: In DAB mode, use the < and > buttons to browse available stations. Press Select to tune to a station.
 - FM: In FM mode, press Select to auto-scan for the next available station. Use < and > for fine-tuning.
- 3. **Save Presets:** To save a station, press and hold the **Preset** button. Use < and > to choose a preset number, then press **Select** to confirm.
- 4. **Recall Presets:** Briefly press the **Preset** button. Use < and > to select a preset, then press **Select**.

Bluetooth Pairing and Streaming

1. Enter Bluetooth Mode: Press the Source button until "Bluetooth" is displayed. The Siesta S6 will enter

- pairing mode, indicated by a flashing Bluetooth icon.
- 2. **Pair Your Device:** On your smartphone, tablet, or computer, enable Bluetooth and search for "Pure Siesta S6" in the list of available devices. Select it to pair.
- 3. **Start Streaming:** Once paired, you can play audio from your device, and it will stream wirelessly to the Siesta S6.

Setting Alarms



Image: A hand interacting with the top controls of the Siesta S6, demonstrating alarm setting.

- 1. Select Alarm: Press one of the Alarm (1, 2, 3, or 4) buttons to select an alarm to configure.
- Configure Settings: Use the < and > buttons to adjust the time, alarm source (DAB, FM, Tone, Last Station), volume, and days of the week (Everyday, Weekdays, Weekends, Once). Press Select to confirm each setting.
- 3. **Activate/Deactivate:** Briefly press the corresponding **Alarm** button to toggle the alarm on or off. An active alarm will show its indicator on the display.
- 4. **Snooze:** When an alarm sounds, press the **Snooze** bar to temporarily silence it. The alarm will sound again after the snooze period.
- 5. **Stop Alarm:** To turn off a sounding alarm completely, press the **Power** button.

Using the Siesta Timer

The Siesta timer allows you to set a short nap timer.

- 1. Activate: Press the Siesta button.
- 2. **Set Duration:** Use the < and > buttons to set the desired nap duration (e.g., 5, 10, 15 minutes).
- 3. Confirm: Press Select to start the Siesta timer. The display will show the countdown.

USB Charging

The USB port on the back of the Siesta S6 can be used to charge your mobile devices.

- Connect your device's USB charging cable to the USB port on the Siesta S6.
- Ensure the Siesta S6 is powered on and connected to mains electricity.
- Charging will begin automatically.

Maintenance

Proper care will ensure the longevity of your Siesta S6.

- Cleaning: Wipe the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Placement:** Avoid placing the unit in direct sunlight, near heat sources, or in environments with high humidity or dust.
- **Ventilation:** Ensure adequate ventilation around the unit to prevent overheating. Do not block ventilation openings.

Troubleshooting

If you encounter issues with your Siesta S6, refer to the following common problems and solutions.

Problem	Solution
No Power	Ensure the power adapter is securely connected to both the unit and a working wall outlet.
Poor Radio Reception	Fully extend and reposition the wire antenna. Try moving the unit to a different location, away from other electronic devices that may cause interference. Perform a full scan for DAB stations.
Bluetooth Not Connecting	Ensure the Siesta S6 is in Bluetooth pairing mode (flashing icon). Make sure Bluetooth is enabled on your device and it is within range. Try unpairing and re-pairing the device.
Alarm Not Sounding	Verify that the alarm is activated (indicator on display). Check the alarm volume setting. Ensure the alarm time is correctly set.
Display Too Dim/Bright	Access the Menu settings to adjust the display brightness or toggle the automatic brightness feature.

Specifications

Feature	Detail
Brand	Pure
Model Number	P149584
Color	Noir (Black)
Product Type	Digital Alarm Clock Radio
Display Size	3.9 Inches
Connectivity	Bluetooth
Special Features	Alarm, Siesta Timer, USB Charging Port
Compatible Devices	Mobile Phone, Tablet

Feature	Detail
Power Source	Mains Powered
Product Dimensions	14.6L x 7H centimeters

Warranty and Support

Pure products are designed and manufactured to the highest standards. For warranty information and technical support, please refer to the warranty card included with your product or visit the official Pure website. Keep your proof of purchase for warranty claims.

For further assistance, you may also contact Pure customer service through their official channels.

© 2024 Pure. All rights reserved.

Related Documents - S6 (P149584)



PURE 1852595 S6 Siesta Radio Alarm Clock User Manual

Comprehensive user manual for the PURE 1852595 S6 Siesta Radio Alarm Clock, covering setup, basic options, alarm functions, specifications, and warranty information.



Pure Siesta S6 Digital Radio and Bluetooth Speaker - User Guide

Comprehensive guide to setting up and using the Pure Siesta S6, covering radio tuning, Bluetooth connectivity, alarm functions, timers, settings, and specifications.



Pure Siesta Rise (Bluetooth) User Manual and Quick Start Guide

Comprehensive guide for the Pure Siesta Rise (Bluetooth) digital radio, covering setup, features like alarms, sleep timer, Bluetooth connectivity, and specifications. Includes multilingual instructions.



Pure Siesta Charge User Guide: Wireless Charging, DAB/FM Radio, Bluetooth

Comprehensive user guide for the Pure Siesta Charge, detailing setup, wireless charging, radio functions (DAB/FM), Bluetooth connectivity, alarm settings, and basic operations.



PURE Moment Ambient Sleep Companion - DAB+/FM Radio, Bluetooth Speaker, Sunrise Alarm

Explore the PURE Moment, an ambient sleep companion offering DAB+/FM radio, Bluetooth 5.3, natural sounds, and a sunrise alarm. Enhance sleep hygiene with customizable alarms and a dimmable light for a tranquil bedroom experience.



Pure Siesta Charge DAB Radio with Wireless Charging - User Manual

User manual for the Pure Siesta Charge DAB/FM radio with Bluetooth and wireless charging capabilities. Learn how to set up, operate, and use all features of your Siesta Charge.