

## Habitdesign F00532801001

# Habitdesign Distrimobel Saetabis Vanilla A10 Wall Unit Instruction Manual

Model: F00532801001

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Habitdesign Distrimobel Saetabis Vanilla A10 Wall Unit. Please read all instructions carefully before beginning assembly to ensure safe and correct installation. Keep this manual for future reference.

**Safety Warning: Always read and follow the assembly instructions provided in the product packaging to ensure safe installation and use. Wall mounting must be performed securely to prevent tipping.**

## 2. COMPONENTS OVERVIEW

Before starting assembly, unpack all components and verify them against the parts list included in your product packaging. Ensure all pieces are present and undamaged. If any parts are missing or damaged, please contact customer support.



*Figure 2.1: Fully assembled Habitdesign DISTRIMOBEL Saetabis Vanilla A10 Wall Unit, showcasing the lower TV cabinet and upper wall-mounted shelf with storage.*

### 3. ASSEMBLY INSTRUCTIONS

Assembly of the Habitdesign DISTRIMOBEL Saetabis Vanilla A10 Wall Unit requires careful attention to detail. It is recommended to have two people for assembly, especially for wall mounting.

1. **Preparation:** Clear a spacious area for assembly. Lay out all components on a soft, clean surface to prevent scratches. Identify all hardware and panels.
2. **Assemble the Base Unit:** Follow the step-by-step diagrams in your product's included manual to construct the main TV cabinet base. Ensure all connections are tight and secure.
3. **Assemble the Wall-Mounted Unit:** Construct the upper wall-mounted cabinet and shelf according to the provided instructions.
4. **Wall Mounting:** The upper unit is designed for wall fixation. Use appropriate wall anchors and screws for your wall type (e.g., drywall, concrete). Ensure the wall can support the weight of the unit and its contents. Use a level to ensure horizontal alignment.
5. **Attach Doors and Hinges:** Install the doors onto both the base and wall units. Note that there may be different types of hinges for various door positions (e.g., shorter hinges for central doors). Refer to the specific hinge

instructions to ensure correct alignment and function. Adjust hinges as needed for proper door closure and alignment.

6. **Final Inspection:** Once assembled, check all connections for stability. Ensure doors open and close smoothly.



*Figure 3.1: Interior view of the lower TV cabinet, showing multiple compartments for storage.*





Figure 3.2: Interior view of the upper wall-mounted cabinet, featuring sliding doors and internal storage space.

## 4. OPERATION AND USAGE

The Habitdesign DISTRIMOBEL Saetabis Vanilla A10 Wall Unit is designed for versatile storage and display in your living space.

- **Lower TV Cabinet:** Use the spacious compartments behind the doors to store media devices, cables, books, or other household items. The top surface is suitable for placing a television or decorative objects.
- **Upper Wall-Mounted Unit:** The upper cabinet provides additional enclosed storage with sliding doors, ideal for items you wish to keep out of sight. The open shelf is perfect for displaying decorative items, photos, or small plants.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 40 kg for the entire unit. Distribute weight evenly across shelves and compartments.

## 5. CARE AND MAINTENANCE

To maintain the appearance and longevity of your wall unit, follow these care instructions:

- **Cleaning:** Use a soft, damp cloth for general cleaning. For specific stains or deeper cleaning, use a product designed for furniture made of wood and melamine. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Dusting:** Regularly dust surfaces with a dry, soft cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.
- **Protect Surfaces:** Use coasters or mats under hot or wet items to prevent damage to the surface.

## 6. TROUBLESHOOTING

---

If you encounter issues during or after assembly, consider the following:

- **Misaligned Doors:** If doors do not align correctly or close properly, check the hinge installation. Ensure you have used the correct hinge type for each door (e.g., shorter hinges for central doors). Adjust the screws on the hinges to fine-tune door alignment.
- **Unit Instability:** Ensure all screws and fasteners are tightened securely. For wall-mounted units, verify that the wall anchors are appropriate for your wall type and installed correctly.
- **Missing Parts:** If you find any parts missing during assembly, refer to the contact information provided in your product packaging to request replacements.

## 7. PRODUCT SPECIFICATIONS

---




Figure 7.1: Dimensional diagram of the wall unit, indicating overall length, depth, and height for both the lower and upper sections.

Feature	Detail
Brand	Habitdesign
Model Number	F00532801001
Dimensions (L x D x H)	200 x 41 x 43 cm
Material	Wood, Plastic (Melamine finish)
Weight	51.3 Kilograms
Maximum Weight Capacity	40 Kilograms
Assembly Required	Yes
Wall Mounting	Yes (for upper unit)

Feature	Detail
Color	Arctic White and Canadian Oak


## 8. WARRANTY AND SUPPORT

For warranty information, details on replacement parts, or technical support, please refer to the documentation included with your purchase. You may also contact Habitdesign customer service directly through their official channels for assistance.



© 2023 Habitdesign. All rights reserved.

### Related Documents - F00532801001

	<p><a href="#">Catálogo Detallado de Productos y Precios</a></p> <p>Explore un extenso catálogo de productos que abarca mejoras para el hogar, artículos de cocina, equipos deportivos, productos para bebés y más. Cada artículo incluye una descripción detallada y precio.</p>
--	---