

Manuals.plus /

› Lepro /

› Lepro LED Desk Lamp User Manual - Model 3100030-EU

## Lepro 3100030-EU

# Lepro LED Desk Lamp User Manual

Model: 3100030-EU | Brand: Lepro

## INTRODUCTION

Thank you for choosing the Lepro LED Desk Lamp. This lamp is designed to provide versatile and comfortable lighting for various tasks, featuring adjustable brightness, multiple color temperatures, a flexible design, and convenient additional functions.



The Lepro LED Desk Lamp provides versatile illumination for your workspace.

- **Adjustable Lighting:** Choose from 3 color temperatures (3000K Warm White, 4700K Natural White, 6000K Cool White) and stepless dimming from 5% to 100% brightness.
- **Flexible Design:** The lamp features a multi-angle adjustable arm and head, allowing for precise light

positioning. The base rotates 90 degrees, and the lamp head adjusts 180 degrees.

- **Integrated USB Port:** A 5V/1A USB output port is located on the back of the base for convenient charging of your electronic devices.
- **Smart Functions:** Includes a memory function to recall your last lighting setting and a 30-second timer for automatic shut-off.
- **Durable Construction:** Made with a brushed aluminum alloy stand and shade, ensuring excellent heat dissipation and longevity, with ABS plastic articulations for flexibility.

## SETUP INSTRUCTIONS

---

1. **Unpack Contents:** Carefully remove the lamp, power adapter, and cleaning cloth from the packaging.
2. **Position the Lamp:** Place the lamp on a stable, flat surface such as a desk or table.
3. **Connect Power:** Insert the power adapter's DC plug into the power input port on the back of the lamp base. Then, plug the power adapter into a standard electrical outlet.



Ensure all components, including the power adapter and cleaning cloth, are present.

## OPERATING INSTRUCTIONS

---

## 1. Power On/Off

Gently touch the power symbol (ⓘ) on the lamp base to turn the lamp on or off.

## 2. Adjusting Brightness

Slide your finger along the touch panel (indicated by a horizontal line with sun icons) on the lamp base to adjust the brightness level from 5% to 100%. The lamp offers stepless dimming for precise control.

## 3. Changing Color Temperature

Touch the mode symbol (icons resembling a coffee cup, book, and computer) on the lamp base to cycle through the three available color temperature modes:

- **3000K (Warm White):** Ideal for relaxation or a cozy atmosphere.
- **4700K (Natural White):** Suitable for general reading and daily tasks.
- **6000K (Cool White):** Best for focused work and concentration.



Easily switch between three color temperatures and adjust brightness with the touch controls.

## 4. USB Charging Port

Connect your smartphone, tablet, or other USB-powered devices to the 5V/1A USB output port located on the rear of the lamp base for convenient charging.

## Integrate 5V/1A USB Port

Charge your phone and other device more effectively

5V/1A  
USB



Charge your devices efficiently using the integrated 5V/1A USB port.

### 5. Memory Function

The lamp automatically remembers your last used brightness and color temperature settings. When you turn the lamp on again, it will resume with these previous settings.

### 6. 30-Second Timer

Touch the clock symbol (**CLOCK**) on the lamp base to activate the 30-second timer. The lamp will dim to a low light level and automatically turn off after 30 seconds, providing a convenient delay for leaving a room or falling asleep.

# Light for every Moment



Utilize the timer and memory functions for enhanced convenience.

## 7. Adjusting Lamp Position

The lamp's design allows for extensive adjustment to direct light precisely where needed:

- **Base Rotation:** The lamp base can be rotated up to 90 degrees horizontally.
- **Arm Adjustment:** The main arm of the lamp can be adjusted to various angles.
- **Head Adjustment:** The lamp head can be tilted and rotated up to 180 degrees vertically.



Adjust the lamp's arm and head to achieve optimal lighting angles.



The flexible design allows for precise light direction, suitable for various scenarios.

## MAINTENANCE

---

- **Cleaning:** Use the provided cleaning cloth or a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or electronic components.
- **Storage:** If storing the lamp for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **LEDs:** The LED light source is integrated and not user-replaceable. Do not attempt to disassemble the lamp head.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply or loose connection.	Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet.
Light flickers or brightness is inconsistent.	Unstable power supply or dirty touch panel.	Check the power source. Clean the touch control panel with a dry cloth.
USB charging port is not working.	Device incompatibility or faulty cable.	Ensure your device is compatible with 5V/1A USB charging. Try a different USB cable.
Lamp does not hold its adjusted position.	Joints may be loose or over-extended.	Gently readjust the lamp to a stable position. Avoid forcing joints beyond their intended range of motion.

## SPECIFICATIONS

Feature	Detail
Model Number	3100030-EU
Dimensions (L x W x H)	14P x 21l x 48H cm (5.5 x 8.3 x 18.9 inches)
Weight	1450 Grams (3.2 lbs)
LED Power	9 Watts
USB Output	5V/1A (10 Watts)
Input Voltage	240 Volts
Color Temperatures	3000K, 4700K, 6000K
Brightness Adjustment	Stepless Dimming (5%-100%)
Control Method	Touch Control
Materials	Brushed Metal (Base, Shade), ABS Plastic (Articulations)
Included Components	Desk Lamp, Power Adapter, Cleaning Cloth

## WARRANTY AND SUPPORT

This product comes with a 1-year availability of spare parts, indicating a commitment to product support.

For any questions, technical assistance, or warranty claims, please contact the retailer where you purchased the product or visit the official Lepro website for customer support information.

Please retain your proof of purchase for warranty purposes.

