

[Manuals.plus](#) /

> [Air Wick](#) /

> Air Wick Essential Mist Diffuser Starter Kit: Lavender and Almond Blossom User Manual

Air Wick 62338-98576

Air Wick Essential Mist Diffuser Starter Kit: Lavender and Almond Blossom User Manual

1. INTRODUCTION

The Air Wick Essential Mist Starter Kit transforms natural essential oils into a fine, fragrant mist, enhancing your living space with a divine blend of freshness and softness. The fresh aroma of lavender wrapped with the delicate sweet and creamy floralcy of almond blossom brings a feeling of joy and serenity. This portable, cordless, and battery-operated device offers a modern way to experience fragrance, automatically diffusing scent for 8 hours and then pausing for 16 hours before restarting.



Image: The Air Wick Essential Mist Diffuser Starter Kit, featuring the diffuser unit and a refill bottle, highlighting the Lavender and Almond Blossom scent.

2. SAFETY INFORMATION

- **Eye Irritant:** Avoid contact with eyes. In case of contact, rinse immediately with plenty of water and seek medical advice.
- **Skin Contact:** Prolonged or frequent skin contact may cause an allergic reaction. Avoid contact with skin and clothing. If on skin, wash with plenty of soap and water. If irritation persists, get medical attention.
- **Ingestion:** DO NOT ingest. If swallowed, DO NOT induce vomiting. Call a physician or Poison Control Center immediately.
- **Ventilation:** Use in well-ventilated areas.
- **Children and Pets:** Keep out of reach of children and pets.
- **Discontinue Use:** Discontinue use immediately and get medical attention if a reaction develops.
- **Handling:** Wash hands after handling.

3. INGREDIENTS

The essential oil refill contains: C13-14 Isoparaffin, C 11-13 Isoparaffin, PPG-2 Methyl Ether, Fragrance.

4. PACKAGE CONTENTS

- 1 Air Wick Essential Mist Diffuser Unit
- 1 Essential Oil Refill (Lavender and Almond Blossom)
- 2 AA Batteries



Image: The Air Wick Essential Mist Starter Kit displayed in its retail packaging, showing the diffuser and refill.

5. SETUP INSTRUCTIONS

1. Remove the Air Wick Essential Mist Starter Kit from its packaging.
2. Gently twist the top cover of the diffuser counter-clockwise and lift it off to reveal the battery compartment and refill slot.
3. Insert the 2 AA batteries into the designated slots, ensuring correct polarity (+/-).
4. Remove the cap from the essential oil refill bottle.
5. Insert the essential oil refill bottle firmly into the diffuser unit until you hear a click, ensuring it is securely seated.
6. Replace the top cover of the diffuser by aligning it and twisting clockwise until it locks into place.
7. Place the device on a flat, stable surface in your desired location. For optimal performance, ensure it is in a well-ventilated area.



Image: A close-up view of the Air Wick Essential Mist Diffuser, showcasing the sleek design and the essential oil refill bottle.

6. OPERATING INSTRUCTIONS

The Air Wick Essential Mist Diffuser features adjustable settings and an automatic cycle for continuous fragrance.

- **Power On/Off:** Use the switch located on the side of the diffuser to turn the device on or off.
- **Intensity Settings:** The diffuser offers 5 adjustable intensity settings (Off, Low, Medium, High, Max) to control the fragrance output. Select your preferred level using the slider switch.
- **Automatic Cycle:** Once activated, the device operates on an 8-hour cycle, diffusing mist periodically. After 8 hours, it automatically shuts off for 16 hours, then restarts at the same time the next day.
- **Mist Duration & Pause:**
 - **Low:** 4-second mist burst, 17-minute pause.
 - **Medium:** 5-second mist burst, 12-minute pause.
 - **High:** 6-second mist burst, 10-minute pause.
- **Refill Lifespan:** Each essential oil refill lasts up to 45 days when used on the lowest intensity setting.

- **Waterless Operation:** The device diffuses pure essential oils directly, requiring no water.
- **Portability:** Being battery-operated and cordless, the diffuser can be placed anywhere in your home without needing to be near an electrical outlet.



Image: A visual guide illustrating the different mist burst durations and pause intervals for the low, medium, and high fragrance settings.

7. MAINTENANCE

- **Refill Replacement:** When the essential oil refill is empty, twist off the top cover, remove the old refill, and insert a new one as per the setup instructions.
- **Battery Replacement:** When the device stops misting or the indicator light fades, replace the 2 AA batteries.
- **Cleaning:** Periodically wipe the exterior of the diffuser with a soft, damp cloth to remove any dust or residue. Do not immerse the device in water.



Image: A graphic emphasizing that refills are ready to use, require no added water, and can last up to 45 days on the low setting.

8. TROUBLESHOOTING

- **Device not misting:**
 - Check if the batteries are correctly inserted and not depleted. Replace if necessary.
 - Ensure the essential oil refill is securely inserted into the device.
 - Verify the device is switched to an active setting (Low, Medium, High, Max) and not Off.
- **Scent is too strong or too weak:**
 - Adjust the intensity setting using the slider switch on the side of the diffuser to your preferred level.
 - Ensure the device is placed in an appropriately sized room for the desired fragrance intensity.
- **Refill not lasting as long as expected:**
 - The refill duration depends on the intensity setting. The lowest setting provides up to 45 days of fragrance. Higher settings will consume the oil more quickly.

9. SPECIFICATIONS

Product Dimensions	3.35 x 7.09 x 6.3 inches
Item Weight	9.28 ounces
Item Model Number	62338-98576
Batteries	2 AA batteries (included)
Material	Plastic
Scent	Lavender & Almond Blossom
Special Feature	Adjustable, Premium

10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Air Wick website. Keep your purchase receipt for any warranty claims.