

[manuals.plus](#) /› [Anker](#) /› [Anker Zolo Liberty+ Total-Wireless Earphones Instruction Manual \(Model Z2010011\)](#)**Anker Z2010011**

# Anker Zolo Liberty+ Total-Wireless Earphones Instruction Manual

Model: Z2010011

## 1. INTRODUCTION

The Zolo Liberty+ Total-Wireless Earphones offer a cable-free audio experience with advanced features. These earphones are designed with revolutionary graphene-augmented drivers for superior sound clarity and extended battery life. They incorporate adjustable ambient sound levels and smart AI integration for enhanced user interaction. The robust design ensures a secure fit and sweatproof performance, making them suitable for various activities.

## 2. WHAT'S IN THE Box

Please check the package contents to ensure all items are present:

- Zolo Liberty+ Total-Wireless Earphones
- Zolo Liberty+ Charging Case
- 4 x GripFit Jackets (various sizes)
- 3 x Ear Tips (various sizes)
- Micro-USB Cable
- User Manual
- Travel Pouch




Image: All accessories included with the Zolo Liberty+ earphones, neatly arranged.

### 3. SETUP

#### 3.1. Charging the Earphones and Case

Before first use, fully charge the Zolo Liberty+ earphones and their charging case. Place the earphones into the charging case. The LED indicators on the case will show the charging status. A full charge provides approximately 3.5 hours of playtime, which can be extended to an impressive 48 hours with multiple recharges from the fully charged case.



48  
HOURS

Playtime

## Super-Extended Playtime

Included charging case offers over 12 on-the-go recharges.

Image: Zolo Liberty+ earphones in their charging case, illustrating the charging process.

### 3.2. Pairing with Your Device (PUSH AND GO™ Technology)

The Zolo Liberty+ features PUSH AND GO™ technology for quick and easy pairing:

1. **Initial Pairing:** Remove both earphones from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), open the Bluetooth settings.
3. Select "Zolo Liberty+" from the list of available devices.
4. Once connected, you will hear an audio confirmation.
5. **Automatic Reconnection:** After the initial setup, the earphones will automatically connect to your last paired device when removed from the case. They will disconnect when returned to the case.



## Graphene-Enhanced Sound

Advanced audio technology delivers exceptional clarity.

Image: A user interacting with the Zolo Liberty+ charging case and earphones, demonstrating the PUSH AND GO™ pairing process.

### 4. OPERATING INSTRUCTIONS

#### 4.1. Graphene-Enhanced Sound


The Zolo Liberty+ earphones feature graphene-coated drivers. This advanced material allows for precision oscillation, delivering superior sound clarity and boosted treble. The rigid yet lightweight construction of the drivers contributes to breathtaking audio quality with deep bass and exceptional sound isolation.



Image: A close-up diagram of the graphene-enhanced driver, highlighting its advanced audio technology.

## 4.2. GripFit™ Technology for Secure Fit

GripFit™ technology ensures that the Liberty+ earphones fit comfortably and securely in your ear. To achieve the best fit, simply slide the earphone into your ear and gently turn to lock it into place. The included silky smooth liquid silicon Ear Tips and Grip Jackets in multiple sizes allow for personalized comfort and stability.



## GripFit™ Technology


Secure and comfortable fit in any ears.

Image: A person wearing the Zolo Liberty+ earphones, illustrating the secure and comfortable fit provided by GripFit™ technology.

### 4.3. Toggle Audio Isolation / Smart AI Activation

With a single tap on the earphone, you can toggle sound isolation to either immerse yourself in your audio or allow ambient sounds to pass through for better awareness of your surroundings. This one-tap activation also allows you to activate your favorite AI Assistant (e.g., Siri, Google Assistant). The microphones are optimized for voice recognition,

ensuring clear commands and quick responses.



## Toggle Audio Isolation

Hear only your music or let in the outside world.

Image: A user toggling the audio isolation feature, indicating the ability to switch between immersive sound and environmental awareness.

### 4.4. Sweatproof Design (IPX5 Rating)

The Zolo Liberty+ earphones feature an IPX5 water resistance rating. This means they are protected against low-pressure

water jets from any direction, making them ideal for workouts and outdoor activities where sweat or light rain might be a factor. Ensure the earphones are dry before placing them back into the charging case.



## Sweat Proof

IPX5-rated housing prevents water ingress.

Image: A person engaged in a strenuous activity, demonstrating the sweatproof nature of the Zolo Liberty+ earphones.

## 5. MAINTENANCE

- **Cleaning:** Regularly clean the earphones and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earphones in their charging case to protect them and keep them charged.
- **Water Exposure:** While sweatproof, avoid prolonged exposure to water. If they get wet, dry them thoroughly before charging or storing.

## 6. TROUBLESHOOTING

Problem	Solution
Earphones do not turn on.	Ensure the earphones are charged. Place them in the charging case and check the LED indicators.
Earphones do not pair with my device.	<ol style="list-style-type: none"> <li>1. Ensure Bluetooth is enabled on your device.</li> <li>2. Remove both earphones from the charging case to activate pairing mode.</li> <li>3. Forget "Zolo Liberty+" from your device's Bluetooth list and try pairing again.</li> <li>4. Ensure the earphones are within the effective Bluetooth range (typically 10 meters/33 feet).</li> </ol>
Only one earphone is playing audio.	<ol style="list-style-type: none"> <li>1. Place both earphones back into the charging case, close the lid, and then take them out again.</li> <li>2. Ensure both earphones are sufficiently charged.</li> <li>3. If the issue persists, try resetting the earphones (refer to the full user manual for specific reset instructions if available).</li> </ol>
Poor sound quality or intermittent connection.	<ol style="list-style-type: none"> <li>1. Ensure there are no obstructions between your device and the earphones.</li> <li>2. Move closer to your device.</li> <li>3. Avoid strong electromagnetic interference from other devices.</li> <li>4. Check for firmware updates via the Zolo Life app (if applicable).</li> </ol>

## 7. SPECIFICATIONS

Feature	Detail
Model Name	AK-Z2010011
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Audio Driver Type	Dynamic Driver (Graphene-coated)
Audio Driver Size	6 Millimeters
Battery Life (Earphones)	Up to 3.5 Hours

Feature	Detail
Total Playtime (with Charging Case)	Up to 48 Hours
Charging Time (Case)	3.5 Hours
Water Resistance Level	IPX5 (Sweatproof)
Control Method	Touch
Special Features	Microphone Included, Voice Activated, Sound Isolation
Item Weight	9.6 ounces (total package)
UPC	848061057294

## 8. WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the official Anker (Zolo) website or contact their customer support directly. Keep your proof of purchase for warranty claims.

You can often find additional resources, FAQs, and contact details on the manufacturer's official support pages.