

Air Wick 3237920

Air Wick Essential Mist Refill: Lavender and Almond Blossom User Manual

Model: 3237920 | Brand: Air Wick

INTRODUCTION

This manual provides instructions for the safe and effective use of your Air Wick Essential Mist Refill in Lavender and Almond Blossom scent. This product is designed to be used with an Air Wick Essential Mist diffuser (sold separately) to release a fine mist of fragrance infused with natural essential oils, enhancing the ambiance of your home.

IMPORTANT SAFETY INFORMATION

- Keep out of reach of children and pets.
- Avoid contact with skin and eyes. In case of contact, rinse thoroughly with water.
- Do not ingest. If swallowed, seek immediate medical attention and show the product container or label.
- Do not use near open flames or heat sources.
- Store in a cool, dry place.
- Ensure proper ventilation when in use.

PACKAGE CONTENTS

Your Air Wick Essential Mist Refill package contains:

- 1 x Air Wick Essential Mist Refill (Lavender and Almond Blossom scent)

Note: The Air Wick Essential Mist diffuser and AA batteries are sold separately.

SETUP INSTRUCTIONS

1. **Prepare the Diffuser:** Twist to remove the base cover of your Air Wick Essential Mist diffuser. Insert

3 AA batteries into the designated compartment.




Image: Twist to remove the base cover and insert 3 AA batteries into the diffuser.

- 2. Insert the Refill:** Remove the cap from the Air Wick Essential Mist Refill bottle. Firmly push the refill bottle upright into the diffuser until you hear a click, ensuring it is securely seated.



Image: Remove the refill cap and firmly push the refill bottle into the diffuser until it clicks.

- 3. Reassemble the Diffuser:** Replace the base cover back onto the device, twisting it until it is secure.



Image: Replace the base cover onto the diffuser.

Setup Video Guide

Your browser does not support the video tag.

Video: A visual guide demonstrating how to set up the Air Wick Essential Mist diffuser and insert the refill.

OPERATING INSTRUCTIONS

- 1. Turn On and Select Intensity:** Turn on the device using the slider switch located on the base. A blue light will flash at the nozzle, indicating it is active. Select your desired fragrance intensity (Low, Medium, or High) using the same slider.



Image: Turn on the device with the slider and select the intensity setting.

2. Fragrance Intensity Settings:

- **Low:** 4-second mist puff, 17-minute pause.
- **Medium:** 5-second mist puff, 12-minute pause.
- **High:** 6-second mist puff, 10-minute pause.



Image: Detailed view of the fragrance control settings.

3. **Automatic Cycle:** The device operates on an 8-hour cycle, emitting bursts of fragrance at regular intervals based on your selected intensity. After 8 hours, it automatically goes into standby mode for 16 hours until the next day.



Image: The diffuser's 8-hour operational cycle followed by a 16-hour standby period.

MAINTENANCE

- **Replacing Refills:** When the fragrance runs out (typically up to 45 days on a low setting), follow the "Setup Instructions" to replace the empty refill bottle with a new one. Ensure the device is turned off before replacing.
- **Battery Replacement:** When the device no longer mists or the blue light does not activate, it may be time to replace the 3 AA batteries. Follow the initial setup steps to access the battery compartment and replace old batteries with new ones.
- **Cleaning:** Periodically wipe the exterior of the diffuser with a soft, dry cloth to remove dust. Do not immerse the device in water or use harsh cleaning agents.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not misting / No blue light	Batteries are depleted or incorrectly inserted.	Check battery orientation and replace with fresh AA batteries if needed. Ensure the device is switched ON.
No fragrance detected	Refill is empty or not properly seated.	Replace the refill bottle. Ensure the refill is pushed firmly into the diffuser until it clicks. Adjust intensity setting to a higher level if desired.
Device not turning off after 8 hours	This is normal operation. The device has an 8-hour active cycle followed by a 16-hour standby period.	No action required. The device will automatically resume its cycle after 16 hours.

SPECIFICATIONS

- **Product Dimensions:** 1.38 x 2.95 x 6.3 inches
- **Item Weight:** 3.17 ounces
- **Model Number:** 3237920
- **Scent Name:** Lavender & Almond Blossom
- **Runtime (per refill):** Up to 1080 hours (45 days on low setting)
- **Power Source:** Battery Powered (3 AA batteries, not included with refill)
- **Coverage:** Medium to Large Room
- **Automatic Shutoff:** No (operates on 8-hour cycle with 16-hour standby)

WARRANTY AND SUPPORT

Specific warranty information for the Air Wick Essential Mist Refill is not provided in the product details. For warranty claims or technical support regarding your Air Wick Essential Mist products, please refer to the manufacturer's official website or contact their customer service directly.