Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEYBLADE E1046

Beyblade Burst Evolution Single Top Valtryek V2 Instruction Manual

Model: E1046
Brand: BEYBLADE (by Hasbro)

1. About Your Beyblade Burst Evolution Valtryek V2 Top

The Beyblade Burst Evolution Valtryek V2 is a right-spin battling top designed for competitive play, inspired by Season 2 of the Beyblade Burst animation. This top features components that can 'burst' into pieces during battle, awarding points to the opponent. It is engineered for balance, offering a versatile performance in the Beystadium.

2. What's Included

- 1x Beyblade Burst Evolution Valtryek V2 Top, consisting of:
  - Energy Layer: Valtryek V2 (aka Victory Valtryek)
  - Forge Disc: D04 (aka Limited)
  - Performance Tip: TB03 (aka Unite)
- Instruction Manual

Please note: A Beyblade Burst right-spin launcher and a Beyblade Burst Beystadium are required for play and are sold separately.

3. Setup and Assembly

The Beyblade Burst Valtryek V2 top comes in three main interchangeable parts. Follow these steps to assemble your top:

1. **Align the Energy Layer and Forge Disc:** Take the Valtryek V2 Energy Layer and the D04 Forge Disc. Align the tabs on the Energy Layer with the corresponding slots on the Forge Disc.
2. **Attach the Performance Tip:** Once the Energy Layer and Forge Disc are aligned, take the TB03 Performance Tip. Insert the Performance Tip into the bottom of the assembled Energy Layer and Forge Disc. Twist the Performance Tip clockwise until it clicks securely into place.
3. **Verify Assembly:** Gently pull on each component to ensure they are firmly connected. A properly assembled top will not easily separate.



EDAD 8+
IDADE
E1046/B9500 ASST.

Ask a parent first. • Demander d'abord à un parent.
Pregunta a tus padres primero. • Pedir aos pais antes.

BEYBLADE BURST EVOLUTION

VALTRYEK™ V

D04 / TB03

Fantasy scene. Burst rates vary.
Scène fictive. Les taux d'éclatement varient.
Escena ficticia. La frecuencia de separación varía.
Imagens fictícias. A frequência de desmontagens varia.

Requires BEYBLADE BURST™ right-spin launcher and BEYBLADE BURST Beystadium™, sold separately. Subject to availability.

Utiliser avec les propulseurs BEYBLADE BURST à rotation droite et l'arène Beystadium™ BEYBLADE BURST, vendus séparément. Selon les stocks.

Requiere lanzador de rotación derecha BEYBLADE BURST y arena Beystadium™ BEYBLADE BURST que se venden por separado. Sujeto a disponibilidad.

Requer um lançador BEYBLADE BURST de giro à direita e uma arena Beystadium™ BEYBLADE BURST. Vendidos separadamente. Sujeitos à disponibilidade.

• LES TOUPIES DE PERFORMANCE • TOPS DE ALTO RENDIMIENTO • PIÕES DE ALTO DESEMPENHO

RFORMANCE TOP SYSTEM™ •

Hasbro



Figure 3.1: Beyblade Burst Evolution Valtryek V2 components as seen in packaging. The top consists of three main parts: the Energy Layer (top), Forge Disc (middle), and Performance Tip (bottom).



Figure 3.2: Fully assembled Beyblade Burst Evolution Valtryek V2 top, ready for battle.

4. Operating Instructions

To engage in a Beyblade Burst battle, you will need your assembled Valtryek V2 top, a Beyblade Burst right-spin launcher, and a Beyblade Burst Beystadium.

1. **Attach to Launcher:** Securely attach your assembled Valtryek V2 top to a Beyblade Burst right-spin launcher (sold separately). Ensure the top is firmly clicked into the launcher.
2. **Position in Beystadium:** Hold the launcher over a Beyblade Burst Beystadium (sold separately). Aim the top towards the

center of the stadium.

3. **Launch:** Pull the ripcord of the launcher with a swift, strong motion. The top will detach and spin rapidly within the Beystadium.
4. **Battle Objective:** The goal is to defeat your opponent's top by out-spinning it, knocking it out of the Beystadium, or causing it to 'burst' into its component pieces. The first player to score 3 points wins the battle.

The 'burst' mechanism is a key feature of Beyblade Burst tops. When a top bursts, the opponent earns 2 points. Burst rates can vary depending on the tops involved and the intensity of the battle.

5. Maintenance

Proper care will extend the life of your Beyblade Burst top:

- **Cleaning:** After play, wipe down the top and its components with a clean, dry cloth to remove dust and debris. Do not use water or cleaning solutions, as this may damage the plastic or metal parts.
- **Storage:** Store your Beyblade Burst top and its components in a cool, dry place, away from direct sunlight or extreme temperatures.
- **Handling:** Avoid dropping the top or subjecting it to excessive force, which can cause damage to the components or the bursting mechanism.

6. Troubleshooting

- **Top not spinning effectively:**
  - Ensure all three components (Energy Layer, Forge Disc, Performance Tip) are securely assembled and locked into place.
  - Verify that your Beyblade Burst right-spin launcher is functioning correctly.
  - Ensure the ripcord is pulled with sufficient force and a smooth motion.
- **Top bursting too easily:**
  - While bursting is a designed feature of Beyblade Burst tops, excessive or unintended bursting might indicate loose assembly. Re-check component connections.
  - Burst rates can vary based on battle conditions, the type of opponent top, and the impact points during collisions.

7. Specifications

Attribute	Detail
Product Name	Beyblade Burst Evolution Single Top Valtryek V2
Model Number	E1046
Type	Right-Spin Balance Type Battling Top
Manufacturer	Hasbro
Product Dimensions	1.18 x 3.5 x 7.76 inches
Item Weight	1.06 ounces
Recommended Age	8 years and up
Release Date	September 11, 2017

8. Safety Information

Please read and adhere to the following safety guidelines:

- **WARNING: CHOKING HAZARD – Small parts.** Not for children under 3 years.
- Recommended for ages 8 and up.
- Use only official Beyblade Burst tops, launchers, and Beystadiums. Do not use custom or modified parts.
- Do not lean over the Beystadium when tops are in play.
- Do not launch tops on tables or other elevated surfaces, as they may bounce up and strike eyes or face.
- Always play in a clear, open area to avoid injury or damage to property.

9. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please visit the official Hasbro or Beyblade website, or contact their customer service department. Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2024 Hasbro. All Rights Reserved. BEYBLADE and all related terms are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075K53NHP

More documents and user manuals: **https://manuals.plus/**