TELESIN GP-MNP-270

TELESIN Ultra Long Selfie Stick (Model GP-MNP-270) Instruction Manual

Brand: TELESIN | Model: GP-MNP-270

1. Introduction

The TELESIN Ultra Long Selfie Stick is designed for capturing wide-angle and elevated shots in various activities such as group photos, travel, and sports. Its extended length allows for unique perspectives, including "invisible" selfie stick effects with compatible 360 cameras.

Key Features:

- **Ultra-Long Extension:** Extends up to 106 inches (2.7 meters) for expansive shots.
- **Lightweight Carbon Fiber:** Constructed from upgraded carbon fiber for stability and reduced weight.
- **Multiple Length Settings:** Features more than 6 adjustable lengths, including 15.75", 37.4", 49.2", 70.86", 80.7", and 106".
- **Universal Compatibility:** Compatible with GoPro Max, Hero series (10/9/8/7/6/5/4/3+/3/2/1/Session Fusion), Mi Sphere 360, Insta360 ONE X/One R Twin Edition, DJI OSMO ACTION, and most mini sports cameras.
- **Universal Tripod Mount:** The base includes a 1/4-inch universal tripod mount for attaching to a tripod.
- **360° Rotation:** Allows for multi-angle capture of moments.

2. What's in the Box

- TELESIN Ultra Long Selfie Stick (Carbon Fiber)
- Long Screw (for camera attachment)

3. Setup

3.1 Extending and Collapsing the Selfie Stick

The selfie stick features multiple telescopic sections. To extend, gently pull each section outwards until it reaches the desired length. The sections are designed to hold their position through friction. To collapse, push each section back

inwards.




Figure 1: The selfie stick can be extended to various lengths, up to 106 inches.

For specific lengths, such as 47.2 inches (1.2 meters), move the EVA gasket to the top of the first section, pull out the last two sections (sixth and seventh), then fix the EVA gasket with the silver ring. This method helps secure intermediate lengths.

3.2 Attaching Your Camera

The top of the selfie stick is equipped with a standard mount for action cameras. Use the provided long screw to securely attach your compatible camera (e.g., GoPro, Insta360, DJI Osmo Action) to the mount.



Figure 2: Detailed view of the selfie stick's components, including the stainless steel camera mount.

The base of the selfie stick also features a universal 1/4-inch tripod mount, allowing you to attach it to a compatible camera or phone tripod stand for stationary use. For extended lengths, a stronger tripod is recommended for optimal stability.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the TELESIN Ultra Long Selfie Stick in use, showcasing its extension and compatibility with action cameras.

4. Operating Instructions

4.1 Capturing Wide-Angle and Elevated Shots

Extend the selfie stick to your desired length to capture broad scenes, group photos, or elevated perspectives. The carbon fiber construction provides stability for various shooting scenarios.



Figure 3: Examples of wide-angle and elevated shots achievable with the extended selfie stick.

4.2 Achieving "Invisible" Selfie Stick Effect

When used with compatible 360-degree action cameras (e.g., Insta360 ONE X, Insta360 One R Twin Edition), the slim design and carbon fiber material of the selfie stick allow it to be automatically removed from the 360-degree footage, creating an "invisible" effect that simulates drone-like shots.



Figure 4: Visual examples of the "invisible" selfie stick effect in various environments.

4.3 Multi-Angle Shooting

The camera mount allows for 360° rotation, enabling you to capture every wonderful moment from diverse angles. Adjust the camera's orientation as needed for your desired shot.



Figure 5: The selfie stick facilitates capturing high-altitude views and party photos.

5. Maintenance

To ensure the longevity and optimal performance of your TELESIN Ultra Long Selfie Stick, follow these maintenance guidelines:

- **Cleaning After Saltwater Use:** If the selfie stick is used in saltwater, it is crucial to wash it thoroughly with fresh water immediately afterward. This prevents salt particles from accumulating inside the pole, which can lead to corrosion and hinder smooth extension/retraction.
- **General Cleaning:** For general cleaning, wipe the stick with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the carbon fiber or surface finish.
- **Storage:** Store the selfie stick in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure it is fully collapsed and clean before storage.
- **Inspection:** Periodically inspect the stick for any signs of wear, damage, or loose components. Ensure all sections extend and retract smoothly.



Figure 6: The selfie stick is designed for use in various environments, including saltwater, with proper post-use cleaning.

6. Troubleshooting

- **Wobbling or Instability at Full Extension:** While the carbon fiber design enhances stability, extreme lengths may exhibit slight flex. Ensure all sections are fully extended and securely friction-locked. For stationary shots at maximum extension, consider using a robust tripod attached to the base.
- **Rattling Sound:** If the stick rattles when not fully extended, it may be due to internal sections not being completely pulled out or pushed in. Ensure all sections are either fully extended and locked by friction, or fully collapsed. This can help minimize noise, especially when recording audio.
- **Difficulty Extending/Retracting:** If sections are stiff, ensure no dirt or debris is lodged within the joints. Clean the stick as per maintenance instructions. Avoid forcing sections, as this can cause damage.
- **Broken or Damaged Parts:** In case of any breakage or damage, discontinue use. Contact TELESIN customer support for assistance or replacement parts. Do not attempt to repair damaged components if it compromises the structural integrity of the stick.

7. Specifications

Product Dimensions	22 x 1 x 1 inches (collapsed)
Item Weight	7.8 ounces (222 Grams)
Extended Length	Up to 106 inches (2.7 meters)
Folded Size	15.75 inches
Material	Upgraded Carbon Fiber
Mount Type	Universal 1/4-inch screw (top and bottom)

Compatibility	GoPro Max, Hero 10/9/8/7/6/5/4/3+/3/2/1/Session Fusion, Mi Sphere 360, Insta360 ONE X/One R Twin Edition, DJI OSMO ACTION, most mini sports cameras.
Model Number	GP-MNP-270
UPC	791280766235

8. Warranty and Support

For warranty information, technical support, or any inquiries regarding your TELESIN Ultra Long Selfie Stick, please refer to the official TELESIN website or contact their customer service directly. Keep your purchase receipt for warranty claims. You can visit the TELESIN Store on Amazon for more product information and support resources.

© 2024 TELESIN. All rights reserved. Information is subject to change without notice.