Hampton Bay 59120

Hampton Bay 59120 3-Light Glossy White LED Track Lighting Kit User Manual

Model: 59120

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Hampton Bay 59120 3-Light Glossy White LED Track Lighting Kit. This kit features three independently adjustable track heads, a glossy white finish, and includes energy-efficient LED bulbs. It is designed for indoor use and is fully dimmable with a compatible dimmer switch.

2. Safety Information

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or other hazards that could cause personal injury or property damage.

- Always disconnect power at the circuit breaker or fuse box before installing, servicing, or cleaning this product.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Use only the specified bulb type and wattage. This kit includes 50-Watt equivalent E26 R20 LED bulbs.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create safety hazards.

3. Package Contents

Carefully unpack your lighting kit and ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer service for assistance.

- 1x Track Lighting Bar with integrated canopy
- 3x Adjustable Track Heads
- 3x 50-Watt equivalent E26 R20 LED Bulbs
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Instruction Manual

4. Setup and Installation

This track lighting kit is designed for semi-flush mount installation on a ceiling. All necessary mounting hardware is included for a quick and easy setup.

4.1 Preparation

1. Turn off power at the circuit breaker or fuse box to the outlet box where the fixture will be installed.
2. Remove the existing fixture (if any) and its mounting hardware.
3. Ensure the ceiling outlet box is securely mounted and capable of supporting the fixture's weight.

4.2 Mounting the Fixture

1. Attach the mounting bracket to the ceiling outlet box using the provided screws. Ensure the bracket is firmly secured.
2. Connect the electrical wires:
    - Connect the bare copper ground wire from the fixture to the ground wire from the outlet box using a wire nut.
    - Connect the white (neutral) wire from the fixture to the white (neutral) wire from the outlet box using a wire nut.
    - Connect the black (hot) wire from the fixture to the black (hot) wire from the outlet box using a wire nut.

    Ensure all wire connections are secure and properly insulated.
3. Carefully tuck the wires into the outlet box.
4. Align the fixture's canopy with the mounting bracket and secure it with the provided screws.



Figure 1: Close-up of the mounting canopy and an adjustable track head, showing the connection point to the track bar.

4.3 Installing Bulbs and Adjusting Heads

1. Screw the included 50-Watt equivalent E26 R20 LED bulbs into each of the three track heads. Do not overtighten.
2. The track heads are independently adjustable. Gently pivot and rotate each head to direct light to your desired area.



Figure 2: The Hampton Bay track lighting kit with bulbs installed (left: unlit, right: lit). Each head can be adjusted to focus light.



Figure 3: Examples of the track lighting kit installed, demonstrating its ability to direct light in various settings.

5. Operating Instructions

Once installed and power is restored, your Hampton Bay track lighting kit is ready for use.

- **Power On/Off:** Use your standard wall switch to turn the fixture on or off.
- **Dimming Function:** This fixture is fully dimmable. If connected to a compatible dimmer switch (sold separately), you can adjust the light output to create the desired ambiance. Refer to your dimmer switch's instructions for specific operation.
- **Adjusting Light Direction:** The three track heads can be independently rotated and tilted to direct light precisely where needed. Gently hold the base of the track head and adjust its position.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your lighting fixture.

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** The included LED bulbs are long-lasting. When replacement is eventually needed, ensure power is off. Allow bulbs to cool before handling. Replace with E26 R20 LED bulbs of equivalent wattage (max 50-Watt equivalent).

7. Troubleshooting

If you experience issues with your track lighting kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb.	Check circuit breaker or fuse. Verify all wire connections are secure (ensure power is off first). Replace bulb with a known good one.
Light flickers or dims improperly.	Incompatible dimmer switch. Loose wire connections. Faulty bulb.	Ensure dimmer switch is compatible with LED lighting. Check wire connections (ensure power is off first). Replace bulb.
Fixture hums.	Incompatible dimmer switch.	Replace dimmer switch with a high-quality, LED-compatible model.

If the problem persists after trying these solutions, contact a qualified electrician or customer support.

8. Specifications

Brand	Hampton Bay
Model Number	59120
Color	Glossy White
Style	Classic
Light Fixture Form	Track Lighting
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Installation Type	Semi Flush Mount
Special Feature	Dimmable
Light Source Type	LED
Finish Type	White Finish
Shade Material	Metal
Number of Light Sources	3
Bulb Base	E26
Wattage (per bulb)	50-Watt equivalent (LED)
Item Weight	3.6 Pounds

Package Dimensions	22.5 x 8 x 5.5 inches
UPC	058219591208

9. Warranty and Support

This Hampton Bay product is manufactured to high-quality standards and is backed by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical assistance, replacement parts, or general inquiries, please contact Hampton Bay customer support.
For the most up-to-date support information, visit the official Hampton Bay website or refer to your purchase documentation.

© 2023 Hampton Bay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question