Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hampton Bay HD38989SD

Hampton Bay Low-Voltage 2.7-Watt Sand Outdoor Integrated LED Landscape Modern Down Light Path Light User Manual

Model: HD38989SD

Introduction

This manual provides essential instructions for the safe installation, operation, and maintenance of your Hampton Bay Low-Voltage 2.7-Watt Sand Outdoor Integrated LED Landscape Modern Down Light Path Light. Please read this manual thoroughly before installation and retain it for future reference.

Safety Information

- **CAUTION:** Only for use with low voltage lighting power units with a maximum output rating of 15V, 300W per secondary. Exceeding these limits can damage the fixture and pose a safety risk.
- Ensure the power supply is disconnected before installation, maintenance, or cleaning.
- This product is designed for outdoor use and is water resistant. However, avoid submerging the fixture in water.
- Do not attempt to modify or disassemble the integrated LED light source. It is not user-serviceable.
- Keep children and pets away from the installation area.
- If you are unsure about any part of the installation process, consult a qualified electrician.

Package Contents

Verify that all components are present before beginning installation:

- 1x Hampton Bay Low-Voltage LED Path Light (Model HD38989SD)
- 1x Easy-Clip Connector
- 1x 12-inch Wire Lead
- 1x Ground Stake (pre-attached or separate, for stake mount)



Image: Front view of the Hampton Bay LED Pathway Light product box, showing the light fixture and branding.

Setup and Installation

This path light is designed for easy installation with a low-voltage landscape lighting system. Assembly is required.

1. **Plan Layout:** Determine the desired location for your path light. Ensure it is within reach of your low-voltage power unit's main cable.
2. **Assemble Fixture:** If the ground stake is not pre-attached, securely fasten it to the base of the light fixture.
3. **Position Fixture:** Gently push the ground stake into the soil at your chosen location. Ensure the fixture is stable and upright.
4. **Connect to Main Cable:** Locate the 12-inch wire lead extending from the path light. Use the provided easy-clip connector to attach the light's wire lead to the main low-voltage landscape cable. Ensure a secure connection by following the connector's instructions. The easy-clip connector pierces the main cable insulation to make contact.
5. **Test:** Once all connections are made, turn on your low-voltage power unit to test the light. If the light does not illuminate, check all connections and ensure the power unit is functioning correctly.






Image: Back view of the Hampton Bay LED Pathway Light product box, illustrating dimensions, easy-clip connector, and light pattern.

Operating Instructions

The Hampton Bay Low-Voltage LED Path Light operates as part of your existing low-voltage landscape lighting system. It does not have an independent switch or control mechanism.

- **Power On/Off:** The light will turn on and off with your low-voltage power unit. Control the light's operation using the timer, photocell, or manual switch on your power unit.
- **Light Output:** The integrated LED provides a warm white light at 135 lumens. No adjustments to brightness or color temperature are available on the fixture itself.

Maintenance

Regular maintenance ensures optimal performance and longevity of your path light.

- **Cleaning:** Periodically wipe the fixture with a soft, damp cloth to remove dirt, dust, and debris. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Inspection:** Annually inspect the wiring and connections for any signs of damage, corrosion, or loose connections. Ensure the ground stake remains firmly in place.
- **LED Module:** The LED light source is integrated and designed for long-term use. It is not replaceable. Do not attempt to open the sealed LED module.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Light does not turn on.	No power to the low-voltage system. Loose or incorrect wire connection. Faulty low-voltage power unit. Damaged fixture.	Check if the low-voltage power unit is plugged in and turned on. Verify its timer/photocell settings. Inspect the easy-clip connector for a secure connection to the main cable. Re-clip if necessary. Test other lights on the same system. If none work, the power unit may be faulty. If all other steps fail, the fixture may be damaged. Contact customer support.
Light flickers or is dim.	Insufficient power from the transformer. Loose connection. Too many lights on the circuit.	Ensure your low-voltage power unit has sufficient wattage for all connected lights. Check the easy-clip connector for a secure connection. Reduce the number of lights on the circuit or upgrade to a higher wattage power unit.

Specifications

Brand	Hampton Bay
Model Number	HD38989SD
UPC	627442083592
Type	Low-Voltage Integrated LED Path Light
Wattage	2.7 Watts
Brightness	135 Lumens
Efficiency	50 Lumens per Watt
Light Color	Warm White (2800K-3200K)
Voltage	10V (Max 15V input from power unit)
Material	Metal
Finish	Sand
Dimensions (H x W x L)	20.7 in x 6.5 in x 5.1 in (52.5 cm x 16.5 cm x 12.9 cm)
Item Weight	1.35 lbs (0.61 kg)
Installation Type	Stake Mount (Floor Mount/Pole Mount)
Connectivity	Wired (Low-Voltage)
Water Resistance	Water Resistant
Assembly Required	Yes

Warranty and Support

This Hampton Bay product is backed by a **5-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical assistance, or replacement parts, please contact Hampton Bay Customer Service. You may need your proof of purchase and the product model number (HD38989SD).
Contact Information: Refer to the contact details provided with your product packaging or visit the official Hampton Bay website for the most current support information.

© 2023 Hampton Bay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075L4KCTD

More documents and user manuals: **https://manuals.plus/**