



[Manuals.plus](#) /

> [Calor](#) /

> Calor GV9560C0 Pro Express Ultimate High-Pressure Steam Iron Station User Manual

Calor GV9560C0

Calor GV9560C0 Pro Express Ultimate High-Pressure Steam Iron Station User Manual

Model: GV9560C0 | Brand: Calor

1. INTRODUCTION

Welcome to the user manual for your new Calor Pro Express Ultimate High-Pressure Steam Iron Station. This appliance is designed to provide professional-grade steam performance for efficient and effective garment care. Please read this manual thoroughly before first use to ensure safe operation and optimal results. Keep this manual for future reference.



Image 1.1: The Calor Pro Express Ultimate High-Pressure Steam Iron Station, showcasing its compact design and purple accents.

2. SAFETY INSTRUCTIONS

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

2.1 General Safety

- Do not leave the appliance unattended when it is connected to the mains supply.
- Keep the appliance out of reach of children and persons with reduced physical, sensory or mental capabilities.
- Never direct steam at people or animals.
- Use the iron only for its intended purpose, which is ironing clothes.
- Always place the iron on a stable, heat-resistant surface.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.

2.2 Electrical Safety

- Ensure the voltage indicated on the appliance corresponds to your mains supply voltage.
- Do not use the appliance if the power cord or plug is damaged.
- Unplug the appliance from the mains socket before filling the water tank, cleaning, or after each use.
- Do not pull the cord to disconnect the plug from the socket. Grasp the plug itself.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your steam iron station.

3.1 Main Components

- **Iron:** Features the Durilium Airglide Autoclean soleplate.
- **Steam Generator Base:** Houses the water tank and heating element.
- **Removable Water Tank:** For easy filling and emptying.
- **Control Panel:** With mode selection and indicator lights.
- **Steam Cord:** Connects the iron to the base.
- **Power Cord:** For connecting to the mains supply.
- **Anti-Calc Collector:** For easy maintenance and descaling.



Image 3.1: Rear view of the steam station, showing the control panel and various settings.

CONTRÔLE INTUITIF



Image 3.2: Detailed view of the intuitive control panel, allowing selection of different ironing modes.





Image 3.3: The Durilium Airglide Autoclean soleplate, designed for smooth gliding and easy maintenance.

4. SETUP

4.1 Unpacking

Carefully remove all packaging materials and stickers from the appliance. Retain the packaging for storage or future transport if needed.

4.2 Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Remove the removable water tank from the base unit.
3. Fill the tank with clean tap water up to the 'MAX' level indicator. Do not use distilled or demineralized water exclusively, as it can affect steam performance over time. A mix of tap water and distilled water (50/50) is recommended in areas with very hard water.
4. Replace the water tank securely into the base unit.



Image 4.1: Demonstrating the process of filling the removable water tank under a faucet.

4.3 Initial Use

1. Place the steam station on a stable, heat-resistant ironing board or surface.
2. Plug the power cord into a grounded electrical outlet.
3. Press the ON/OFF button. The indicator light will illuminate.
4. Allow the appliance to heat up. This usually takes a few minutes. The steam ready indicator light will turn solid when ready.
5. For first use, or if the iron has not been used for a long time, press the steam trigger several times over an old cloth to clear any residue from the steam channels.

5. OPERATING INSTRUCTIONS

5.1 Selecting Ironing Mode

The Pro Express Ultimate features various modes for different fabric types:

- **Eco Mode:** Reduces energy consumption while providing efficient steam. Suitable for most fabrics.

- **Delicate Mode:** Lower temperature and steam output for delicate fabrics like silk and synthetics.
- **Normal Mode:** Standard setting for everyday ironing.
- **Max Mode:** Maximum steam and temperature for stubborn creases and thick fabrics like denim.
- **Boost Function:** Provides an extra burst of steam for very tough creases. Press the steam trigger fully.

Use the 'MODE' button on the control panel to cycle through the available settings.

5.2 Ironing with Steam

1. Select the appropriate ironing mode for your fabric.
2. Place the garment on the ironing board.
3. Press the steam trigger on the iron handle to release steam as you iron.
4. Move the iron smoothly over the fabric.

EFFICACITÉ PROFESSIONNELLE



Image 5.1: The iron in use, demonstrating its professional steaming capability on a shirt.

5.3 Vertical Steaming

The appliance can also be used for vertical steaming of hanging garments, curtains, or drapes.

1. Hang the garment on a hanger.
2. Select a suitable steam mode.
3. Hold the iron vertically a few centimeters away from the fabric.
4. Press the steam trigger and move the iron up and down over the fabric.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your steam iron station.

6.1 Cleaning the Soleplate

The Durilium Airglide Autoclean soleplate is designed to stay clean. If necessary, clean it with a damp cloth or a non-abrasive cleaning stick specifically designed for iron soleplates. Do not use abrasive pads or metallic objects.

6.2 Descaling (Anti-Calc System)

The Anti-Calc collector helps prevent limescale buildup. It is recommended to clean the collector regularly, depending on the hardness of your water and frequency of use. The appliance may indicate when descaling is needed.

1. Ensure the appliance is unplugged and completely cool.
2. Locate the Anti-Calc collector on the side of the base unit.
3. Unscrew and remove the collector.
4. Rinse the collector under running water to remove any limescale deposits.
5. Screw the collector back into place securely.

SYSTÈME ANTI-CALC



Image 6.1: Illustration of removing the Anti-Calc collector for cleaning and descaling.

6.3 Storage

After use, unplug the appliance and allow it to cool down completely. Empty any remaining water from the tank. Secure the iron to its base using the locking system (if available). Store the appliance in a dry, safe place, out of reach of children.

TRANSPORT SÉCURISÉ



Image 6.2: The steam station is designed for secure transport, making it easy to move and store.

7. TROUBLESHOOTING

If you encounter any issues with your steam iron station, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty. Appliance not heated up. Steam trigger not pressed.	Fill the water tank. Wait for the steam ready indicator light. Press the steam trigger.
Water drips from the soleplate.	Temperature is too low for steam. Iron used horizontally for too long without steam.	Allow the iron to heat up fully. Ensure the correct mode is selected for the fabric.

Problem	Possible Cause	Solution
Limescale particles appear on clothes.	Anti-Calc collector needs cleaning.	Clean the Anti-Calc collector as described in the Maintenance section.
Appliance does not turn on.	Not plugged in. Power outlet issue.	Check power cord connection. Test the outlet with another appliance.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Technical details for the Calor GV9560C0 Pro Express Ultimate Steam Iron Station.

Model Number: GV9560C0

Brand: Calor

Power: 2600 Watts

Voltage: 220V

Water Tank Capacity: 1.9 Liters

Continuous Steam Output: Up to 140 g/min

Steam Boost: Up to 490 g/min

Soleplate Technology: Durilium Airglide Autoclean

Dimensions (L x W x H): Approximately 42.3 x 28.9 x 0.1 cm

Weight: 5.1 kg

Special Features: Anti-Calc Function, High-Pressure Technology

Color: White, Purple




Image 8.1: Diagram showing the dimensions of the iron soleplate (42.3 cm length, 28.9 cm width).

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your Calor Pro Express Ultimate Steam Iron Station is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. Keep your proof of purchase for warranty claims.

9.2 Repairability

Calor is committed to making products repairable. This product is designed to be repairable at a fair price for 15 years. There are over 6200 approved repairers worldwide.



Image 9.1: The "Repairable at Fair Price for 15 Years" logo, highlighting Calor's commitment to product longevity and repair support.

9.3 Customer Support

For technical assistance, spare parts, or service, please contact Calor customer support. Contact information can typically be found on the Calor official website or on the product packaging.

You can also visit the official Calor website for FAQs and additional resources www.calor.fr

