

[Manuals.plus](#) /

› [Moen](#) /

› Moen Graeden Spot Resist Brushed Nickel 2-handle 4-in Centerset Bathroom Faucet User Manual

Moen 84137SRN

Moen Graeden Spot Resist Brushed Nickel 2-handle 4-in Centerset Bathroom Faucet User Manual

Model: 84137SRN

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Moen Graeden Spot Resist Brushed Nickel 2-handle 4-in Centerset Bathroom Faucet, Model 84137SRN. Please read these instructions carefully before beginning installation or use to ensure proper function and longevity of your product.



Image: The Moen Graeden 2-handle centerset bathroom faucet in Spot Resist Brushed Nickel finish.

SETUP AND INSTALLATION

The Moen Graeden faucet is designed for a 3-hole installation on a bathroom sink deck. Ensure your sink configuration matches this requirement before proceeding. The maximum recommended deck thickness is 1.19 inches, and the connection size is 3/8 inch.

Pre-Installation Steps:

1. Turn off the main water supply to your bathroom.
2. Clear the area under the sink for easy access.
3. Gather all necessary tools, which typically include an adjustable wrench, plumber's putty or silicone sealant, and a screwdriver.

Installation Procedure:

1. Position the faucet body onto the sink deck, ensuring the handles align correctly with the hot and cold water inlets.

2. Secure the faucet from underneath the sink using the provided mounting hardware. Tighten nuts evenly to prevent tilting.
3. Connect the hot and cold water supply lines to the corresponding inlets on the faucet. Use an adjustable wrench to tighten connections, being careful not to overtighten.
4. Install the drain assembly according to the manufacturer's instructions, applying plumber's putty or silicone sealant as required to ensure a watertight seal.
5. Once all connections are secure, slowly turn on the main water supply and check for leaks.
6. Run water through the faucet for a few minutes to flush out any debris from the lines.





Image: Dimensional diagram of the Moen Graeden faucet, illustrating key measurements for installation.

Will this faucet fit my sink?

This faucet fits a three hole configuration.



MOEN®

Image: A top-down view of a sink basin showing the standard three-hole configuration required for this faucet.

OPERATING INSTRUCTIONS

Your Moen Graeden faucet features two lever handles for precise control over water temperature and flow.

- **Cold Water:** Rotate the right lever handle counter-clockwise to activate cold water.
- **Hot Water:** Rotate the left lever handle counter-clockwise to activate hot water.
- **Temperature Control:** Adjust the mix of hot and cold water by positioning both handles to achieve your desired temperature.
- **Flow Control:** The further you rotate the handles, the greater the water flow. Return the handles to the off position to stop water flow.



Image: The Moen Graeden faucet in operation, demonstrating water flow.

MAINTENANCE

Regular cleaning and maintenance will help preserve the finish and functionality of your Moen Graeden faucet.

Cleaning the Finish:

- The Spot Resist Brushed Nickel finish is designed to resist fingerprints and water spots.
- Clean the faucet with a soft, damp cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish and void the warranty.
- Rinse thoroughly with clean water and dry with a soft cloth to maintain its luster.

General Maintenance:

- Periodically check all connections under the sink for any signs of leaks. Tighten if necessary, but do not overtighten.
- If water flow decreases, the aerator at the end of the spout may be clogged. Unscrew the aerator, clean any debris, and reattach.



Image: A detailed view of the Moen Graeden faucet, highlighting its Spot Resist Brushed Nickel finish.

TROUBLESHOOTING

Refer to the following common issues and solutions before contacting customer support.

Problem	Possible Cause	Solution
Faucet leaks from spout or handles	Loose connections, worn cartridge, damaged O-rings.	Check and tighten water supply line connections. If leaking persists, the internal cartridge or O-rings may need replacement. Contact Moen support for parts.
Low water flow	Clogged aerator, partially closed shut-off valves, debris in water lines.	Unscrew and clean the aerator. Ensure hot and cold shut-off valves under the sink are fully open. Flush water lines if debris is suspected.
Water temperature inconsistent	Improper cartridge installation, issues with water heater.	Verify cartridge is installed correctly. Check your water heater settings and functionality.

SPECIFICATIONS

- **Model Number:** 84137SRN
- **Brand:** Moen
- **Product Dimensions:** 6.63 x 9.5 x 5.94 inches
- **Item Weight:** 4.21 Pounds
- **Mounting Type:** Deck Mount

- **Finish Type:** Nickel
- **Color:** Spot Resist Brushed Nickel
- **Number of Handles:** 2
- **Hole Count:** 3
- **Installation Type:** Centerset
- **Recommended Uses:** Bathroom

WARRANTY INFORMATION

The Moen Graeden Spot Resist Brushed Nickel 2-handle 4-in Centerset Bathroom Faucet is backed by Moen's Limited Lifetime Warranty. This warranty covers defects in material and manufacturing workmanship for the original consumer purchaser. For complete details regarding warranty coverage, terms, and conditions, please refer to the official Moen website or contact Moen customer service.

SUPPORT

If you require further assistance, have questions not covered in this manual, or need to order replacement parts, please contact Moen customer support. Have your product model number (84137SRN) and purchase date available when you call or email.

For the most current contact information and support resources, please visit the official [Moen website](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B075LYPPKY>

More documents and user manuals: <https://manuals.plus/>