

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pure Enrichment](#) /
- › [Pure Enrichment HumeXL Ultrasonic Cool Mist Humidifier User Manual](#)

## Pure Enrichment PEHUMEXL

# Pure Enrichment HumeXL Ultrasonic Cool Mist Humidifier User Manual

Model: PEHUMEXL

## INTRODUCTION

---

The Pure Enrichment HumeXL Ultrasonic Cool Mist Humidifier is designed to enhance the air quality in your home or office by providing soothing moisture. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your humidifier.

Key features include a large 5-liter (1.3 gallon) water tank, touch-button controls for mist output, two independent 360° rotating mist nozzles, and an optional night mode.

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your HumeXL Humidifier before initial use.



**Image:** Exploded view showing the Humidifier Base, 5-Liter Water Tank, Water Tank Cap, and the Extra-Large Tank Opening for Easy Cleaning.

- **Humidifier Base:** Contains the ultrasonic transducer and control panel.
- **Water Tank:** 5-liter (1.3 gallon) capacity for extended operation. Features a large opening for easy cleaning.
- **Water Tank Cap:** Secures the water in the tank.
- **Dual Mist Nozzles:** Two independent nozzles that rotate 360° for customizable mist direction.
- **Control Panel:** Intuitive touch-buttons for power, mist settings, and night mode.

## SETUP

---

1. **Placement:** Place the HumeXL Humidifier on a flat, water-resistant surface. Ensure it is not placed directly on carpet or near heat sources.
2. **Fill Water Tank:**

- Lift the water tank from the base.
  - Unscrew the water tank cap.
  - Fill the tank with clean, cool tap water or distilled water. Do not use hot water.
  - Securely close the water tank cap.
3. **Assemble:** Place the filled water tank back onto the humidifier base, ensuring it is seated correctly.
  4. **Power On:** Plug the power cord into a standard 120V AC electrical outlet. The humidifier will beep once and enter standby mode.

## OPERATING INSTRUCTIONS

---

The HumeXL Humidifier features a touch-button control panel for easy operation.



**Image:** The HumeXL Humidifier actively emitting cool mist from its dual 360° rotating nozzles, illustrating wide coverage.

- **Power On/Off:** Press the power button ( ) to turn the unit on. Press it again to turn off the misting and enter standby mode.
- **Mist Output Control:**

- Press the Low Mist button ( ) to select the lowest mist setting.
- Press the High Mist button ( ) to select the highest mist setting.
- **Night Mode:** Press the Night Mode button (zZ) to dim the LED control panel lights and turn off the soft glow night light for undisturbed sleep.
- **Adjusting Mist Nozzles:** Manually rotate the two independent mist nozzles on top of the unit to direct the mist in any desired direction.



Safe, Whisper-Quiet  
Operation

GREAT FOR LIGHT SLEEPERS

**Image:** The HumeXL Humidifier positioned in a bedroom, highlighting its quiet operation suitable for sleeping environments.



**Image:** A close-up of the humidifier's base showing the soft glow night light feature, which can be turned off for night mode.

## MAINTENANCE

---

Regular cleaning is essential to maintain optimal performance and prevent mineral buildup.

### Daily Maintenance:

- Empty any remaining water from the tank and base.
- Rinse the water tank and base with clean water.
- Refill the tank with fresh, cool water before each use.

### Weekly Maintenance (Mineral Buildup Removal):

1. Unplug the humidifier and remove the water tank.
2. Pour 1 cup of white vinegar into the water tank and 1 cup into the water reservoir in the base.
3. Let it soak for at least 30 minutes.
4. Empty the vinegar and rinse thoroughly with clean water.
5. Use a soft brush or cloth to clean any mineral buildup.

6. Ensure all parts are dry before reassembling.

*Note: Do not use harsh chemicals or abrasive cleaners.*

## TROUBLESHOOTING

---

If you experience issues with your HumeXL Humidifier, please refer to the following common solutions:

Problem	Possible Cause	Solution
No mist or low mist output	Low water level; mineral buildup on transducer; unit not properly assembled.	Refill water tank; clean transducer with vinegar solution; ensure water tank is correctly seated.
Unusual odor	Stale water; dirty water tank/base.	Empty and clean water tank and base thoroughly; use fresh water.
White dust around humidifier	Hard water with high mineral content.	Use distilled or demineralized water. Clean the transducer regularly.
Unit not turning on	Not plugged in; power outage; water tank not properly seated.	Check power connection; verify power outlet; ensure water tank is correctly placed on the base.

## SPECIFICATIONS

---



**Image:** The HumeXL Humidifier with its dimensions clearly marked: 9 inches (width), 6 inches (depth), and 15 inches (height).

Feature	Detail
Size	8.9" (L) x 5.9" (W) x 14.4" (H)
Power Supply	120V, 60Hz, 27W
Max Room Coverage	Up to 270 sq. ft.

Feature	Detail
Max Run Time (High)	16 hours
Max Run Time (Low)	50 hours
Tank Capacity	5 Liters (1.3 Gallons)
Max Moisture Output (High)	≥300ml/h
Max Moisture Output (Low)	≥100ml/h
Noise Level	<35dB
Model Name	cool mist humidifier
Item Model Number	PEHUMEXL
UPC	817387020176

*\*Run time may vary depending on water quality, room temperature, and the amount of water in the tank.*

## WARRANTY AND SUPPORT

---

The Pure Enrichment HumeXL Ultrasonic Cool Mist Humidifier comes with an industry-leading 5-Year Manufacturer's Warranty.

For customer support, please contact Pure Enrichment directly. Caring customer support is available 7 days a week to assist with any questions or concerns.

Please refer to the official Pure Enrichment website or the contact information provided in your product packaging for the most up-to-date support details.