

## Magic CL-5800T

# Magic CL-5800T 6 LED Rechargeable Camping Lantern User Manual

Model: CL-5800T

## INTRODUCTION

Thank you for purchasing the Magic CL-5800T 6 LED Rechargeable Camping Lantern. This manual provides essential information for the safe and efficient use of your lantern. Please read it thoroughly before operation and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

- Do not expose the lantern to extreme temperatures or direct sunlight for extended periods.
- Keep the lantern away from water and moisture to prevent electrical shock or damage.
- Do not attempt to disassemble or modify the lantern. This will void the warranty and may cause injury.
- Use only the provided charging cable or a compatible charger.
- Keep out of reach of children.

## PACKAGE CONTENTS

Verify that all items are present in your package:

- Magic CL-5800T 6 LED Rechargeable Camping Lantern
- Charging Cable
- User Manual (this document)



Image: The Magic CL-5800T 6 LED Rechargeable Camping Lantern in blue, bronze, and gold colors, shown with its retail packaging and charging cable.

## SETUP

### Initial Charge

1. Before first use, fully charge the lantern.
2. Locate the charging port on the side of the lantern.
3. Connect the provided charging cable to the lantern's charging port.
4. Plug the other end of the charging cable into a compatible USB power source (e.g., wall adapter, computer USB port).
5. The charging indicator light (if present) will illuminate during charging and turn off or change color when fully charged.
6. A full charge typically takes 4-6 hours.

### Unpacking and Inspection

- Carefully remove the lantern from its packaging.
- Inspect the lantern for any visible damage. If damage is found, do not use the product and contact customer support.

## OPERATING INSTRUCTIONS

### Turning On/Off and Adjusting Brightness

1. To turn on the lantern, gently pull the top section upwards. The 6 LED lights will illuminate.
2. To adjust brightness, continue pulling the top section further upwards for brighter light, or push it downwards for dimmer light.
3. To turn off the lantern, fully push the top section back into the base until it clicks into place.



Image: A Magic CL-5800T lantern in its extended, illuminated state, demonstrating how to activate the light.

### Using the USB Output (Power Bank Function)

The lantern features a USB output port, allowing it to function as a power bank for charging small electronic devices.

1. Locate the USB output port on the top section of the lantern.
2. Connect your device's charging cable to the USB output port.
3. The lantern will begin charging your device. Note that using this feature will consume the lantern's battery power.

## MAINTENANCE

### Cleaning

- Wipe the exterior of the lantern with a soft, dry cloth.
- Do not use abrasive cleaners or solvents, as these may damage the finish.
- Ensure the charging port is free of dust and debris.

### Storage

- When not in use for extended periods, store the lantern in a cool, dry place.
- It is recommended to charge the lantern every 3-6 months to maintain battery health, even if not in use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lantern does not turn on.	Battery is depleted.	Charge the lantern fully.
Lantern does not turn on.	Top section not fully extended.	Ensure the top section is pulled upwards completely.
Device not charging from USB output.	Lantern battery is low.	Charge the lantern.
Device not charging from USB output.	Incorrect cable or device incompatibility.	Ensure you are using a compatible charging cable for your device.







## SPECIFICATIONS

- **Model:** CL-5800T
- **Light Source:** 6 LED
- **Power Source:** Rechargeable Battery
- **Features:** Portable, Rechargeable, USB Output (Power Bank Function)
- **ASIN:** B075M9B8ZC

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Related Documents - CL-5800T

	<p><a href="#">MAGIC Steam Air Fryer S05 User Manual</a></p> <p>Comprehensive user manual for the MAGIC Steam Air Fryer S05, detailing its features, functions, operation, safety precautions, and maintenance. Learn how to use the steam, air fry, and hybrid modes for healthy cooking.</p>
	<p><a href="#">MAGIC ECO S07 PRO Steam Air Fryer User Manual</a></p> <p>Comprehensive user manual for the MAGIC ECO S07 PRO Steam Air Fryer, covering product features, parts, important safeguards, preparation, operation, cooking guides, troubleshooting, and maintenance.</p>
	<p><a href="#">Magic A-53 Infrared Cooker User Manual</a></p> <p>User manual for the Magic A-53 Infrared Cooker, detailing product specifications, structure, instructions for use, and cleaning &amp; maintenance.</p>
	<p><a href="#">Magic A-52 Induction Cooker User Manual</a></p> <p>User manual for the Magic A-52 induction cooker, providing instructions for use, cleaning, maintenance, and troubleshooting.</p>
	<p><a href="#">Magic Combo Electrotherapy Device Instruction Manual</a></p> <p>This instruction manual provides comprehensive details on the Magic Combo Electrotherapy Device, covering its functions, safety precautions, operation, specifications, and maintenance. Learn how to use TENS, EMS, and Massage modes for pain relief and muscle stimulation.</p>
	<p><a href="#">Cẩm Nang Máy Hút Bụi Không Dây AC-400: Hướng Dẫn Sử Dụng và Tính Năng</a></p> <p>Khám phá chi tiết về máy hút bụi không dây AC-400, bao gồm các tình huống sử dụng lý tưởng, tính năng công nghệ tiên tiến, thông số kỹ thuật đầy đủ và các dịch vụ hậu mãi hấp dẫn.</p>