Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- ClearClick /
- > ClearClick Retro AM/FM Radio with Bluetooth Classic Wooden Vintage Retro Style Speaker User Manual

ClearClick AM/FM Retro Radio With Bluetooth

ClearClick Retro AM/FM Radio with Bluetooth

Model: AM/FM Retro Radio With Bluetooth
Brand: ClearClick

INTRODUCTION

Thank you for choosing the ClearClick Retro AM/FM Radio with Bluetooth. This classic wooden vintage-style speaker combines nostalgic aesthetics with modern functionality, allowing you to enjoy both traditional radio broadcasts and contemporary digital audio. This manual provides essential information for setting up, operating, and maintaining your new radio.

PRODUCT OVERVIEW



Figure 1: Front view of the ClearClick Retro AM/FM Radio, showcasing its classic wooden design and central tuning dial.



Figure 2: Close-up of the tuning dial and control knobs for FM/AM/BT selection and volume.

The ClearClick Retro Radio features a beautiful, handmade wooden exterior, an easy-to-use tuning dial, and dedicated knobs for mode selection and volume control. It is designed to be powered by a standard North American power plug.

SETUP

- 1. **Unpacking:** Carefully remove the radio from its packaging. Ensure all components, including the power cord, are present.
- 2. **Placement:** Place the radio on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture.
- 3. **Power Connection:** Insert the included power cord into the AC input on the back of the radio. Plug the other end into a standard North American wall outlet (120V AC, 60Hz).
- 4. **Antenna Setup:** For optimal FM reception, extend the built-in wire antenna fully. For AM reception, the radio utilizes an internal antenna; repositioning the radio may improve signal strength.

OPERATING INSTRUCTIONS

Power On/Off and Volume Control

- To power on the radio, rotate the right-side **VOLUME** knob clockwise until you hear a click.
- To adjust the volume, continue rotating the **VOLUME** knob.
- To power off, rotate the **VOLUME** knob counter-clockwise until it clicks off.

AM/FM Radio Operation

• Rotate the left-side FM AM BT knob to select either FM or AM mode.

- Turn the central TUNING knob to scan for radio stations. The tuning backlight will illuminate in AM/FM mode.
- Adjust the **TUNING** knob carefully for clear reception.

Bluetooth Operation

- Rotate the left-side FM AM BT knob to select BT mode. The radio will enter Bluetooth pairing mode, indicated by a blue LED.
- On your Bluetooth-enabled device (e.g., smartphone, tablet), search for available Bluetooth devices.
- Select "Vintage Radio" or "ClearClick Radio" from the list to pair.
- Once paired, the blue LED will remain solid, and you can play audio from your device through the radio.
- The radio's tuning backlight stays on even in Bluetooth mode (NEW 2019 feature).

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the radio. Do not use abrasive cleaners or solvents, as they may damage the wooden finish.
- **Storage:** When not in use for extended periods, store the radio in a cool, dry place, away from extreme temperatures and humidity.
- **Ventilation:** Ensure the radio has adequate ventilation to prevent overheating. Do not block the ventilation holes on the back.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active.	Ensure power cord is securely plugged into the radio and a working wall outlet. Check if the volume knob is turned on.
Poor radio reception	Weak signal; antenna not extended.	Fully extend the FM wire antenna. For AM, try repositioning the radio. Adjust the tuning knob slowly.
Bluetooth not connecting	Radio not in BT mode; device too far; device already paired.	Ensure radio is in BT mode. Move your device closer to the radio. Unpair "Vintage Radio" from your device's Bluetooth settings and try pairing again.
No sound from Bluetooth	Volume too low on radio or device.	Increase volume on both the radio and your connected Bluetooth device.

SPECIFICATIONS

• Product Dimensions: 10.5" (H) \times 8" (W) \times 6" (D)

• Item Weight: 4.74 pounds

Connectivity Technology: Bluetooth
 Tuner Technology: AM, FM (2-Band)

• Power Source: Corded Electric (Standard North American Power Plug)

• Included Components: Power Cord

- Water Resistance Level: Not Water Resistant
- **Display Technology:** LCD (for tuning dial backlight)



Figure 3: Side view illustrating the dimensions of the radio.

WARRANTY AND SUPPORT


The ClearClick Retro AM/FM Radio with Bluetooth comes with a **Full 5-Year Warranty**. ClearClick is a USA-Based Small Business committed to providing excellent customer support.

For warranty claims or technical assistance, please refer to the contact information provided with your product packaging or visit the official ClearClick website. Keep your purchase receipt for warranty validation.

IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions provided in the original product packaging. Do not expose the unit to rain or moisture. Do not disassemble the unit; refer all servicing to qualified personnel. Ensure proper ventilation to prevent overheating.

Related Documents - AM/FM Retro Radio With Bluetooth





ClearClick Mini Wireless HDMI Transmitter & Receiver Kit User Manual & Quick Start Guide

Comprehensive user manual and quick start guide for the ClearClick Mini Wireless HDMI Transmitter & Receiver Kit. Learn how to set up, connect, and troubleshoot your device for seamless wireless HD streaming.