

AW D28GHC001-AG-06

# AW Acoustic Guitar Case Instruction Manual

Model: D28GHC001-AG-06 | Brand: AW

## INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your AW Acoustic Guitar Hard Case. Designed for 41-inch acoustic guitars, this durable hardshell case offers robust protection and convenient portability for your instrument.



Image: The AW Acoustic Guitar Hard Case, shown both open with a guitar inside and closed with a key, highlighting its design and security features.

## PRODUCT FEATURES

- **Durable Construction:** Features hard plywood wrapped in PU leather for long-lasting toughness.
- **Protective Interior:** Molded foam interior lined with plush suede provides scratch resistance and shock absorption for your guitar.
- **Secure Latches:** Equipped with sturdy chrome locks and bumpers on the bottom and sides for enhanced protection against damage and intrusion.
- **Portable Design:** A comfortable molded handle ensures easy and convenient transportation.
- **Accessory Compartment:** An integrated compartment allows for secure storage of essential guitar accessories like picks, strings, or tuners.



Image: A comprehensive view detailing the various components of the guitar case, including the molded handle, chrome locks, protective metal feet, and the plush-lined interior with an accessory compartment.





Image: Close-up showing the padded neck support and the convenient storage cassette within the case's interior, designed to hold small accessories securely.

SPECIFICATIONS

Attribute	Detail
Item Weight	9.9 pounds
Product Dimensions (External)	43.3 x 18.3 x 6.3 inches
Item Model Number	D28GHC001-AG-06
Color	Black-PU
Compatibility	Designed for 41-inch acoustic guitars
Country of Origin	China



Image: Diagram illustrating the internal dimensions of the guitar case, ensuring a proper fit for acoustic guitars.







Image: Diagram illustrating the external dimensions of the guitar case, useful for transport and storage planning.

## USAGE INSTRUCTIONS

### 1. Opening and Closing the Case

1. Place the case on a flat, stable surface.
2. To open, unlock all chrome latches by pushing the release mechanism. If locked with a key, insert the key and turn to unlock.
3. Gently lift the lid of the case. The hinges are designed to hold the lid open for easy access.
4. To close, carefully lower the lid, ensuring it aligns with the base. Secure all latches firmly until they click into place. For added security, use the provided key to lock the main latch.

### 2. Placing Your Guitar

- Ensure the case interior is clean and free of debris.
- Carefully place your 41-inch acoustic guitar into the molded interior. The body should fit snugly into the main cavity, and the neck should rest securely on the padded neck support.
- Verify that the guitar is seated properly and does not shift excessively within the case.

### 3. Using the Accessory Compartment

- The accessory compartment is located under the neck support. Lift the flap to access it.
- Store small items such as picks, capos, strings, or tuners in this compartment.
- Ensure the flap is closed before closing the case to prevent items from moving around.

Your browser does not support the video tag.

Video: Demonstrates the portability, locking mechanism, and proper placement of a guitar within the AW Acoustic Guitar Hard Case.

## MAINTENANCE AND CARE

---

- **Exterior Cleaning:** Wipe the PU leather exterior with a soft, damp cloth to remove dust and dirt. Avoid harsh chemicals or abrasive cleaners.
- **Interior Cleaning:** Use a soft brush or vacuum cleaner with a brush attachment to gently clean the plush suede interior. Do not use wet cleaners on the interior.
- **Latch Maintenance:** Periodically check the chrome latches and hinges for any signs of wear or damage. Keep them clean and free of debris to ensure smooth operation.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures to preserve its materials and structural integrity.

## TROUBLESHOOTING

---

### Accessory Compartment Flap Does Not Stay Shut

If the flap covering the accessory compartment does not stay securely closed, ensure that no items are overfilling the compartment, which might prevent the flap from seating correctly. If the issue persists, small, soft items can be placed on top of the flap to help keep it down, or consider using a small piece of hook-and-loop fastener if a permanent solution is desired.

### Latches Are Stiff or Difficult to Close

Check for any foreign objects or debris obstructing the latch mechanism. Clean the latches with a dry cloth. If stiffness continues, a small amount of silicone-based lubricant can be applied to the moving parts of the latch, ensuring not to get any on the case's exterior or interior fabric.

## WARRANTY AND SUPPORT

---

For any questions regarding your AW Acoustic Guitar Case, or for support and warranty information, please visit the official AW store or contact their customer service. Keep your purchase receipt for any warranty claims.

You can find more information and contact details by visiting the [AW Store on Amazon](#).