

[manuals.plus](#) /

› [Keter](#) /

› [Keter WonderFold Children's Folding Playhouse User Manual](#)

Keter 232042

Keter WonderFold Children's Folding Playhouse User Manual

Model: 232042

1. INTRODUCTION

Thank you for choosing the Keter WonderFold Children's Folding Playhouse. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new playhouse. Designed for both indoor and outdoor use, this innovative playhouse offers a fun and engaging environment for children while being incredibly easy to fold and store.



Image: The Keter WonderFold Playhouse in its fully assembled state, showcasing its vibrant multicolor design with a red roof, beige walls, and green doors.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in serious injury.

- Adult supervision is required at all times.
- Ensure the playhouse is assembled on a flat, stable surface.
- Keep children away from moving parts during folding and unfolding.
- Do not allow children to climb on the roof or walls of the playhouse.
- Inspect the playhouse regularly for any damage or loose parts. Discontinue use if damaged.
- This product is intended for children aged 24 months and up.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- WonderFold Playhouse main body (pre-assembled folding panels)
- Roof sections
- Door panels
- Instruction Manual (this document)

4. SETUP AND ASSEMBLY

The Keter WonderFold Playhouse is designed for quick and easy setup. Follow these steps to assemble your playhouse:

1. Unfold the main body of the playhouse from its compact, suitcase-like form. Ensure all panels click into place securely.
2. Attach the roof sections to the top of the playhouse. Align the tabs and press firmly until they lock.
3. Ensure the working doors are properly hinged and can open and close freely.




Image: An illustrated guide showing four steps to fold the playhouse from its assembled state into a compact, flat form for storage.

5. OPERATING INSTRUCTIONS

The WonderFold Playhouse is designed for simple use and convenient storage.

5.1 Using the Playhouse

Once assembled, children can enjoy playing inside and around the playhouse. The working doors allow for easy entry and exit, and the large open windows provide visibility and airflow.



Image: Two children engaging with the Keter WonderFold Playhouse indoors, demonstrating its use as a play space.

5.2 Folding for Storage

One of the key features of the WonderFold Playhouse is its ability to fold into a compact, portable suitcase shape. This makes it ideal for storage in small spaces or for transport.

1. Ensure all items are removed from inside the playhouse.
2. Carefully detach the roof sections.
3. Follow the reverse of the assembly steps to collapse the main body of the playhouse. The panels are designed to fold inward, creating a flat, suitcase-like form.
4. Secure any latches or clips to keep the playhouse in its folded state.



Image: A woman demonstrating how easily the folded Keter WonderFold Playhouse can be stored, sliding it under a bed.

6. MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Keter WonderFold Playhouse, follow these simple care instructions:

- **Cleaning:** Use a soft cloth or hose to wash with water. Mild soap can be used for stubborn dirt. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all connections, hinges, and surfaces for wear, damage, or loose parts.
- **Storage:** When not in use, especially during extreme weather conditions, it is recommended to store the playhouse indoors in its folded, compact form to protect it from elements and prolong its life.

7. TROUBLESHOOTING

This section addresses common questions and minor issues you might encounter.

- **Difficulty Folding/Unfolding:** Ensure all panels are properly aligned and any safety latches are disengaged before attempting to fold or unfold. Do not force the parts.
- **Wobbly Structure:** Check that all connections are securely clicked into place during assembly. Ensure the playhouse is on a flat, level surface.
- **Stains:** For tough stains, a gentle scrub brush with mild soap and water can be used. Rinse thoroughly.

If you encounter persistent issues not covered here, please contact Keter customer support.

8. SPECIFICATIONS


Feature	Detail
Brand	Keter
Model Number	232042
Assembled Dimensions (W x D x H)	89.66 cm x 101.85 cm x 110.49 cm (35.3 in. x 40.1 in. x 43.5 in.)
Item Weight	9.7 kg (21.39 lbs)
Colour	Multicolor
Material Care Instructions	Use a soft cloth or hose to wash with water
Recommended Age	24 months and up
Batteries Required	No
Batteries Included	No
UPC	731161047466


9. WARRANTY AND SUPPORT

Specific warranty information for the Keter WonderFold Children's Folding Playhouse is not provided in this document. For details regarding warranty coverage, claims, or technical support, please refer to the product packaging or visit the official Keter website. You may also contact Keter customer service directly for assistance.

© 2024 Keter. All rights reserved.

Related Documents - 232042

	<p>Keter Darwin 6x4W Garden Shed Assembly Manual - Instructions and Guide</p> <p>Comprehensive assembly manual for the Keter Darwin 6x4W garden shed. Includes site preparation, parts list, step-by-step assembly instructions, and care guidelines. Available in multiple languages.</p>
	<p>Keter PRO SERIES Folding Work Table - Instruction Manual</p> <p>Official instruction manual for the Keter PRO SERIES Folding Work Table. Provides detailed guidance on safe operation, setup, closing, clamp usage, transportation, and maintenance.</p>

	<p>Keter 511L / 135 US GAL Outdoor Storage Box Assembly and Care Guide</p> <p>Comprehensive assembly instructions, features, and care guide for the Keter 511L (135 US GAL) outdoor storage box. Learn how to assemble, use, and maintain your durable Keter storage solution.</p>
	<p>Keter STRONGHOLD Shed User Manual: Assembly and Care Guide</p> <p>Comprehensive user manual for the Keter STRONGHOLD shed, covering assembly instructions, site preparation, parts identification, and care guidelines for models 10x8, 10x11.5, and 10x15.</p>
	<p>Keter 150 US GAL 570L Outdoor Storage Box - Assembly and User Manual</p> <p>Comprehensive assembly instructions and user guide for the Keter 150 US GAL 570L outdoor storage box. Learn how to build, care for, and maintain your durable Keter storage solution.</p>
	<p>Keter DARWIN 6x8 Shed User Manual and Assembly Guide</p> <p>Detailed user manual and assembly guide for the Keter DARWIN 6x8 shed, covering site preparation, parts identification, step-by-step assembly instructions, and care and safety guidelines.</p>

Documents - Keter – 232042



[pdf] User Manual Instructions

Installation Assembly WonderFold 2 94 x 3 34 Playhouse Keter ktr1247 232042 234263 231455Keter

231455installation assemblysecure img1 ag wfcdn dm document 62ea0495 8171 4fd1 a28b

5bd42332384c installation assembly |||

2 EN ASSEMBLY INSTRUCTIONS FR INSTRUCTIONS DE MONTAGE ES
INSTRUCCIONES DE MONTAJE DE MONTAGEANLEITUNG IT ISTRUZIONI DI
MONTAGGIO NL MONTAGE INSTRUCTIES PT INSTRUÇÕES DE MONTAGEM DK
MONTERINGSVEJLEDNING RO INSTRUCIUNI DE ASAMBLARE GR RU SVHE SE
MONTERINGSANVISNING CZ POKYNY K MONTZI SK NVOD N...

lang:en score:15 filesize: 3.27 M page_count: 11 document date: 2016-01-17