

[Manuals.plus](#) /

› [Adesso](#) /

› Adesso 7W LED Desk Lamp with Qi Wireless Charging & USB Port, Model 4217-01 Instruction Manual

Adesso 4217-01

Adesso 7W LED Desk Lamp with Qi Wireless Charging & USB Port

Model: 4217-01

Brand: Adesso

INTRODUCTION

This manual provides instructions for the safe and efficient operation of your Adesso 7W LED Desk Lamp (Model 4217-01). This adjustable LED task lamp features integrated Qi wireless charging and a USB port for convenient device charging.

Please read these instructions thoroughly before use and retain them for future reference.



Figure 1: Adesso 7W LED Desk Lamp (Model 4217-01)

SAFETY INFORMATION

- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not expose the lamp to water or excessive moisture. This product is not water resistant.
- Use only with the provided power adapter.
- Do not attempt to disassemble or modify the lamp. There are no user-serviceable parts.
- Keep away from flammable materials.
- The integrated LED is non-replaceable.

PACKAGE CONTENTS

Verify that all components are present before assembly and operation:

- 1 x Adesso 7W LED Desk Lamp (Model 4217-01)
- 1 x Power Adapter (integrated cord)

SETUP

1. **Unpack the Lamp:** Carefully remove all packaging materials from the lamp and its components.
2. **Position the Lamp:** Place the lamp on a stable, flat surface in your desired location. Ensure the power cord can reach an electrical outlet without being strained or obstructed.
3. **Connect to Power:** Plug the power cord into a standard 120V AC electrical outlet.

BRIGHT, LONG-LASTING LIGHT

Integrated LED, up to 50,000 hours of light. 450 lumens, 3000K Warm Light, CRI 80.



ADESSO®

▲ 4217-01 | COLLETTE LED DESK LAMP - Black

Figure 2: Lamp placement on a desk

OPERATING INSTRUCTIONS

1. Powering On/Off and Adjusting Brightness

The lamp features a 3-way touch dimmer switch located on the top of the lamp head.

- **First Touch:** Turns the lamp ON to its lowest brightness setting.
- **Second Touch:** Increases brightness to the medium setting.
- **Third Touch:** Increases brightness to the highest setting (450 lumens).
- **Fourth Touch:** Turns the lamp OFF.



Figure 3: Touch Dimmer Switch on Lamp Head

2. Adjusting the Lamp Arm and Shade

The lamp is designed with an adjustable arm and shade to direct light as needed.

- Gently adjust the lamp arm at its hinge point to change the height and angle of the light.
- The lamp shade can also be pivoted to further refine the light direction.

FULLY ADJUSTABLE DESIGN

Easily modify the height, arm, and shade for focused illumination or more diffused room lighting.



ADESSO®

▲ 4217-01 | COLLETTE LED DESK LAMP - Black

Figure 4: Adjustable Lamp Positions

3. Qi Wireless Charging

The lamp base includes a built-in Qi-certified wireless charging pad.

1. Ensure the lamp is plugged into a power outlet.
2. Place your Qi-compatible smartphone directly onto the wireless charging pad located on the lamp base.
3. The phone should indicate that it is charging. If not, adjust its position on the pad until charging begins.



Figure 5: Qi Wireless Charging Pad

4. USB Charging Port

An additional USB port is located on the side of the lamp base for charging other devices.

1. Ensure the lamp is plugged into a power outlet.
2. Connect your device's USB charging cable to the USB port on the lamp base.
3. Connect the other end of the cable to your device to begin charging.

Product Demonstration Video

Your browser does not support the video tag.

Video 1: This video demonstrates the features of Adesso lamps with wireless charging, including the Qi wireless charging pad and USB port, and shows the lamp in various settings like a desk and bedside table.

MAINTENANCE

- **Cleaning:** Disconnect the lamp from power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **LED Lifespan:** The integrated LED light source is designed to last up to 50,000 hours and is not replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outage; faulty outlet; touch switch not activated correctly.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Firmly touch the switch on the lamp head.
Wireless charging not working.	Phone not Qi-compatible; phone not positioned correctly; phone case too thick.	Verify your phone supports Qi wireless charging. Reposition the phone on the charging pad. Remove thick phone cases.

Problem	Possible Cause	Solution
USB charging not working.	Cable issue; device issue; lamp not powered.	Try a different USB cable. Ensure the lamp is plugged in. Test with another device.

SPECIFICATIONS

PRACTICAL MEETS POLISHED

Efficient LED room lighting in a sleek, space-saving design creates a warm and welcoming atmosphere.



ADESSO®

▲ 4217-01 | COLLETTE LED DESK LAMP - Black

Figure 6: Product Dimensions

Feature	Detail
Model Number	4217-01
Lamp Type	LED Desk Lamp
Light Source Type	Integrated LED (non-replaceable)

Feature	Detail
Wattage	7 watts
Lumen Output	450 lumens
Color Temperature	3000K Warm Light
LED Lifespan	Up to 50,000 hours
Switch Type	3-Way Touch Dimmer
Charging Features	Qi Wireless Charging Pad, USB Port
Power Source	Corded Electric
Voltage	120 Volts
Product Dimensions	22.5"D x 5"W x 22.25"H
Item Weight	3.17 Pounds
Material	Fabric, Metal
Finish Type	Antique Brass
Indoor/Outdoor Usage	Indoor

WARRANTY

This Adesso 7W LED Desk Lamp (Model 4217-01) is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or improper installation.

Please retain your proof of purchase for warranty claims.

SUPPORT

For technical assistance, troubleshooting, or warranty inquiries, please contact Adesso customer support.

- **Online Support:** Visit the official Adesso website or their Amazon Brand Store for FAQs and contact information.
- **Adesso Brand Store:** [Adesso on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B075QPGS7M>

More documents and user manuals: <https://manuals.plus/>