

[Manuals.plus](#) /

> [hansgrohe](#) /

> hansgrohe Raindance Classic 8-inch Showerhead User Manual, Model 04722830

hansgrohe 04722830

hansgrohe Raindance Classic 8-inch Showerhead User Manual

Model: 04722830

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your hansgrohe Raindance Classic 8-inch Showerhead. Please read these instructions carefully before beginning installation or use to ensure optimal performance and longevity of your product.



Image: Front view of the hansgrohe Raindance Classic 8-inch Showerhead in Polished Nickel finish.

The hansgrohe Raindance Classic showerhead is designed to deliver a consistent and enjoyable showering experience. It features RainAir spray mode with Airpower technology, which infuses water with air for a fuller, softer spray. The QuickClean function allows for easy removal of mineral deposits from the silicone spray nozzles.

SAFETY INFORMATION

- Always shut off the main water supply before attempting any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are secure to prevent leaks.
- Comply with all local, state, and federal plumbing codes and regulations during installation.
- If you are unsure about any part of the installation process, consult a licensed plumber.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- hansgrohe Raindance Classic 8-inch Showerhead (Model 04722830)
- *(Note: Additional components like shower arms or basic sets are sold separately and may be required for complete installation.)*

SETUP AND INSTALLATION

This showerhead is designed for easy DIY installation with a 1/2-inch pipe connection. However, for optimal results and to ensure compliance with all plumbing codes, professional installation by a licensed plumber is recommended.

1. **Prepare the Installation Area:** Ensure the main water supply to your shower is turned off. Remove any existing showerhead and clean the shower arm threads.
2. **Apply Thread Sealant:** Apply plumber's tape (PTFE tape) or thread sealant to the threads of your shower arm. Wrap the tape clockwise around the threads 3-4 times.
3. **Attach the Showerhead:** Carefully thread the hansgrohe Raindance Classic showerhead onto the shower arm. Hand-tighten first, then use an adjustable wrench to tighten an additional 1/4 to 1/2 turn. Do not overtighten, as this can damage the connections.
4. **Check for Leaks:** Turn the main water supply back on and check for any leaks around the connection point. If leaks occur, tighten slightly more or reapply thread sealant.



Image: Rear view of the showerhead, illustrating the 1/2-inch pipe connection point for installation.

Note: This showerhead requires a showerpipe basic set (e.g., No. 16181181) for certain installations. A 9-inch Raindance shower arm (#27422001) is also recommended for optimal positioning.

OPERATING INSTRUCTIONS

The hansgrohe Raindance Classic showerhead features a single, luxurious spray mode: RainAir.

- **RainAir Spray Mode:** This mode utilizes hansgrohe's Airpower technology, which enriches water droplets with air. This creates a softer, fuller, and more voluminous spray that feels gentle on the skin while reducing water consumption.
- **Water Flow:** The showerhead is low-flow compliant, delivering water at a rate of 2.0 gallons per minute (GPM).



Image: Close-up view of the silicone spray nozzles and the "AIRPOWER" inscription on the showerhead face.

To operate, simply turn on your shower's water supply. The showerhead will immediately begin dispensing water in the RainAir spray mode.

MAINTENANCE

Regular cleaning and maintenance will ensure the continued performance and appearance of your hansgrohe showerhead.

- **QuickClean Function:** The silicone spray nozzles are designed with QuickClean technology. To remove mineral deposits (limescale), simply rub your finger across the flexible silicone nozzles. This dislodges any buildup, restoring the spray pattern.
- **Cleaning the Finish:** Clean the polished nickel finish with a soft cloth and a mild, non-abrasive cleaner specifically designed for bathroom fixtures. Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.

- **Regular Inspection:** Periodically inspect the showerhead and connections for any signs of wear or leaks.

TROUBLESHOOTING

If you encounter issues with your showerhead, refer to the following common solutions:

Problem	Possible Cause	Solution
Low water pressure	Mineral buildup in nozzles; partially closed shut-off valve; issues with home's water supply.	Rub QuickClean nozzles to remove deposits. Ensure shut-off valves are fully open. Consult a plumber if home water pressure is generally low.
Uneven spray pattern	Clogged nozzles due to mineral deposits.	Rub QuickClean nozzles to clear blockages.
Leaking at connection point	Loose connection; insufficient thread sealant; damaged threads.	Ensure the showerhead is securely tightened. Reapply plumber's tape. If threads are damaged, consult a plumber for repair or replacement of the shower arm.

If these steps do not resolve the issue, please contact hansgrohe customer support.

SPECIFICATIONS

Brand	hansgrohe
Model Number	04722830
Style	Classic
Shape	Round
Material	Nickel
Finish Type	Polished Nickel
Installation Type	Ceiling Mounted (typically, but can be wall-mounted with appropriate arm)
Number of Settings	1 (RainAir)
Flow Rate	2.0 Gallons Per Minute (GPM)
Special Features	RainAir Air Infusion with Airpower, QuickClean
Certification	Watersense
Product Dimensions	8.38 x 8.38 x 1.25 inches
Item Weight	5.13 pounds

WARRANTY INFORMATION

Hansgrohe, Inc. warrants to the original consumer purchaser that hansgrohe products will be free from defects in material and workmanship for as long as the original consumer purchaser owns both the product and the home in which the

product was originally installed. For commercial purchasers, the warranty period is one (1) year from the date of purchase. The warranty period for products in Rubbed Bronze, Matte Black, and Matte White finishes is three (3) years from the date of purchase. This warranty is non-transferable.

This warranty does not cover hansgrohe products purchased from unauthorized sellers, unless otherwise prohibited by law. Authorized sellers can be found on hansgrohe branded websites. Additional warranty restrictions apply. Please refer to the manufacturer's website for full warranty details.

Visit hansgrohe-usa.com for full warranty details.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact hansgrohe customer service:

Email: customerservice@hansgrohe.com

Website: www.hansgrohe-usa.com

© 2023 hansgrohe. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B075QW6F11>

More documents and user manuals: <https://manuals.plus/>