



[Manuals.plus](#) /

> [Cosmos](#) /

> [Cosmos Studio Ghibli My Neighbor Totoro Noren \(Japanese Curtain\) Instruction Manual](#)

Cosmos 10730

Cosmos Studio Ghibli My Neighbor Totoro Noren (Japanese Curtain) Instruction Manual

Model: 10730

[Introduction](#) [Safety Information](#) [Setup &
Installation](#) [Usage](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

Thank you for purchasing the Cosmos Studio Ghibli My Neighbor Totoro Noren. This traditional Japanese curtain, featuring beloved characters and Daruma dolls, is designed to add a decorative touch to your home. This manual provides essential information for the proper setup, usage, and care of your noren.



Image 1.1: Detailed view of the noren fabric featuring Totoro and Daruma doll motifs.

2. SAFETY INFORMATION

- Keep the noren away from open flames, heaters, and other heat sources to prevent fire hazards.
- Ensure the noren is securely installed to prevent it from falling, which could cause injury or damage.
- Do not allow children or pets to pull on the noren excessively, as this may cause it to detach or tear.
- This product is for indoor decorative use only.

3. SETUP & INSTALLATION

The noren is designed for easy installation in doorways or as a decorative wall hanging. A tension rod (not included) is typically used for hanging.

3.1 Unpacking

- Carefully remove the noren from its packaging.
- Inspect the noren for any signs of damage. If damaged, do not proceed with installation and contact customer support.

3.2 Hanging Instructions

1. **Prepare the Hanging Rod:** Obtain a tension rod or a suitable curtain rod that fits your doorway or desired hanging space.

2. **Insert the Rod:** Thread the tension rod through the top sleeve of the noren.
3. **Position the Noren:** Place the tension rod with the noren attached into the doorway or designated area. Adjust the rod to ensure it is secure and level.
4. **Optional: Cut the Center Slit:** Many noren are designed with a pre-marked line down the center. If you desire a split noren for easier passage, carefully cut along this line using sharp scissors. Start from the bottom and cut upwards to the desired height.





Image 3.1: The noren installed in a doorway, illustrating its typical use.

4. USAGE

The Cosmos Totoro Noren serves multiple purposes:

- **Room Divider:** Use it to subtly separate two areas within a room without completely blocking light or airflow.
- **Decorative Accent:** Enhance the aesthetic of a doorway, wall, or window with its unique design.
- **Privacy Screen:** Provide a degree of privacy for open doorways.



Image 4.1: Another detailed view of the noren fabric, highlighting the blue Totoro and Daruma doll patterns.

5. MAINTENANCE & CARE

To ensure the longevity and appearance of your noren, follow these care instructions:

- **Material:** 100% Polyester.
- **Cleaning:** Hand wash gently in cold water with a mild detergent. Do not bleach.
- **Drying:** Hang to dry in a shaded area. Do not tumble dry.
- **Ironing:** If necessary, iron on a low heat setting on the reverse side.
- **Storage:** When not in use, fold neatly and store in a dry, cool place away from direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Noren sags or falls down.	Tension rod is not securely installed or is too short.	Ensure the tension rod is extended firmly against the door frame. Use a rod of appropriate length for your opening.
Fabric appears wrinkled.	Folded during storage or shipping.	Gently iron on a low heat setting on the reverse side, or hang for a few days to allow wrinkles to relax.
Desired split is uneven.	Imprecise cutting.	Always cut slowly and carefully along the pre-marked line (if present) using sharp scissors.

7. SPECIFICATIONS

Model: 10730

Brand: Cosmos

Material: 100% Polyester

Dimensions: 85cm x 150cm (approximately 33.46 x 59 inches)

Subject Character: Totoro

Assembly Required: Yes (for hanging, cutting optional)

Care Instructions: Hand wash cold, hang dry, low iron.

8. CUSTOMER SUPPORT

For further assistance or inquiries regarding your Cosmos Studio Ghibli My Neighbor Totoro Noren, please refer to the retailer where you purchased the product. Keep your purchase receipt for reference.

